



Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

011-0070	Sub-Brightness, Focus, Horizontal Size, Vertical Size
011-0071	Apple Portrait Display Adjustment
011-0073	Hard Drive 160 Adjustment for RFI Tape
011-0080	Adjustment, CRT / Video
011-0082	Warranty Reimbursement, On-Site, Per Repair
011-0083	Warranty Reimbursement, Facilitation, Per Repair
011-0097	Adjustment, Apple AudioVision 14 Display Warranty Reimbursement
011-0115	Logic Board Reset Procedure, Per Repair
011-0115	Logic Board Reset Procedure, Per Repair
011-0122	Adjustment, Battery Contact
011-0147	DOS Compability Card Jumper Adjustment
011-0150	Digital Monitor, Video Adjustment
011-0156	Adjustment, Logic Board, EMI Clips
011-0424	Monitor, Macintosh 12 Monochrome, Whole Unit
011-0425	Monitor, Macintosh 12 RGB, Whole Unit
011-0435	Adjustment, Macintosh 16 Color Display
011-0440	Adjustments, Macintosh Color Display
011-0451	Warranty Repair Return Reimbursement, Apple Color Printer
011-7004	Write-Protect Switch, Drive Speed
011-7022	Reseating IC, Apple II
011-7024	Reseating IC, Apple IIe
011-7025	DuoDisk / UniDisk Adjustments: D-Speed Adjustment Capacitor Fix
011-7026	Adjustment, CRT / Video
011-7033	Disk IIc Adjustments
011-7043	Yoke, Tilt Main PCB, Vertical, Centering Horizontal, Geometric Focus
011-7051	Horizontal Skew, Vertical Skew, Laser power
011-7056	ColorMonitor IIe and IIc Adjustments: White Balance RG&B Bias Focus Screen
011-7057	Firing Hammer Adjustment Ribbon Adjustment Carrier Belt
011-7060	Main Board: Focus, Horizontal Hold, Sub-Brightness
011-7061	Adjustments, AppleColor RGB Monitor
011-7087	Adjustments, Sub-Brightness, Focus, Horizontal Size, Vertical Size
011-7088	Adjustment, Sub-Brightness, Horizontal / Vertical Center & Size, White Balance, Focus
011-7090	ImageWriter LQ Adjustment
011-7095	Adjustment, Shimmer Correction

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

011-7101	Grounding Upgrade
011-7105	Adjustment, Firing Hammer, Ribbon, Carrier Belt
011-7106	Board Modification, Logic
011-7110	Apple SuperDrive Cleaning
011-7111	Adjustments, Macintosh 21 Color Display
011-7112	Registration Adjustment
011-7602	Magnet Adjustment
074-0360	Label, Product ID, Quadra 950, Pkg. of 5
076-0063	Cover Kit, Clutch
076-0069	Heatsinks Kit, Daughter Board
076-0071	Keypad Set, Locking, SMK (Set of 5)
076-0072	Screw Kit
076-0073	Cap Kit, Flip Foot
076-0074	Door, I / O, with Link
076-0075	Keypad Set, ADB Keyboard, White Plunger (10)
076-0076	Case, Bottom, with Labels, PB Duo 210 / 230 (replaced by 076-0419)
076-0077	AC Inlet Assembly
076-0080	Latch Mechanism, Duo 210 / 230 / 250 / 280, CPRC / International Only
076-0087	Latch Mechanism Kit, Duo 270c / 280c (replaced by 076-0495)
076-0099	Monitor II CRT Module
076-0100	Housing Kit, Display, Duo 270c (Replaced by 076-0485)
076-0101	Case Kit, Bottom, with Labels (replaced by 076-0419)
076-0103	CRT and Yoke Assembly, Rev. A
076-0110	Screw Kit
076-0111	Screw Kit
076-0112	Bottle, Plastic 100 cc
076-0119	Case, Bottom, with Label, HDI-20 External Floppy Drive
076-0120	Bulb Kit, FSTN Display (for 661-0675)
076-0128	Clutches Kit, Left & Right, PB Duo 270c & 280c
076-0129	Bracket Kit, PDS Card, Pkg. of 5
076-0130	Cable Kit, SCSI Select
076-0134	Bushing / Spring Kit
076-0135	Cover Set Kit, SCSI Card, Color 1J
076-0136	Paper Guide Kit

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number Part Name

076-0137	Feeder Roller Kit
076-0138	Platen Kit
076-0139	Screw Kit
076-0149	Ink Absorber Plate Kit
076-0150	Shift Gear Assembly
076-0151	Tractor With Bush
076-0152	Tractor Assembly
076-0153	Platen Assy Parts w / o Platen
076-0154	Paper Bail Assembly
076-0155	Pinch Roller Assembly
076-0157	Carrier Block Assembly
076-0158	Color Ribbon Assembly
076-0159	Ribbon Frame Assembly
076-0160	Carrier Parts
076-0161	Cover, Bottom Assembly, White
076-0162	Support Leg Assembly (Left), White
076-0163	Support Leg Assembly (Right), White
076-0164	Knob, Platen Assembly, White
076-0165	Operation Panel, White (replaced by 076-0240)
076-0168	Transfer Guide & Roller Assembly
076-0169	Sheet Feeder Housing, White
076-0170	Sheet Feeder Frame Assembly, White
076-0171	Sheet Feeder Paper Tray Assembly, White
076-0172	Sheet Feeder PCB Assembly
076-0173	CRT Assy (ColorMonitor Ile / Ilc-S) Composite Ilc-S
076-0192	Parts Set
076-0194	CRT Assy (ColorMonitor Ile / Ilc-S) Composite Ile-H
076-0195	Screw / Cable Kit
076-0199	Fuse Kit, (ColorMonitor Ile / Ilc-H), Composite Ile-H
076-0200	Frame Parts
076-0207	CRT, AppleColor RGB
076-0209	Keyswitch Set, AK / AEK, Tan, Pkg. of 10
076-0224	CRT, Monochrome Monitor
076-0226	Keyswitch Set (10 each), Original Keyboard

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

076-0227	Screw / Cable Kit
076-0229	Screw Kit
076-0230	Cable Kit
076-0234	Board, Interface, Daisy Chain
076-0236	Cover, Bottom, Assembly, Platinum
076-0237	Support Leg Assembly (Left), Platinum
076-0238	Support Leg Assembly (Right), Platinum
076-0239	Knob, Platen Assembly, Platinum
076-0240	Operation Panel, Platinum
076-0241	Sheetfeeder Housing, Platinum
076-0242	Sheet Feeder Paper Tray Assembly, Platinum
076-0245	CRT Assembly, Rev. A
076-0246	CRT Assembly
076-0248	Standoff, Dual Locking (Pkg. of 10)
076-0250	Optical Sensor Kit Assembly
076-0254	Bracket, HDA (replaced by 922-0961)
076-0255	Platen Assembly, Complete
076-0256	Tractor Assembly, Right
076-0257	Tractor Assembly, Left
076-0258	Gear Linkage Assembly
076-0261	Pinch Roller Assembly
076-0262	Misc. Hardware Kit (IWLQ)
076-0265	Housing Panels, Left & Right, Pkg. of 5
076-0269	Spring Kit
076-0270	Pin Pivot, Pkg. of 10
076-0271	Gear, Feed Roller, 5 Pk
076-0272	Button Lamp Lock, Pkg. of 5
076-0273	Foot, Rubber, Pkg. of 10
076-0274	Housing Kit, Top & Bottom, with Labels (replaced by 076-0496)
076-0275	Lid Hinge Assembly
076-0277	Screw, Pn Hd, 3x15 Plat., Pkg. of 10
076-0278	Board Assembly, Start Scan
076-0280	Inverter Assembly
076-0283	Fuse, 2 A, 250 V, Pkg. of 10

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

076-0284	Fuse, 1 A, 250 V, Pkg. of 10
076-0285	Fuse, 3 A, 250V, Pkg. of 10
076-0286	Screw 2, Cover, Pkg. of 10
076-0289	Misc. Hardware Kit, Scanner
076-0290	Carrier Block, Gear / Pulleys, Pkg. of 5
076-0291	Switch, Limit Assembly
076-0292	Screw, Double Sems 3x10, Pkg. of 20
076-0293	Screw, Double Sems 3 x 6, Pkg. of 10
076-0294	Screw, Sems 4 x 6, Pkg. of 10
076-0298	Holder, Ribbon Cable, 4-bit, Pkg. of 5
076-0299	Clutches, Left & Right (replaced by 922-2199)
076-0300	Switch, Cover Interlock, 110 V
076-0301	Screw, Tapping 3 x 8, Pkg. of 10
076-0305	Paper Deflector and Springs
076-0306	Timing Belt and Carrier Assembly
076-0307	Front Carrier Assembly
076-0308	Rear Carrier Assembly
076-0310	Light Meter, R77
076-0311	Fan Kit
076-0312	Spring, Belt Tension, Pkg. of 10
076-0313	Stopper, Carrier, Pkg. of 10
076-0314	Cover, Lamp, Pkg. of 5
076-0315	Switch, Cover Interlock, 220 / 240 V
076-0317	Misc. Hardware Kit, ImageWriter II
076-0320	CRT Assembly
076-0321	Sheet Feeder Frame Assembly, Platinum
076-0322	Spring, Slide, Pkg. of 10
076-0323	Drive Belt Assembly
076-0325	Screw, Double Sems 4 x 8, Pkg. of 10
076-0333	Foot, Printer, Pkg. of 10
076-0334	Foot, CSF, Pkg. of 10
076-0335	Roller, Output Feed
076-0336	Cartridge Hook Kit
076-0337	Screw Hardware Kit

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

076-0338	Keycap Set, Apple Keyboard II, Version A (replaced by 949-0357)
076-0339	CPU Stiffener
076-0342	Carrier Motor Kit, IWII
076-0344	Spring, Paper Deflector, 4 / pk
076-0345	Deflector Stop Plate, Left
076-0346	Deflector Stop Plate, Right
076-0350	CRT Assembly
076-0355	Screw Kit
076-0366	Color Ribbon Assembly
076-0367	Operation Panel, Platinum
076-0368	Knob, Platen Assembly, Platinum
076-0376	Battery Pack, 6 V
076-0377	Keycap Set, Numeric Keypad
076-0378	Keycap Set, Numeric Keypad, International Z version
076-0379	Keycap Set, Numeric Keypad, International PA version
076-0380	End Bracket & LED, Assembled, 160 SC
076-0382	CRT Assembly, Domestic & Europe
076-0384	CRT Assembly, Rev. A
076-0385	CRT Assembly, Europe
076-0386	CRT Assembly, Australia
076-0387	Keyswitch Set, AEK II, Ivory, Pkg. of 10
076-0388	Forms Thickness Lever Kit (contains lever & spring)
076-0389	Cable, Operation Panel
076-0393	CRT Assembly, Rev. B
076-0394	CRT Assembly, International Only
076-0395	CRT Assembly, Rev. B
076-0398	On / Off Switch Filter Assembly
076-0400	Cover, Rear, with Product Label
076-0401	Base & Tray, Cut Sheet Feeder, with Product Label
076-0402	CRT Assembly, Reversed Polarity, Australia
076-0403	Magnetometer Coils, Front / Rear
076-0404	Video Filter Boards, Left / Right
076-0405	Degauss Coils, Upper / Lower
076-0410	Housing Assembly, Bottom

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

076-0411	Feet, Elevation, Rear
076-0412	Cover, Rear Connector Panel
076-0413	Cover, Top
076-0414	Palm Rest Assembly
076-0416	Bezel, Display
076-0417	Bracket Assembly, LaserWriter IIg Controller-I / O Board
076-0418	Bracket Assembly, LaserWriter IIc Controller-I / O Board
076-0419	Case, Bottom, with Labels
076-0422	Keystem w / Spring, AK II, Version B, Pkg. of 10
076-0423	Dome, Rubber, AK II, Version A, Pkg. of 10
076-0430	Microphone
076-0431	Bezel, Blank, CD-ROM Drive
076-0432	Vent, Fan Exhaust
076-0433	Panel, Front, Quadra 900, with Speaker
076-0434	Housing Assembly, Main
076-0435	Screw Kit, Misc., PS fan / Light Pipe / Speaker / FD Spacer
076-0436	Cover, Side
076-0437	Bezel, Floppy
076-0438	Panel, Front, Quadra 950, with Speaker
076-0439	Shields, Dust, Apple SuperDrive (Pkg. of 5)
076-0443	Spring, Paper Guide Plate (Pkg. of 10)
076-0445	Cable, Flex, Hard Drive, with Shield
076-0450	Keycap Set
076-0452	LaserWriter IIc / IIg ROM Kit, Version 2.0
076-0453	Engine Screw Kit, Main
076-0454	Engine Screw Kit, Secondary
076-0455	Hardware Kit
076-0456	Screw Kit
076-0459	Fuser Ring Kit
076-0460	I / F Screw Kit, Pkg. of 2
076-0462	Brackets, Floppy Drive, Pkg. of 5
076-0463	Carriage Assembly Kit
076-0464	Bezel Kit, Display
076-0465	Base, Rev. B

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

076-0466	Subassembly, Plastic, Rev. B
076-0467	Cables Kit, Interconnect to Display
076-0468	Foot Kit, Elevation, Pkg. of 5 Sets (Left / Right)
076-0469	Screw Kit
076-0470	Ink Absorber Kit
076-0471	Idler Bracket, Roller, Spring Kit
076-0472	Panel, Front, Quadra 800, Kit with Bezels
076-0473	Cable Kit
076-0474	Hard Drive Bracket Kit
076-0476	Tray, Tray Guides, Manual Feed
076-0477	Gasket, EMI, Keyboard, Pkg. of 10
076-0478	Gear Kit, Pickup Block
076-0479	Fuser Roller / Bushing / Gear Kit
076-0480	Pickup Block Roller / Shaft Kit
076-0481	Fuser Spring Kit
076-0483	RAM Card Holder Kit, Pkg. of 10
076-0485	Housing Kit, Display
076-0486	Screw Kit, Display
076-0487	O-Ring Kit
076-0488	Shield, All-In-One Enclosure (replaced by 661-0981)
076-0489	Chassis (520 / 550 CD with Caddy) (replaced by 661-0980)
076-0491	Battery Cover, MessagePad 110 / 120, Pkg. of 5
076-0492	Cover, Top, Hinged, Pkg. of 5
076-0495	Latch Mechanism Kit, Duo 270c / 280c / 2300c
076-0496	Housing Kit, Top & Bottom, with Label and EMI Shield
076-0497	Foot Kit
076-0498	Front Door Hinge Kit
076-0499	Cassette Rail Kit
076-0500	Paper Pickup Block Kit
076-0501	Screw Kit
076-0502	Holder, Scale
076-0505	Foot / Spring Kit, Pkg. of 10
076-0506	LED Kit, Media Bay
076-0507	Release Mechanism Kit, Media Bay

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

076-0508	Screw Kit (replaced by 076-0639)
076-0510	Speaker Kit
076-0514	I / O Bracket and Label Kit
076-0515	Sound Enclosure, Misc. Hardware Kit
076-0516	Bezel Kit, Display, 10.4"
076-0517	Bezel Kit, Battery, Pkg. of 5
076-0518	Bezel Kit, Side, Left & Right, Pkg. of 5 Each
076-0519	Housing, Bottom, with Label
076-0520	Lifter Foot Kit
076-0521	Plug / Shield, I / O External Video Connect
076-0524	Case Kit, Floppy Drive
076-0525	Screw Kit, PB 550c
076-0529	Extension Cable Kit
076-0530	Housing Kit, Display
076-0531	Case, Bottom, with Labels
076-0532	Clutch Kit, Left & Right
076-0533	CPU Stiffener Kit (replaced by 922-2055)
076-0534	Screw Kit
076-0535	Foot Kit
076-0537	Fuser Pressure Roller Kit
076-0539	Drive Gear Kit
076-0540	Cable, Self-Terminating Ethernet, 2-Meter
076-0541	Cable, Self-Terminating Ethernet, 5-Meter
076-0542	Cable, Self-Terminating Ethernet, Plenum, 13-Meter
076-0543	Standoffs, Ethernet LC Card, 10 sets
076-0546	CRT and Yoke Assembly, Rev. B
076-0548	ROM Upgrade, Display Card 4 / 8 (661-0607) or 8 / 24 (661-0608)
076-0556	Screw Kit
076-0557	Screw Kit
076-0558	Clutch, Right
076-0559	Clutch, Left
076-0563	CRT Assembly, Anti-Glare, Anti-Static, Replaced by 661-0089
076-0564	CRT Assembly, Anti-Glare, Rev Polarity, Australia
076-0565	Screw / Knob Set

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

076-0566	Battery Recharger, External
076-0567	Battery Recharger, External
076-0575	Screws, Modem, Pkg. of 5
076-0587	Shield, Inverter, PB 170 / 180, Pkg. of 5
076-0588	Shield, Inverter, PB 140 / 145 / 145B / 150 / 160 / 165, Pkg. of 5
076-0589	Top Cover Latch Kit
076-0590	Battery Case (replaced by 076-1539)
076-0591	Battery Case
076-0592	Board Assembly, Start Scan, 24-bit
076-0597	Rails, Mounting, Left & Right
076-0598	Panel, ADB Board, Left / Right
076-0599	Manual Feed Lever Kit
076-0602	Latch Kit, Display
076-0606	Bezel / Housing Kit, Mono Display
076-0607	Bezel / Housing Kit, Color Display (Replaced by 076-0629)
076-0608	Bezel / Housing Kit, Mono Display
076-0609	Bezel / Housing Kit, Color Display (replaced by 076-0631)
076-0610	Film Guides and Transparency Template Kit
076-0611	Tool, Cleaning, Pick-up Roller
076-0615	Fan / Gasket
076-0616	Feed Rollers, Pkg. of 10
076-0619	Latch Kit
076-0620	Screw Kit
076-0621	ROM Kit, 2.0
076-0622	Level & Shim Kit
076-0623	Top Case/Trackpad Button Kit
076-0624	Labels Kit, CLW 12 / 660 Upgrade
076-0625	Screw and Washer Kit, Processor Fan, Pkg. of 2 Each
076-0627	Case Kit, Bottom, CPRC / International Only
076-0629	Bezel/Housing Kit, Color Display
076-0631	Bezel/Housing Kit, Color Display
076-0633	Latch Kit
076-0634	Plugs Kit, Ink Well, Right & Left
076-0635	Plugs Kit, Screw, Bottom Case

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

076-0636	Key, Dummy, Keyboard
076-0637	Screw Kit
076-0638	Spring Kit
076-0639	Screw Kit, REA
076-0640	Door, Flip, Expansion Bay, with Spring
076-0641	Screw Kit, CD-ROM Drive
076-0642	Screw Kit, Floppy Drive
076-0643	Screw Kit, Bottom Case
076-0644	Covers, Front Speakers, Left and Right
076-0645	Clutch / Sleeve Kit, Pkg. of 5
076-0646	Harness Kit (replaced by 076-0711)
076-0647	Spring Kit
076-0648	Screw Kit
076-0649	Feed Core Kit
076-0650	Bearing Kit
076-0651	Separation Pad Kit
076-0652	Registration Sensor Kit
076-0653	Full Stack Actuator Kit
076-0654	Screw Kit
076-0655	Kit, Paper Catch and Spring
076-0656	Kit, Width Adj / Spring / Cork
076-0657	Hardware Assembly, 7" PC Compatibility Card, For Use With 661-1123
076-0658	Floppy Drive Kit, External, Japan Only
076-0659	Standoff Kit, Multiprocessor
076-0662	Gear Kit
076-0663	Bushing / Ring / Spring Kit
076-0664	Roller / Pin Kit
076-0665	Screw Kit
076-0666	Gear Kit
076-0667	Screw / Ring Kit
076-0668	Bushing / Spring / Washer Kit
076-0669	Screw Kit
076-0670	Top Cover Hinge Kit
076-0671	Gear Kit, Pickup Block

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

076-0672	Pickup Block Ring / Spring Kit
076-0673	Pickup Block Roller / Shaft Kit
076-0674	Pickup Block Piece Parts Kit
076-0675	Delivery Assembly Piece Parts Kit
076-0676	Fuser Roller / Bushing / Gear Kit
076-0677	Fuser Spring Kit
076-0678	Spring Kit, Engine
076-0679	Misc. Hardware Kit, 24-bit
076-0680	Screw Kit
076-0681	Bulb Kit, Rev. A Display, PB 140 / 145 (for 661-0706)
076-0682	Bulb Kit, Rev. C Display, PB 140 / 145 / 160 / 165 (for 661-0745)
076-0683	Button Lock Assembly Kit
076-0684	Case, Bottom, with Label, PB 145B (replaced by 076-0870)
076-0685	ROM Upgrade Kit
076-0686	Screw Kit, Display
076-0687	Screw Kit, Bottom Case
076-0688	Case Kit, Floppy Drive
076-0689	Board, Infrared, Japan Only
076-0690	Cover Kit, Panel, Japan Only
076-0692	Structure Kit, Front, Japan Only
076-0693	Screw Kit
076-0694	Plugs Kit, LCD, Left & Right, Japan Only
076-0696	Shields Kit, EMI
076-0697	Palm Rest Kit
076-0698	Battery Latch Kit, Japan Only
076-0699	Card / Cable, Video Out, With Labels
076-0700	Gear Kit
076-0701	Exit Roll Kit
076-0702	Stand, Rubber, Feet Kit
076-0703	Rubber Foot Kit, Keyboard
076-0704	Kit, Clutches, Left and Right
076-0706	Battery Gasket Insertion Tool Kit
076-0709	Knobs, Button, and Spring Kit
076-0710	Screw Kit

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

076-0711	Kit, Cables, Rev. B
076-0713	Cable Kit
076-0714	Fan / Gasket Kit
076-0715	Heatsink Kit, G3 CPU
076-0716	Jumper Block Kit, 233 MHz
076-0717	Jumper Block Kit, 266 MHz
076-0719	Battery, Lithium Ion
076-0720	Eject Arm Kit, Expansion Bay
076-0721	Latch Kit, Keyboard
076-0723	Panel, ADB Board, Left / Right, TCO 95
076-0724	Screw Kit, Bottom Case
076-0727	Lockpawl Kit, Expansion Bay
076-0733	Screw Kit, Display, 12.1" / 13.3" / 14.1"
076-0734	I / O Door Kit, Labels, Door, Springs
076-0737	Jumper Block Kit, 300 MHz
076-0738	Door / Spring Kit, Modem
076-0739	Latch / Spring Kit, Display
076-0740	I / O Wall Kit, 2 Wall Labels
076-0741	EMI Shield Kit, I / O Wall, Left and Right (replaced by 076-0780)
076-0743	Foot Kit, Elevation, with Clips, Bondi Blue
076-0744	PC Cardcage Kit
076-0746	I / O Panel Kit
076-0747	Speaker Kit, Left and Right
076-0748	Shim Kit, Battery, Pkg. of 5
076-0750	Jumper Block Kit, 333 MHz
076-0752	Heatsink Kit
076-0753	Shield Kit, CPU
076-0754	Screw Cover Kit, Left and Right, Pkg. of 20
076-0756	Cable Kit
076-0757	Board, CRT/Video Kit
076-0758	Jumper Block Kit, 400 MHz
076-0759	Jumper Block Kit, 300 MHz
076-0760	Jumper Block Kit, 350 MHz
076-0761	Kit, Modem Shield, Top and Bottom

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number Part Name

076-0762	Kit, Bezel, Zip / Blank
076-0763	Kit, I / O Panel
076-0765	Cable Kit, CRT
076-0766	Cable Kit, USB
076-0768	Button Kit, Power and Control Panel
076-0769	Kit, Heatsink, CPU, Rev 2
076-0770	Foot Kit, Elevation, with Clips, Blueberry
076-0771	Foot Kit, Elevation, with Clips, Strawberry
076-0772	Foot Kit, Elevation, with Clips, Grape
076-0773	Foot Kit, Elevation, with Clips, Tangerine
076-0774	Foot Kit, Elevation, with Clips, Lime
076-0777	Carrier, Hard Drives, Version 2
076-0780	EMI Shield Kit, I / O Wall, Left and Right (replaces 076-0741)
076-0783	Cable / Gasket Kit, PMU (replaces 922-3353)
076-0784	Gasket Kit, PMU, Pkg. of 5
076-0785	Kit, Heatsink, CPU, Rev 3
076-0860	IC, ROM, 512Kx8, 150ns, 32-pin, LL, Rev. 1.0
076-0861	IC, ROM, 512Kx8, 150ns, 32-pin, LM, Rev. 1.0
076-0862	IC, ROM, 512Kx8, 150ns, 32-pin, UM, Rev. 1.0
076-0863	IC, ROM, 512Kx8, 150ns, 32-pin, UU, Rev. 1.0
076-0864	Misc. Hardware Kit, Apple Adjustable Keyboard
076-0865	Keycap Set, Apple Adjustable Keyboard
076-0866	Space Bar, Apple Adjustable Keyboard
076-0868	Keycap Set, Apple Adjustable Keypad
076-0870	Case, Bottom, with Labels
076-0872	Case, Bottom with Labels
076-1018	Cable Accessory Kit
076-1019	ROM Upgrade, Display Card 8 / 24GC (661-0606)
076-1020	Screw / Knob Set
076-1021	Screw Kit, Miscellaneous, AppleCD 150 / 300
076-1539	Battery Case, Nicad
076-2000	Fuser Ring Kit
076-2001	Standard Screw Kit
076-2002	Board Screw Kit

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

076-2003	Drive Assembly Screw Kit
076-2004	Spring Kit
076-2005	Panel Assembly, Left / Right, AppleCD 150 / 300
076-8075	Cable Assembly, RJ-11
076-8117	Monitor IIc Stand Friction Cone, (12)
076-8126	Corona Wire, Set of 2
076-8128	Flat Panel Display, LCD
076-8130	Bearing / Bushing, Type JP, (10pk)
076-8131	Bearing / Bushing, Type T, (10 pk)
076-8133	Screw Assembly, Miscellaneous
076-8135	Ring Set, Grip / E
076-8136	Pin Set, Guide / Roll
076-8137	Spring Set
076-8138	Gear Kit
076-8139	Screw Set
076-8149	Res. Assy, 47 Ohm, (Pkg. of 10)
076-8150	Misc. Hardware Kit
076-8167	Gear / Roller Kit, Fuser
076-8168	Spring / Terminal Set, Fuser
076-8343	Spacebar Stabilizer Assembly, Apple IIe
076-8375	Paper Deflector with Springs
076-8376	Frame Parts
076-8379	Dowel and Ring Kit
076-8382	Screw Kit
076-8392	Spring Kit
076-8410	Bracket Hardware Kit
076-8414	Claw, Separation, 5 PK
076-8415	Clamp and Spacer Kit
076-8416	Spring Kit
076-8418	Gear, Pin, Stopper, Ring and Holder Kit
076-8545	Shim, Display Cable, PB 140, Pkg. of 5
077-0153	Card, PC Diagnostics
077-0160	Alignment Tool, PC Cardcage
077-0168	Adapter, Adjustment

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

077-0830	Adjustment Tool, Gauge, Gap, 1.2 mm
101-4151	Resister, 150Ω, .25W, ±5%
101-4271	Joystick, Resistor, 270 Ohm
107-0102	Thermistor, Fuser
109-0430	Hand Controller, Potentiometer
109-0648	Knob, Volume Control
109-1020	Pot, 10K ohm, 0.15 W, Contrast
109-1022	Pot, 10K ohm, 0.15W, CC Brightness
121-0117	Capacitor, C522, 0.022 uF, 50 V, Mylar
121-0118	Capacitor, C522, 0.047 uF, 50 V, Mylar
157-0050	Transformer, I / O Board, 110 V
159-0061	Ferrite Bead, Clamp-On
197-0001	Crystal, 14.318630 MHZ
199-0005	Filter, Noise, 100 / 115VAC, 15A
302-9334	IC, 9334
305-0032	IC, 74LS32
305-0074	IC, 74LS74, Disk / / /
306-0125	IC, 74LS125
306-0245	IC, 74LS245
315-0828	IC, 8T28 (Apple II only)
315-0897	IC, 8T97(Apple II only)
327-2003	IC, 2003A
331-0931	IC, Keyboard Encoder
332-9600	IC, Keyboard Encoder
333-0129	IC, DRAM, DIP, 256 Kb 120 ns (replaced by 334-0114)
334-0002	IC, RAM 16K
334-0003	IC RAM 64K 200ns w / Logo
334-0021	RAM 256K
334-0024	IC, Video RAM, 150 ns
334-0114	IC, DRAM, 256 K x 4 bit, 80 ns
334-4256	IC, 256K DRAM, Serial NB Card
341-0001	ROM 16K E0
341-0002	ROM 16K E8
341-0003	ROM 16K F0

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number Part Name

341-0004	ROM16K F8
341-0011	ROM 16K-1AS-D0
341-0012	ROM 16K-1AS-D8
341-0013	ROM 16K-1AS-E0
341-0014	ROM 16K-1AS-E8
341-0015	ROM 16K-1AS-F0
341-0016	ROM16K D0
341-0028	IC, PROM State Machine P6A
341-0036	ROM SPCL
341-0057	ROM, Parallel Printer Card
341-0112	ROM, SCSI Interface Card (replaced by 341-0437)
341-0299	IC, EPROM X- Meg ProFile Interface
341-0437	ROM, SCSI Interface Card
341-0711	IC, ROM, LL0, LWII NTX
341-0712	IC, ROM, HH0, LWII NTX
341-0713	IC, ROM, LL1, LWII NTX
341-0714	IC, ROM, HH1, LWII NTX
341-0715	IC, ROM, LM0, LWII NTX
341-0716	IC, ROM, HM0, LWII NTX
341-0717	IC, ROM, LM1, LWII NTX
341-0718	IC, ROM, HM1, LWII NTX
341-0768	EPROM, 40 / 80 MB Hard Drive, Version TA.2 01
342-0007	ROM, LocalTalk PC Card
342-0020	ROM Autostart F8
342-0077	ROM, Apple IIGS
342-0081	IC, ROM, LaserWriter Rev 2, L0
342-0082	IC, ROM, LaserWriter Rev 2, HO
342-0083	IC, ROM, LaserWriter Rev 2, L1
342-0084	IC, ROM, LaserWriter Rev 2, H1
342-0085	IC, ROM, LaserWriter Rev 2, L2
342-0086	IC, ROM, LaserWriter Rev 2, H2
342-0087	IC, ROM, LaserWriter Rev 2, L3
342-0088	IC, ROM, LaserWriter Rev 2, H3
342-0089	IC, ROM, LaserWriter Plus, L0

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number **Part Name**

342-0090	IC, ROM, LaserWriter Plus, H0
342-0091	IC, ROM, LaserWriter Plus, L1
342-0092	IC, ROM, LaserWriter Plus, H1
342-0093	IC, ROM, LaserWriter Plus, L2
342-0094	IC, ROM, LaserWriter Plus, H2
342-0095	IC, ROM, LaserWriter Plus, L3
342-0096	IC, ROM, LaserWriter Plus, H3
342-0097	IC, ROM, LaserWriter Plus,L4
342-0098	IC, ROM, LaserWriter Plus,H4
342-0099	IC, ROM, LaserWriter Plus,L5
342-0100	IC, ROM, LaserWriter Plus,H5
342-0101	IC, ROM, LaserWriter Plus,L6
342-0102	IC, ROM, LaserWriter Plus, H6
342-0103	IC, ROM, LaserWriter Plus,L7
342-0104	IC, ROM, LaserWriter Plus,H7
342-0132	IC, ROM, 16K, Keyboard
342-0133	IC ROM 32K Character Generator
342-0134	IC ROM 'EF' Firmware
342-0135	IC ROM 'CD' Firmware
342-0170	IC, PAL, A2e, State, Mach.
342-0220	ROM, High Boot, 256K (replaced by 661-0220)
342-0221	ROM, Low Boot, 256K (replaced by 661-0221)
342-0265	IC Character Generator Rom, Enhanced Ile
342-0303	IC ROM 'EF' Enhanced Ile
342-0304	IC ROM 'CD' Enhanced Ile
342-0341	ROM, High Boot (replaced by 661-0632)
342-0342	ROM, Low Boot (replaced by 661-0633)
342-0359	IC, 1M ROM, LW Rev 47, L0
342-0360	IC, 1M ROM, LW Rev 47,H0
342-0361	IC, 1M ROM, LW Rev 47, L1
342-0362	IC, 1M ROM, LW Rev 47, H1
342-0363	IC, 1M ROM, LW Plus Rev 47, L0
342-0364	IC, 1M ROM, LW Plus Rev 47, H0
342-0365	IC, 1M ROM, LW Plus Rev 47, L1

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number **Part Name**

342-0366	IC, 1M ROM, LW Plus Rev 47, H1
342-0367	IC, 1M ROM, LW Plus Rev 47,L2
342-0368	IC, 1M ROM, LW Plus Rev 47, H2
342-0369	IC, 1M ROM, LW Plus Rev 47, L3
342-0370	IC, 1M ROM, LW Plus Rev 47, H3
342-0371	IC, 512K ROM, LW Plus Rev 47, L0
342-0372	IC, 512K ROM, LW Plus Rev 47, H0
342-0373	IC, 512K ROM, LW Plus Rev 47, L1
342-0374	IC, 512K ROM, LW Plus Rev 47, H1
342-0375	IC, 512K ROM, LW Plus Rev 47, L2
342-0376	IC, 512K ROM, LW Plus Rev 47, H2
342-0377	IC, 512K ROM, LW Plus Rev 47, L3
342-0378	IC, 512K ROM, LW Plus Rev 47, H3
342-0379	IC, 512K ROM, LW Plus Rev 47, L4
342-0380	IC, 512K ROM, LW Plus Rev 47, H4
342-0381	IC, 512K ROM, LW Plus Rev 47, L5
342-0382	IC, 512K ROM, LW Plus Rev 47, H5
342-0383	IC, 512K ROM, LW Plus Rev 47, L6
342-0384	IC, 512K ROM, LW Plus Rev 47, H6
342-0385	IC, 512K ROM, LW Plus Rev 47, L7
342-0386	IC, 512K ROM, LW Plus Rev 47, H7
342-0387	Rom, AppleFax Modem
342-0445	IC, ROM 256K
342-0545	IC, ROM, L0, LW IINT
342-0546	IC, ROM, H0, LW IINT
342-0547	IC, ROM, L1, LW IINT
342-0548	IC, ROM, H1, LW IINT
342-0549	IC, ROM, L2, LW IINT
342-0550	IC, ROM, H2, LW IINT
342-0551	IC, ROM, L3, LW IINT
342-0552	IC, ROM, H3, LW IINT
342-0560	IC, ROM, LL0, LW IINTX
342-0561	IC, ROM, HH0, LW IINTX
342-0562	IC, ROM, LL1, LW IINTX

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

342-0563	IC, ROM, HH1, LW IINTX
342-0564	IC, ROM, LM0, LW IINTX
342-0565	IC, ROM, HM0, LW IINTX
342-0566	IC, ROM, LM1, LW IINTX
342-0567	IC, ROM, HM1, LW IINTX
342-0568	IC, 512K ROM, LW Rev 47, L0
342-0569	IC, 512K ROM, LW Rev 47, H0
342-0570	IC, 512K ROM, LW Rev 47, L1
342-0571	IC, 512K ROM, LW Rev 47, H1
342-0572	IC, 512K ROM, LW REV 47, L2
342-0573	IC, 512K ROM, LW Rev 47, H2
342-0574	IC, 512K ROM, LW Rev 47, L3
342-0575	IC, 512K ROM, LW Rev 47, H3
342-0639	IC, ROM, 512K HI (replaced by 661-0639)
342-0640	IC, ROM, 512K MED HI (replaced by 661-0640)
342-0641	IC, ROM, 512K Med Low (replaced by 661-0641)
342-0642	IC, ROM 512K, LOW (replaced by 661-0642)
342-0701	IC, ROM, HI (replaced by 661-0701)
342-0702	IC, ROM, LOW (replaced by 661-0702)
343-0002	IC, HMMU
343S0062	IC, SWIM
344-0010	IC, MMU
344-0020	IC, IOU
344S0046	VGC, Apple II GS
344S0062	IC, SWIM (replaced by 343s0062)
351-3146	IC, 3146
352-3141	IC, High Volt. Diode 30V, 100 mA
353-7815	IC,7815, 15V POS. Volt Reg. IC601
353-7816	Photo-Interrupter (replaced by 922-1353)
355-3470	IC, MC3470 Floppy Disk Read Ampl.
400-1604	Screw, 6-32x1 / 4
400-1606	Screw, 6-32x3 / 8, Disk III
400-1612	Screw, 6-32x3 / 4
400-3604	Screw, 6-32x 1 / 4, Pozi-Drive FLT Hd, Disk II

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

407-1605	Screw, 6-32x5 / 16 Pan Head
408-1603	Screw, 6-32 x 3 / 16
410-1308	Screw, M3X.5x8mm
416-1304	Screw, Metal Shield
416-1305	Screw, Torx, External 800K Drive
416-1306	Screw, M3x6mm, Mach
416-1310	Screw, M3x.5x10mm, PN, CRS
416-1330	Screw, M3x.5x30mm (Fan to Plenum)
416-1412	Screw, M3.5x.6x8 (replaced by 416-1414)
416-1414	Screw, Cover
420-1011	Screw, Eject Switch Bracket
424-1001	Screw, Tap M2.9x1.06x13
426-1001	Screw, Tap, M4.22 x 1.41 x 13, Torx, Zinc (CRT & Chassis)
426-1007	Screw, Tap, M4.22 x 1.41 x 16, Torx, Zinc, Case Top (replaced by 922-0392)
430-1019	Tap Screw 4-24x1 / 4
430-1020	Tap Screw 4-24x.750 PN CRS Rec. A
430-1025	Screw, Tap 2.20x6.25 (keybd. case)
430-1029	Screw, Tap 4-20 x .250
430-1030	Screw, Tap 4-14 x .750
430-1031	Screw, Cover
435-5002	Screw, Tap 8.32 x .625 Fill, Torx, Zinc Oxide (Case Bottom)
440-4105	Screw, Sem 4-40 x3 / 8
440-6105	Screw, SEMS 6-32x.313 PN (replaced by 922-1381)
444-6104	Screw, 6-32x.250
450-0032	Screw, NuBus Adapter Bracket
460-3400	Screw, M3X0.5X6MM
462-3100	Screw, M3 x 0.5 x 6
462-3401	Screw, M3x6, with Two Washers
462-4100	Screw, M 3.5 x 6 x .8 PNCR Rec
467-3000	Screw, M3.5x10
470-2100	Screw, 2.9 x 6mm (replaced by 490-0002)
470-2101	Screw, M2.9 x 10 (replaced by 440-4105)
490-0001	Screw, Power / Sweep to Chassis; HDA to Apple SuperDrive
490-0002	Screw, Tap, 6-32x.375 (Chassis Grounding) (replaced by 922-1234)

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

511-1603	IC, Socket, 16-pin
517-0546	Connector, Jumper, Pkg. of 10
517-1230	Jumper, 2-pin
520-0344	Battery Holder
569-0047	Cable, Cassette Sensor
569-0048	Cable, Optical Fiber
569-0049	Cable, Fuser AC Connector
569-0060	Cable, Thermistor
590-0003	Power Cord, AC
590-0007	Cable, Keyboard Interconnect, Apple II
590-0021	Cable, Super Serial Card
590-0024	Cable, Disk III
590-0031	Cable Assembly, Disk II, 15" LG
590-0071	Cable Assembly, LED
590-0090	Cable, Power Adapter EtherTalk, Europe
590-0091	Cable Assembly, British Power Cord
590-0094	Power Cord, 220 V, Smoke, International
590-0095	Power Cord, 220V UK
590-0096	Power Cord, 220V AUS / NZ
590-0097	Power Cord, 220V Swiss
590-0098	Power Cord, 220V Israel
590-0099	Power Cord, 220V Denmark
590-0100	Cable Assembly, LED
590-0101	Cable Assembly, Micro-Switch Eject
590-0108	Cable, Keyboard
590-0109	Cable, ADB Ancillary (replaced by 590-0616)
590-0114	Cable
590-0119	Cable, Numeric Keypad II
590-0126	Cable, SchoolBus, Internal
590-0127	Cable, SchoolBus, External, 3-Meter
590-0129	Cable, Interconnect, Numeric Keypad
590-0130	Cable, Numeric Keypad IIe
590-0132	Cable, Hand Controllers, Apple IIe
590-0133	Cable, SchoolBus, External, 6-Meter

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

590-0140	Cable Assembly, LED, D1
590-0144	Cable, Keyboard / Keypad (replaced by 590-0170)
590-0152	Cable, ADB, Coiled Cord, 1.9M
590-0160	Cable, CRT Socket
590-0167	Cable, Internal, Floppy Drive, Red Stripe
590-0170	Cable, Keyboard / Keypad, Smoke
590-0181	Cable, Internal Disk Drive
590-0183	Cable, Macintosh 400K External Drive
590-0187	Cable, Joystick, Apple IIe / IIc, Beige
590-0188	Cable, 3.5" Drive, Internal, Red or Yellow Stripe
590-0211	Cable, Internal, Hard Drive, SCSI
590-0212	Cable, Disk IIc
590-0221	Cable, LED, Disk IIc
590-0223	Cable Assembly, LED
590-0228	Cable, Hard Drive, Internal, SCSI
590-0235	Cable, SCSI Device to Case
590-0237	Cable, LED, Red (replaced by 922-1243)
590-0238	Cable, SCSI Select (replaced by 922-1247)
590-0248	Cable, LED, 400 MB Hard Drive (replaced by 922-1244)
590-0255	Cable, External 800K Disk Drive (replaced by 590-4360)
590-0260	Power Cord
590-0261	Power Cord, AC, 115 V, Monitor IIc
590-0264	Cable, SCSI Device to Case, AppleCD SC Plus
590-0283	Power Cord, 115 VAC, RT Angle, White
590-0303	Cable, Hard Drive, Power
590-0305	Cable, SCSI, System (replaced by 658-8031)
590-0321	Cable, External Drive
590-0327	Cable Assembly, Drive to CPU (replaced by 590-0367)
590-0360	Cable, External Drive, Smoke (replaced by 590-4360)
590-0361	Cable, ADB Keyboard, 1-Meter (replaced by 590-0616)
590-0367	Cable, Drive to CPU, Smoke
590-0368	Cable, Smoke
590-0370	Power Cord, 110 V, Smoke, 1M
590-0371	Power Cord, 1.9 M, U.S.

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

590-0372	Power Cord, 120 V, Domestic
590-0373	Power Cord, 110 V, Smoke
590-0380	Power Cord, 110 V, Smoke
590-0391	Cable Assembly, LED
590-0392	Cable, Logic Board Power Interconnect
590-0393	Cable, Power Supply, 6-pin
590-0395	Cable, Flat, Main Board / Video Board, 12-pin
590-0396	Cable, Flexible Relay
590-0397	Cable, Main Board / Video Board, 3-pin
590-0398	Cable, Flat, Main Board / Video Board, 14-pin
590-0420	Power Cord, 220 V, European, 1M
590-0421	Power Cord, 1.9 M, European
590-0422	Power Cord, 220 V, European
590-0423	Power Cord, 220 V, Smoke
590-0437	Cable, Floppy Drive, Internal, 3.5" Drive, Yellow Stripe
590-0439	Cable Assembly, LED
590-0440	Cable, LED Assembly
590-0441	Cable, Logic Board to Power Supply
590-0442	Cable, Logic Board to Control Panel
590-0466	Cable, Degaus Coil / Magnetometer Degauss Board
590-0467	Cable, Position Sensor / Magnetometer Degauss Board
590-0468	Cable, Flat, Brightness Control Assembly / Video Filter Board
590-0469	Cable, Flat, Power Supply / Video Filter Board / Main Board
590-0501	Cable, Apple SuperDrive to Logic Board
590-0502	Cable, Display, Original Portable
590-0505	Cable, Internal Hard Drive, Power
590-0506	Cable, Hard Drive, LED, Amber (replaced by 922-1245)
590-0507	Cable, Keyboard / Trackball / Numeric Keypad to Logic Board
590-0511	Cable, Power Supply to Logic Board
590-0512	Cable, Hard Drive, Internal Power, 2x2-pin
590-0515	Cable, Floppy
590-0517	Cable, Power, Hard Drive
590-0518	Cable, SCSI Device Select (replaced by 922-1247)
590-0521	Cable, Power, Hard Drive

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

590-0524	Cable, 1.4MB, FDHD, Internal
590-0525	Cable, Optical Assembly / Logic Board, 8-bit
590-0527	Cable, Hard Drive, LED, Fits 1" Height Drives (replaced by 922-0003)
590-0528	Cable, SCSI, with Terminator
590-0536	Cable, RGB Video, CPU to Monitor
590-0539	Cable, Monitor II Video, Smoke
590-0550	Cable, Peripheral Adapter, Apple IIGS
590-0551	Cable, DB9M to Mini DIN-8M, Rev. A
590-0552	Cable, Mini DIN-8, 2 M, Smoke
590-0553	Cable, Adapter, Mini DIN-8M to DB9F, Rev. B
590-0554	Cable, APM / ImageWriter II / LQ to Apple IIc, Smoke
590-0555	Cable, APM / ImageWriter II / LQ to Apple / / / & / / / Plus, Smoke
590-0556	Cable, ImageWriter II / LQ to Apple II, II+, IIe, Smoke
590-0560	Cable, Joystick, Apple IIe / IIc, Smoke
590-0566	Cable, Internal, Hard Drive, SCSI
590-0574	Cable, Video, DB25 to DB25
590-0575	Cable, Mini DIN-8 to Mini DIN-8, MIDI
590-0576	Cable, DIN-5 to DIN-5, MIDI
590-0583	Cable, Internal Disk Drive
590-0590	Cable, Telephone
590-0600	Cable, PC Drive Card, Internal
590-0601	Cable, Control Panel
590-0602	Cable, AppleTalk Connector
590-0603	Cable, Printhead to Relay PCB
590-0607	Cable, 3.5" Drive, Internal, Yellow Stripe
590-0609	Cable, Hard Drive, Internal, SCSI
590-0612	Cable, Audio Extension
590-0615	Cable, Video, DB15 to DB25
590-0616	Cable, ADB Keyboard, 1-Meter
590-0620	Cable, Video I / O, All Video Overlay Card
590-0625	Cable, RGB Video, All Video Overlay Card
590-0626	Cable, Internal ADB, Tilt-Swivel Monitor Stand
590-0627	Cable, UTP RJ4, 100 OHMS
590-0630	Cable, Hard Drive, LED, Fits 1" Height Drives (replaced by 922-0003)

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

590-0690	Cable, Apple Hydra, for Serial NuBus
590-0691	Cable, Apple V.35
590-0693	Cable, CPU to Monitor
590-0695	Terminator II, Cable, SCSI, Apple (replaced by 922-1185)
590-0703	Cable, Apple Ile Card
590-0705	Terminator II, Cable, SCSI, Apple, Black
590-0717	Cable, HDI-30, SCSI System
590-0718	Cable, HDI-30, SCSI Adapter
590-0719	Cable, HDI-20, Drive to CPU
590-0734	Cable, Video
590-0760	Power Cord, 110 V, AC, Smoke
590-0790	Cable, SCSI Select, 400 MB Hard Drive (replaced by 922-1247)
590-0794	Cable, SCSI Select, 230 / 500 MB Hard Drive (replaced by 922-1248)
590-4037	Cable, 50-Pin, SCSI Device to Case, 160 SC
590-4161	Cable, CPU to Monitor, 1.75 M
590-4360	Cable, External Drive
590-4501	Cable, ADB, 2 M
590-4510	Cable, CPU to Monitor
590-4512	Cable, Sound-Out
590-4513	Cable, Sound-In
590-4515	Internal SCSI Terminator Block, Mac IIcx
590-4516	Internal SCSI Filter, Mac IIcx
590-4550	Cable, Interface Card
590-4551	Cable, Carriage Assembly PCB
590-4552	Cable, Power Supply to Main Logic Board
590-4553	Cable, Operation Panel PCB
590-4555	Cable, SF, ImageWriter II / L
591-0025	Cable, 1.4 MB FDHD
591-0026	Cable, Hard Drive, SCSI
591-0027	Cable, Hard Drive, Power
600-0008	Configuration Block, Super Serial 1
600-0009	Speaker Assembly
600-0136	Cover, Rear
600-0180	Cable, Ext. 80 Column AppleColor Card

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

600-0190	EtherTalk Interface Card Accessory Pack
600-0193	Fan Assembly LC II
600-0349	Speaker
600-0361	Tube of 16K RAM (25 IC / tube)
600-0393	Speaker
600-0403	Speaker
600-0406	Speaker
600-0425	Wire Harness, 9 V
600-0455	Power Supply
600-0530	Board, Battery Holder, Mac II / IIx, 2 Pk
600-4454	CD, 5XXX, 6XXX, Update
600-8010	Assy, Installation Hardware (All / II+ and Alle)
601-0176	Accessory Kit
601-0669	Accessory Kit, USA
601-1030	Accessory Kit, Macintosh
601-1031	Accessory Kit, Windows
603-5010	Door, HDI-20 External Floppy Drive
603-5011	Pins, Door Retainer, HDI-20 External Floppy Drive (replaced by 922-0001)
603-5106	Shield, Outer Metal
603-5109	Cable Assembly, LED
603-5110	Cable Assembly, Eject Switch
603-5111	Cover, Bottom, Platinum
603-5112	Cover, Top, Platinum
603-5113	Door, Platinum
603-5117	Case, Bottom, Plastic
603-5118	Cable Assembly, LED, Yellow
603-5120	Case, Top, HDI-20 External Floppy Drive
603-5121	Case, Bottom, HDI-20 External Floppy Drive (replaced by 076-0119)
605-0119	Apple II Keycap Set-Non Sculptured
605-0133	Apple II Keycap Set-Sculptured
607-5004	Top Cover, Apple IIGS
607-5005	Base, Apple IIGS
607-5006	Case Hinge, Apple IIGS
607-5007	Fan

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

607-5010	Apple II Junction Box
607-5012	Bottom Pan, Apple IIGS Upgrade
607-5015	Case & Lid, Alle, Platinum
607-5033	Apple II Spacer Clip
607-5174	Speaker
607-5183	Assembly, Upgrade Hardware
609-0003	Speaker Assembly
612-5004	Power Supply RFI Shield Assembly
612-5025	Case, Top
612-5029	Case, Apple IIc, Top
612-5030	Case, Apple IIc, Bottom
616-0004	Door, Battery, Type 1
620-0045	Case, Top
620-0046	Case, Bottom (replaced by 076-0419)
630-0408	Terminator, SCSI
630-0500	Housing, Bottom Case, Macintosh LC
630-0501	Housing, Bottom Case
630-0505	Housing, Top Case, Macintosh LC
630-0507	Housing, Top Case, Macintosh LC II
630-0534	Cable, Flex, Hard Drive
630-4166	Board, Rear Audio
630-4173	Board, LED
630-5009	Bezel, Display, PB 170
630-5017	Case, Top
630-5027	Case, Bottom (replaced by 076-0870)
630-5058	Fan / Speaker Assembly (LC only)
630-5063	Housing, Display, PB 170
630-5071	Case, Handle
630-5139	Housing, Rear, with Label
630-5180	Case Assembly, Top, 800K Drive, Beige
630-5181	Case Assembly, Bottom, 800K Drive, Beige
630-5211	Housing, Rear
630-5222	Speaker
630-5227	Assembly, Bottom Cover, Macintosh II

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

630-5229	Assembly, Top Cover and Latches
630-5235	Housing, Rear, Platinum
630-5241	Thermistor Assembly, Flex Circuit
630-5257	Case, Plastic Bottom, Beige
630-5258	Case, Plastic Top, Beige
630-5271	Housing, Rear, with Door and Feet
630-5287	Case, Plastic Bottom, 20 SC, Platinum
630-5288	Case, Plastic Top, 20 SC, Platinum
630-5297	Case, Bottom
630-5298	Case, Top
630-5302	Assy, Disk Slot Plug
630-5303	Chassis (replaced by 805-0938)
630-5330	Slot Plug, Apple SuperDrive
630-5335	Case, Plastic Bottom, 40 SC
630-5337	Case, Plastic Bottom, 80 SC
630-5376	Case, Top
630-5377	Case, Bottom
630-5412	Case, Bottom
630-5413	Case, Top
630-5418	Case, Bottom (replaced by 630-5844)
630-5425	Light Pipe Assembly
630-5494	Assy, Bottom Cover, Macintosh IIx
630-5499	Bezel, Front, with Speaker
630-5502	Bottom Case, Macintosh IIcx
630-5503	Speaker
630-5505	Light Pipe Assembly
630-5506	Case, Bottom
630-5574	Case, Carrying
630-5662	Case, Bottom
630-5684	Subframe
630-5687	Cover, Rear
630-5700	Case, Plastic Bottom, 160 SC
630-5723	Battery Cover
630-5802	Case, Plastic to Assembly, Platinum, 160 SC

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

630-5803	Housing, Bottom Case
630-5804	Housing, Top Case
630-5806	Assembly, Bottom Cover, Macintosh IIfx
630-5818	Chassis with Plenum
630-5825	Bezel, Front, Macintosh Classic
630-5844	Case, Bottom, Lightweight
630-5954	CRT and Yoke Assembly, Rev. B (replaced by 076-0546)
630-5992	Housing, Bottom, Quadra 700
630-5999	Speaker, 8 Ohms
630-6011	Speaker
630-6045	Housing, Rear, with Feet
630-6046	Bezel, Front, Macintosh Classic II
630-6097	Drive Shelf with Cable Straps
630-6229	Bezel, Display, PB 140
630-6271	Cable, Flex, Display, Rev. A, PB 140 / 145 (replaced by 936-0108)
630-6272	Cable, Flex, Display, FSTN, Rev. B, PB 140 / 145
630-6273	Cable, Flex, Display, Active Matrix, PB 170 / 180
630-6280	Cable, Display, Backlit Portable
630-6282	Interface Box, MIDI
630-6386	Battery Recharger, External
630-6387	Cable, Display, Backlit Upgrade
630-6546	Battery, Backup, with Cable
630-8125	Lisa / Macintosh XL Connector Kit
630-8221	IC, PMMU
630-8272	Locking Connector Kit, DB-9
630-8273	Cable Kit, 10-Meter, Locking
630-8275	Locking Connector Kit, DIN 8
630-8276	Cable Kit, 25-Meter, Locking
630-8503	Transceiver, Ethernet, Thin Coax
630-8504	Ethernet Twisted Pair Transceiver
630-8505	Ethernet AUI Adapter
640-5020	Bracket, I / O Board, PLW SC
640-5022	Bracket, I / O Board, PLW NT
640-8002	Cassette, Letter

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

640-8003	Cassette, Legal
640-8005	Cassette, Envelope
640-8006	Cassette, A4
640-8007	Cassette, B5
641-0106	Ink Cartridge, High-Performance, Black
652-0037	Floppy Drive with Top Case Kit, Manual Insert
652-0593	Refurbishment Kit
652-0597	LaserWriter II Refurbishment Kit
652-0602	Carrier Motor
652-0604	Housing, Display, Original (replaced by 652-0605)
652-0605	Housing, Display, Backlit Portable
655-5006	Case, Top, Assembly, External Disk Drive IIc
655-6101	Adapter Assembly, PCB, Disk / / / & Apple III+
655-8112	Clamp, Peripheral Connector, All+
658-0005	Board, Interface, Keypad II
658-0303	Microphone (replaced by 699-5098)
658-4040	Numeric Keypad Assembly, IIe
658-4045	Keypad Assembly, Macintosh
658-5186	Keycap Set, Beige
658-5190	Keycap Set, Smoke
658-5210	Case, Keyboard Top, AEK II
658-5211	Case, Keyboard Bottom, AEK II
658-7008	Keycap Set, Numeric Keypad II
658-7010	Keycap Set, Apple Extended Keyboard & AEK II (replaced by 922-3083)
658-7011	Keycap Set, Apple Keyboard
658-7014	Keycap Set, Platinum (for P / N 661-0357)
658-7039	Keycap Set, Mac 128K, 512K, 512Ke, Beige
658-7044	Keycap Set, Numeric Keypad IIe (replaced by 658-4040)
658-7045	Keycap Set, Apple IIe, Alps, Beige w / Black
658-7055	Keycap Set (For P / N 661-91181) (replaced by 661-0294)
658-7083	Keycap Set, Alps Beige (For P / N 661-0294) (replaced by 661-0294)
658-7096	Keycap Set, Alps Platinum (For P / N 661-0361) (replaced by 661-0361)
658-7101	Keycap Set
658-7136	Keycap set

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

658-8031	Cable, System, CPU to SCSI Device
658-8032	Terminator, Cable (replaced by 922-1185)
658-8033	Extender, Cable
658-8034	Cable, Peripheral Interface
658-8351	Bezel, Plastic Case
658-8352	Housing, Rear, Plastic
658-9001	Keycap, Reset, Apple Extended Keyboard II (replaced by 922-3083)
661-0004	CRT Assembly, 9" RGB, Domestic
661-0008	Monitor, Apple Basic Color, Whole Unit, US (645-0031 / PA645-0031) (replaced by
661-0009	Monitor, Apple Basic Color, Whole Unit, US / Pacific (645-0032 / PA645-0032)
661-0011	Board, Logic, 33 MHz, 4 MB, Ethernet, FPU, Quadra 650
661-0013	Battery, Nicad, 2.9 Amp Hour
661-0022	CRT Assembly, 9" RGB, European
661-0023	CD-ROM Drive, 2x, SCSI, Apple CD 300, Caddy Loading
661-0024	CRT Assembly, 9" RGB, Australia
661-0025	Fuser Assembly, 110 V
661-0026	Fuser Assembly, 220 V
661-0027	Laser / Scanner Assembly
661-0028	Controller Assembly, 240 V
661-0029	Controller Assembly, 120 V
661-0030	Board, I / O, Personal LaserWriter 300
661-0031	Monitor, Apple Basic Color, Whole Unit, Rev. B, US (645-0029) (replaced by 661-1186)
661-0035	Card, Power Macintosh Upgrade, 040 PDS
661-0036	Card, Ethernet, Thin Net, Comm Slot
661-0037	Keyboard, U.S.
661-0038	Trackpad (replaced by 661-0934)
661-0039	Tape Drive, DAT, DDS-2, 120 M
661-0042	Board, Logic, without FPU, Quadra 610
661-0043	Board, Logic, FPU, Ethernet
661-0044	Board, Logic, 33 MHz, 8 MB, Quadra 650
661-0047	Hard Drive, 500 MB, IDE, 2.5"
661-0048	Speakers, AppleDesign Powered Speakers II, Platinum
661-0049	Adapter, NuBus, Power Macintosh
661-0051	Board, Logic, Duo 280 / 280c

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0052	Display, Active Matrix, Monochrome, CPRC / International Only
661-0053	Battery, Type 3
661-0054	Board, Mother, with Fuse, Rev. A
661-0055	Battery Pack with Door
661-0056	Display, TFT, Color, CPRC / International Only
661-0057	Board, Daughter, 33 Mhz, Rev. A
661-0058	Card, RAM, 8 MB
661-0059	Board, Daughter, 25 MHz, Rev. A
661-0061	Floppy Drive, 1.4 MB (replaced by 661-0994)
661-0062	Display, Dual Scan Color, PB 520c
661-0063	Display, TFT, Monochrome, CPRC / International Only
661-0064	Display, Dual Scan Monochrome
661-0068	Hard Drive, 350 MB, IDE, 3.5" (replaced by 661-0146)
661-0070	Hard Drive, 250 MB, IDE, 3.5" (replaced by 661-0146)
661-0086	Hard Drive, 500 MB, IDE, 3.5" (replaced by 661-0146)
661-0087	SIMM, DRAM, 16 MB, 80 ns, 72-pin
661-0089	Monitor, Multiple Scan 17, North, Whole Unit
661-0090	Board, I / O Controller
661-0091	Fuser Assembly, 110 V
661-0092	Fuser Assembly, 220 V
661-0093	Laser / Scanner Assembly
661-0094	Board, DC Controller
661-0095	Card, Fax, U.S.
661-0096	High-Voltage Power Supply
661-0097	Power Supply, 110 V
661-0098	Power Supply, 220 V
661-0101	Speakers, AppleDesign Powered II, Slate
661-0102	Board, Main Deflection, with E. Star Compliance
661-0104	Mouse II, Apple Desktop Bus, Rev. B (discontinued and replaced by 922-2733)
661-0106	Board, Modem, International
661-0107	Board, Modem, U.S.
661-0108	Board, Mother, with Fuse, Rev. B
661-0109	Board, Daughter, 33 MHz, Rev. B
661-0110	CD-ROM Drive, 1x, SCSI, Apple CD SC, Caddy Loading, External

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0113	Monitor, Performa Plus Display, .29 Dot Pitch, US, Whole Unit
661-0114	Monitor, Performa Display, .39 Dot Pitch, US, Whole Unit (replaced by 661-1186)
661-0117	Board, Power Sweep
661-0118	Board, Video
661-0119	Board, CRT Video
661-0121	Floppy Drive, Apple SuperDrive, 1.4 MB, Manual Insert
661-0122	Board, Daughter, 25 MHz, Rev. B
661-0123	Board, Controller
661-0124	Board, Controller
661-0128	Monitor, Apple Multiple Scan 15 Display, Whole Unit with Video Cable, Canada
661-0130	Card, Fax, International
661-0131	SIMM, 512K Cache, Power Macintosh
661-0132	Board, Logic, 601, 80 MHz (replaced by 661-0993)
661-0133	Board, I / O Controller
661-0135	Monitor, Apple Multiple Scan 20, Whole Unit, Canada
661-0136	Card, Token Ring, NB, 7"
661-0137	PCMCIA Expansion Module, Rev. B (replaced by 661-1060)
661-0138	Board, Monitor Connection (replaced by 922-1160)
661-0139	Board, Front Panel Control
661-0140	Board, Logic
661-0143	Display, FSTN
661-0146	Hard Drive, 500 MB, IDE, 3.5"
661-0151	Board, Daughter, 603
661-0153	Board, Logic, 603e, 100 MHz
661-0154	Board, Logic, 040, 33 MHz, 4 MB
661-0156	Card, RAM, 8 MB
661-0158	Board, Logic, 1-72 Pin SIMM Slot
661-0159	Card, Video-In, Rev. A (replaced by 661-1073)
661-0160	Card, TV Tuner
661-0161	Board, Logic, Color StyleWriter
661-0162	Power Supply, 110 V
661-0163	Power Supply, 220 V
661-0169	Board, Main Deflection, Rev. B, with E. Star Compliance
661-0170	Power Supply

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0175	Hard Drive, 500 MB, SCSI, 2.5" (replaced by 661-1298)
661-0180	Hard Drive, 2 GB, SCSI, 3.5"
661-0182	Hard Drive, 350 MB, SCSI, 3.5" (Replaced by 661-0219)
661-0184	Hard Drive, 700 MB, SCSI, 3.5", Replaced by 661-1102
661-0185	Board, Logic, 24-bit, Color OneScanner / B
661-0186	Power Supply, Color OneScanner / B
661-0187	Optical Assembly, Color OneScanner / B
661-0189	Board, Logic, 4 MB, Quadra 630
661-0190	Board, Interconnect
661-0191	Hard Drive, 240 MB, SCSI, 2.5"
661-0192	Board, Analog, LC 520 / 550 / 575 & Peforma 550
661-0193	Board, Analog (replaced by 661-0872)
661-0195	Monitor, Apple Multiple Scan 15 Display, Whole Unit without Video Cable, Pol / North, Canada
661-0197	LocalTalk Option, Whole Unit (replaced by 922-2172)
661-0198	Board, Modem, International
661-0199	Board, Logic, 110 MHz
661-0200	Board, I / O
661-0201	Controller, 110 / 115V
661-0202	Laser / Scanner Assembly
661-0203	Controller, 220 / 240V
661-0207	Board, Logic, 66 MHz
661-0208	Board, Logic, 80 MHz
661-0209	Board, Logic
661-0210	Board, Logic, 120 MHz, WS 9150 / 120
661-0211	Hard Drive, 80 MB, SCSI, 2.5" (replaced by 661-1298)
661-0216	Hard Drive, 40 MB, SCSI, 3.5"
661-0217	Hard Drive, 240 MB, SCSI, 2.5" (replaced by 661-1298)
661-0219	Hard Drive, 500 MB, SCSI, 3.5"
661-0220	ROM, High, Macintosh w / 400k floppy
661-0221	ROM, Low, Macintosh w / 400K floppy
661-0222	CD-ROM Drive, 2x, SCSI, Apple CD 300+, Trayloading (replaced by 661-0913)
661-0225	CD-ROM Drive, 2x, SCSI, Apple CD 300+, Trayloading, External
661-0226	Card, Ethernet LC Twisted Pair
661-0228	Hard Drive, 1 GB, SCSI, 3.5" (replaced by 661-1142)

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0230	Card, DOS Compatibility, with Adapter Bracket
661-0232	Power Supply, 225 W
661-0233	Display, Active Matrix, Color, CPRC / International Only
661-0234	Board, Logic, 4 MB, without FPU (replaced by 661-1114)
661-0236	Board, Logic, 4 MB, FPU (replaced by 661-1115)
661-0240	Print Unit
661-0242	Printer, Apple StyleWriter 1200, Whole Unit, 110V
661-0243	Printer, Apple StyleWriter 1200, Whole Unit, 220V
661-0247	Board, Memory, 4 MB
661-0253	Board, Sound, DOS Compatibility
661-0255	Card, Macintosh Processor Upgrade, 256K Cache
661-0257	Board, Controller
661-0258	Mouse Assembly, Apple IIe (replaced by 661-0259)
661-0259	Mouse, Beige, Apple II / Macintosh 512 / 512k / Plus
661-0262	Card, Ext. 80 Column AppleColor, Apple IIe
661-0264	Drive Mechanical Assembly, Apple IIc
661-0265	Board, Drive Analog, Apple IIc
661-0266	High-Voltage Power Supply
661-0267	Board, DC Controller
661-0268	Board, Driver, 110 V
661-0270	Board, I / O (replaced by 661-0436)
661-0273	Board, Power Supply / Motor Drive, 110 V
661-0277	Laser Unit
661-0278	Scanner Unit, 300 DPI
661-0280	Hub, Ethernet, 5-Port
661-0281	Card, Contrast
661-0282	Connector Box
661-0283	Board, Logic, Enhanced, Apple IIe
661-0287	Card, Analog, Unidisk
661-0288	Monitor, Apple MultiScan 15AV, Whole Unit
661-0294	Keyboard, Alps, Apple IIc
661-0303	Drive PCB, ImageWriter II
661-0304	Imagewriter II Main CPU PCB (replaced by 661-0413)
661-0305	Floppy Drive, 800K Mechanism, 3.5" (replaced by 661-0345)

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0306	Card, UniDisk 3.5 - Apple IIe Interface
661-0307	Card, Controller
661-0308	Board, Logic, (Composite IIe, IIc-S), IIc
661-0310	Keyboard, AppleDesign (discontinued and replaced by 922-2832)
661-0313	Apple Personal Modem
661-0314	Numeric Keypad Assembly, II, with Cable
661-0316	Print Head (DDH-90)
661-0317	Board, Logic, (Composite IIe,IIc-H), IIe
661-0318	Card, Memory Expansion (Unpop.)
661-0319	Card, ImageWriter II 32K Option
661-0321	Board, Logic
661-0322	Keyboard, Mac Plus, Beige (replaced by 661-0416)
661-0323	Power Supply, I / O Board
661-0324	Board, I / O, LW Plus (replaced by 661-0437)
661-0325	Card, LocalTalk Option
661-0329	ImageWriter II SheetFeeder, White
661-0331	Board, Power Supply, Rev. A, with Thermistor Connector
661-0334	Board, Logic, Apple IIGS
661-0335	Power Supply, Apple IIGS
661-0336	Card, Memory Expansion, Apple IIGS
661-0337	Keyboard, Apple Desktop Bus
661-0338	Mouse, Apple Desktop Bus (discontinued and replaced by 922-2733)
661-0343	Power Supply
661-0344	Card, SCSI, Apple II
661-0345	Floppy Drive, 800K Mechanism, 3.5"
661-0346	Board, Logic, Monochrome Monitor
661-0347	Board, CRT / Video
661-0348	Board, Power Supply, AppleColor RGB
661-0356	Card, LocalTalk PC
661-0357	Keyboard, Extended, Platinum, Apple IIe
661-0358	Board, Power Supply, 220 V / 240 V
661-0359	Board, Logic, Expandable, Apple IIc
661-0360	Card, Memory Expansion, Apple IIc
661-0361	Keyboard, Alps, Platinum, Apple IIc

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0369	Board, Logic
661-0370	Power Supply
661-0371	Board, Analog
661-0372	Board, Video, Vertical (replaced by 982-0024)
661-0374	Board, Logic
661-0375	Power Supply, Macintosh II
661-0376	Card, Video, Mac II , 4-Bit, 12" B / W, 13" RGB
661-0383	Keyboard, Apple
661-0384	Keyboard, Apple Extended (discontinued and replaced by 922-3083)
661-0385	Card, Video Overlay, Apple II
661-0387	Board, Logic, 24-pin, VER II
661-0389	Card, Workstation, Apple II
661-0392	Tape Backup Mechanism, 40 MG
661-0393	Floppy Drive Mechanism
661-0394	Board, Logic, 24-Pin, VER II
661-0395	Power Supply
661-0396	Board, Main
661-0397	Power Supply, Rev. A
661-0398	Board, Video Color, Rev. A
661-0399	Board, Deflection, Rev. A
661-0400	Mouse, Apple, Platinum
661-0401	Imagewriter II Sheetfeeder, Platinum
661-0402	SIMM, DRAM, 256K, 120 ns
661-0403	SIMM, DRAM, 1 MB, 120 ns (replaced by 661-0520)
661-0404	Board, Main, ImageWriter LQ (replaced by 661-0563)
661-0405	ImageWriter LQ Print Head
661-0406	Card, PC Interface
661-0407	Card, PC 5.25" Drive
661-0410	SIMM, DRAM, DIP, 1 MB, 120 ns (replaced by 661-0520)
661-0413	ImageWriter II Main CPU PCB Rev. A
661-0414	Card, EtherTalk
661-0416	Keyboard, Platinum, Mac Plus
661-0418	Board, Logic, Apple IIc Plus
661-0419	Keyboard, Apple IIc Plus

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0420	Power Supply
661-0423	Laser / Scanner Unit
661-0424	Power Supply, DC, 110 V
661-0425	High-Voltage Power Supply
661-0426	Board, DC Controller
661-0427	Power Supply Block, 110 V
661-0428	Board, I / O, SC
661-0429	Board, I / O, NTX
661-0430	Board, Logic, 4-bit (replaced by 661-0534)
661-0431	Board, Power Supply
661-0432	Card, Apple Macintosh Display, 24AC
661-0433	Board, Logic, Fax Modem
661-0435	Board, Logic, Auxiliary
661-0436	Board, I / O, LW
661-0437	Board, I / O, LW Plus
661-0438	Board, I / O, NT
661-0440	Fuser Assembly, 110V
661-0441	SIMM, DRAM, 256K, 120 ns, 64-pin
661-0442	Power Supply, DC, 220 V
661-0443	Power Supply, Block Assembly, 220 V
661-0444	Fuser, 220 / 240V
661-0445	SIMM, DRAM, 1 MB, 120 ns, 64-pin, LWII (replaced by 661-0548)
661-0446	Cut Sheetfeeder Single Bin
661-0447	Cut Sheetfeeder Extension
661-0449	Optical Assembly, 4-bit
661-0450	Fuser Assermbly, 115 V
661-0451	Board, Deflection
661-0452	Board, Video
661-0453	Power Supply
661-0455	Power Supply, Apple II
661-0456	Card, Video, Apple Macintosh II Two-Page, Monochrome
661-0458	Card, Coax / Twinax Adapter, Macintosh II
661-0459	Board, Logic
661-0460	Card, Token Talk NB, Macintosh II (replaced by 661-1617)

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0461	Power Supply, 110 V, Macintosh, Beige (replaced by 661-0462)
661-0462	Power Supply, 110 V, Macintosh, Platinum
661-0463	Board, Logic
661-0467	Power Supply, 112 W
661-0468	Modem, 2400, Portable, Internal, U.S.
661-0470	Board, Logic, Static RAM
661-0473	Display, LCD, Nonbacklit
661-0474	Floppy Drive, Apple SuperDrive, 1.4 MB
661-0475	Trackball Assembly
661-0476	Keyboard, Portable
661-0477	Keypad, Numeric, Original
661-0479	Mouse, Low Power (discontinued and replaced by 922-2733)
661-0480	Card, Static RAM, 1 MB
661-0490	Board, Logic
661-0492	Card, Video, Mac II, 8-bit (replaced by 661-0533)
661-0493	Card, Video, Macintosh II, Hi-Res Display, 4-bit
661-0494	SIMM, DRAM, DIP, 256K, 120 ns
661-0496	Card, EtherTalk NB (replaced by 982-0496)
661-0498	Board, I / O, IINTX-J
661-0499	Card, High Speed SCSI, Apple II
661-0505	Hard Drive, 320 MB, SCSI, 3.5" (replaced by 661-0219)
661-0506	Board, Main Deflection
661-0507	Board, CRT / Video
661-0508	Power Supply
661-0510	Board, Logic
661-0515	Board, Logic, 1MB, Apple IIGS
661-0516	Board, Logic
661-0517	Card, Serial NB, Macintosh II
661-0518	Card, Video, Macintosh II, Monochrome, 1-bit
661-0519	SIMM, DRAM, 256K, 80 ns
661-0520	SIMM, DRAM, 1 MB, 80 ns
661-0522	Board, Logic, Macintosh IIcx
661-0525	Board, Logic, without RAM
661-0526	Board, Logic, without RAM, 800K

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0527	Board, Logic, without RAM
661-0528	Board, Logic, without RAM, Macintosh
661-0529	Board, Logic, without RAM, Macintosh IIfx
661-0532	Board, Logic, without RAM
661-0533	Card, Video, Mac II, Extended Hi-Res Display, 8-bit
661-0534	Board, Logic, 4-bit, Rev B
661-0536	Board, Logic, without RAM, SuperDrive
661-0537	Board, Logic, without RAM, Macintosh IIfx
661-0540	Hard Drive, 40 MB, SCSI, 3.5", Low Power
661-0541	Board, Main, ImageWriter LQ, (replaced by 661-0563)
661-0542	Power Supply, Macintosh IIfx
661-0543	Keyboard II, Apple Extended (discontinued and replaced by 922-3083)
661-0544	Keyboard II, Apple Extended, ISO (discontinued and replaced by 922-3083)
661-0546	SIMM, DRAM, 1 MB x 9, 80 ns, Parity
661-0548	SIMM, DRAM, 1 MB, 80 ns, 64-pin
661-0563	Board, Main, Revised, ImageWriter LQ
661-0565	Board, I / O, Personal LaserWriter NT
661-0566	Board, I / O, Personal LaserWriter SC
661-0567	Board, DC Controller
661-0568	Fuser Assembly, 110 / 115 V
661-0569	Power Supply, 110 / 115 V
661-0570	SIMM, ROM, 1 MB, NT, APL
661-0571	Laser Assembly
661-0572	Scanner Assembly
661-0573	High-Voltage Power Supply
661-0574	Power Supply, 220 / 240 V
661-0575	Fuser Assembly, 220 / 240 V
661-0581	ImageWriter II / L Main CPU PCB
661-0582	Board, Power Supply, 110 / 120 V, ImageWriter II / L
661-0583	Board, Logic, Parity, Macintosh IIfx
661-0585	Mouse, Apple Desktop Bus
661-0586	Card, Video, Macintosh II Portrait Display, DB15
661-0587	Card, Video, Mac II Portrait Display, DB15 & Video Cable
661-0593	Board, Logic, Macintosh LC

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0594	Power Supply (replaced by 661-1733)
661-0595	Card, Apple IIe
661-0596	Board, Logic, 1 MB, Macintosh Classic
661-0597	Board, Power Sweep, 110 V, Rev. A, Macintosh Classic
661-0598	Board, Memory Expansion, 1 MB, Macintosh Classic
661-0599	Board, Power Sweep, 220 V, Rev. A, Macintosh Classic
661-0602	SIMM, ROM, 256K, NT, APL
661-0603	Keyboard II, Apple (discontinued and replaced by 922-2832)
661-0604	Card, Video, Mac II Portrait Display (replaced by 661-0587)
661-0606	Card, Macintosh Display, 8 / 24 GC (replaced by 661-1642)
661-0607	Card, Macintosh Display, 4 / 8 (replaced by 661-0677)
661-0608	Card, Macintosh Display, 8 / 24 (replaced by 661-0678)
661-0609	SIMM, VRAM, 256K, 100 ns, for use with the 4 / 8 Display CD
661-0610	SIMM, DRAM, Video, 1 MB, 100 ns
661-0615	Board, Main
661-0616	Board, Main Deflection, Rev. A
661-0617	Board, Main Deflection, International, Rev. A
661-0618	Board, CRT Video
661-0619	Card, Ethernet NB, AAUI
661-0620	Card, NuBus, ISDN
661-0621	Card, Apple Ethernet LC
661-0628	Cut Sheet Feeder
661-0629	Board, Logic, Rev. A
661-0630	Printer Frame Assembly, Rev. A
661-0631	Board, Serial I / O
661-0632	ROM, High, Macintosh w / 800k floppy
661-0633	ROM, Low, Macintosh w / 800k floppy
661-0634	Optical Assembly, 8-bit
661-0635	Board, Logic, 8-bit
661-0636	Power Supply, 100 / 115 V
661-0637	Power Supply, 220 / 240 V
661-0639	ROM, High, Macintosh II FDHD
661-0640	ROM, Med High, Macintosh II FDHD
661-0641	ROM, Med Low, Macintosh II FDHD

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0642	ROM, Low, Macintosh II FDHD
661-0643	SIMM, DRAM, 2 MB, 80 ns
661-0644	Adapter, Processor Direct
661-0645	Adapter, NuBus
661-0646	SIMM, DRAM, 512K, 80 ns
661-0647	Display, LCD, Backlit
661-0648	Card, ROM, Backlit Upgrade
661-0649	SIMM, VRAM, 512K (replaced by 661-1021)
661-0650	Board, DC Controller
661-0651	Board, Power Sweep, 110 V, Rev. B, Classic / Classic II & Performa 200
661-0652	Board, Power Sweep, 220 V, Rev. B, Classic / Classic II
661-0653	Board, Video Color, Rev. B
661-0654	Board, Deflection, Rev. B
661-0655	Video Assembly
661-0656	Board, Main Assembly
661-0657	Board, Magnetometer Degauss
661-0658	Board, Power Supply
661-0659	Board, Main Deflection, Rev. B
661-0660	Board, Main Deflection, International, Rev. B
661-0661	Board, I / O, IIg (replaced by 661-0775)
661-0662	Board, I / O, IIc (replaced by 661-0776)
661-0664	Power Supply
661-0665	Board, Logic, without DRAM SIMMs, Quadra 900
661-0666	Board, Logic, Quadra 700
661-0667	Power Supply, 220 / 240 V
661-0668	Power Supply, 100 / 115 V
661-0669	Board, Serial Controller
661-0671	CD-ROM Drive, Apple CD SC+, Caddy Loading, External
661-0672	Board, Logic, 2 MB, Classic II & Performa 200
661-0673	Board, Mother
661-0674	Board, Daughter
661-0675	Display, FSTN
661-0676	Trackball Assembly
661-0677	Card, Macintosh Display, 4 / 8, Rev. B

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0678	Card, Macintosh Display, 8 / 24, Rev. B
661-0679	Board, Logic, Upgrade, Apple IIe
661-0681	Display, FSTN, Rev. B, PB 140 / 145 (replaced by 661-8745)
661-0684	Board, Daughter
661-0685	Board, Interconnect, PB 180c
661-0686	Display, Active Matrix, Color, PB 180c (CPRC / International Only)
661-0687	Board, I / O, Personal LaserWriter 320
661-0688	Card, RAM Expansion, 2 MB
661-0689	Card, RAM Expansion, 6 MB
661-0697	Battery, NiCad
661-0701	ROM, High, FDHD
661-0702	ROM, Low, FDHD
661-0705	Power Supply, Rev. B
661-0706	Display, FSTN, Rev. A, PB 140 / 145
661-0707	Board, Daughter, PB 140
661-0708	Board, Mother
661-0709	Board, Daughter, PB 170
661-0710	Trackball Assembly, PB 140 / 170 (replaced by 661-1515)
661-0711	Display, Active Matrix, CPRC / International Only
661-0712	Keyboard, U.S.
661-0713	Keyboard
661-0714	Card, RAM, 4 MB, 100 ns (replaced by 661-1103)
661-0715	Card, RAM, 2 MB, PB 100 / 140 / 145 / 145B / 160 / 170
661-0716	Board, Logic, Rev. B
661-0718	Printer Frame Assembly, Rev. B
661-0719	SIMM, DRAM, 1 MB, 80 ns, Uses Two 4 Megabit Chips
661-0720	Board, Logic, 25 MHz, Performa 450
661-0721	Battery (replaced by 661-0013)
661-0722	SIMM, VRAM, 256K, 80 ns, 68-pin
661-0723	Battery (replaced by 661-0782)
661-0724	Board, Interconnect
661-0725	Board, I / O, Personal LaserWriter NTR
661-0727	Board, Logic, Quadra 950 & AWS 95
661-0728	Board, Logic, 2 MB, Macintosh LC II

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0729	Board, Logic, 4 MB, Macintosh LC II, Performa 400 / 405 / 410 / 430
661-0730	Trackball Assembly (replaced by 661-1515)
661-0731	Keyboard, Apple Adjustable
661-0732	Board, Analog / Power Supply
661-0733	Board, Logic
661-0734	SIMM, DRAM, 1 MB, 80 ns
661-0737	Adapter, AT to SCSI Host
661-0738	Power Supply Board Assembly, 24-bit
661-0739	Optical Assembly, 24-bit
661-0740	Board, Logic, 24-bit
661-0744	Board, Daughter PB 160
661-0745	Display, FSTN, Rev. C, PB 145 / 145B / 160 / 165
661-0746	Board, Mother
661-0747	Board, Daughter PB 180
661-0748	Display, Active Matrix (CPRC / International Only)
661-0750	Board, Interconnect
661-0751	Board, Daughter, PB 165c
661-0752	Display, FSTN, Color, PB 165c
661-0754	Battery with Case, 2.5 Amp (replaced by 661-0013)
661-0755	Card, Cousin
661-0758	Power Supply, 112 W
661-0759	Board, Logic, Macintosh IIvx
661-0760	Board, Logic, Macintosh IIvi
661-0761	Board, Logic
661-0762	Keypad, Apple Adjustable
661-0763	Mouse II, Apple Desktop Bus (discontinued and replaced by 922-2733)
661-0764	Board, Interconnect, PB 165c
661-0765	Board, Mother
661-0767	Board, DOS Compatible, FPU
661-0769	Board, I / O, IIg (replaced by 661-0775)
661-0770	Board, I / O, IIg (replaced by 661-0776)
661-0772	Hard Drive, 120 MB, SCSI, 2.5" (discontinued and replaced by 661-1298)
661-0775	Board, I / O, IIg
661-0776	Board, I / O, LaserWriter IIg

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0779	Hard Drive, 200 MB, SCSI, 2.5" (replaced by 661-1298)
661-0782	Battery, with Case
661-0785	Printer, StyleWriter II, Whole Unit, 110 V
661-0786	Modem, Express, 14.4 Baud, U.S.
661-0787	Power Supply, HBF (replaced by 661-1733)
661-0788	Board, Daughter, PB 145
661-0789	Battery with Case, 2.8 Amp, PB 140 / 145 / 160 / 165 / 170 / 180 (replaced by
661-0790	Card, RAM, 4 MB, 85 ns
661-0791	SIMM, SRAM, 128K, 17 ns, 68-pin
661-0792	SIMM, SRAM, 256K, 17 ns, 68-pin
661-0793	SIMM, SRAM, TAG, 48K, 14 ns, 60-pin
661-0794	Card, PDS, with Bracket, Workgroup Server 95
661-0795	Tape Drive, 2 GB, DDS-DC, SCSI
661-0797	Board, Controller
661-0798	Board, Controller
661-0799	Board, I / O, LaserWriter Pro 600
661-0800	Board, I / O, LaserWriter Pro 630
661-0801	Laser / Scanner Assembly
661-0802	Power Supply, 110 / 115 V
661-0803	Power Supply, 220 / 240 V
661-0804	High-Voltage Power Supply
661-0805	Fuser Assembly (110 / 115)
661-0806	Fuser Assembly (220 / 240)
661-0807	Board, DC Controller
661-0808	SIMM, DRAM, 4 MB, 80 ns, 72-pin
661-0809	SIMM, DRAM, 8 MB, 80 ns, 72-pin
661-0810	Board, Power Supply, 24-bit, 240 V
661-0811	SIMM, DRAM, 4 MB x 9, 80 ns, 30-pin, Parity
661-0812	Board, Logic, 25 MHz, Macintosh LC 520
661-0813	Board, Analog, LC 520 / 550 / 575 & Performa 550 (replaced by 661-0192)
661-0816	Keypad, Apple Adjustable, International, with Decimal Point (,)
661-0817	Keypad, Apple Adjustable, International, with Decimal Point (.)
661-0820	Board, I / O Controller
661-0821	Board, DC Controller

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0822	High-Voltage Power Supply
661-0825	Fuser Assembly, 110 / 115V
661-0826	Fuser Assembly, 220 / 240V
661-0827	Laser and Optic Assembly
661-0828	Scanner Motor
661-0830	Whole Unit, Apple Portable StyleWriter
661-0831	Automatic Sheet Feeder
661-0833	DC Controller, LaserWriter Pro 810
661-0836	Power Supply, 115 V
661-0837	Power Supply, 220 V
661-0842	I / O Controller, Roman, LaserWriter Pro 810
661-0846	Card, Memory, 4 MB
661-0847	Card, Memory, 8 MB
661-0849	High Resolution
661-0851	Board, Fax
661-0852	Card, Ethernet
661-0853	Card, Ethernet, 10 Base T
661-0854	Card, Ethernet, 10 Base 2
661-0857	Fuser, 110 V
661-0858	Fuser, 220 V
661-0860	High-Voltage Power Supply
661-0865	Laser / Scanner Unit
661-0866	Battery, Nicad
661-0867	Board, Logic, 68040, 33 MHz, LC 575
661-0868	Card, Fax
661-0869	Card, Ethernet NB, Twisted Pair
661-0870	Monitor, Apple Color Plus 14, U.S.
661-0872	Board, Analog
661-0876	Board, Controller
661-0877	Power Supply, 110 V
661-0878	Power Supply, 220 V
661-0880	Camera, QuickTake 100, Whole Unit, International Only
661-0881	Board, Main Deflection
661-0882	Board, CRT / Video

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0887	Card, Express Modem, 14.4 Baud, Comm Slot
661-0888	Card, Ethernet, 10 Base-T, Comm Slot
661-0889	Card, Ethernet, AAUI Port, Comm Slot
661-0890	Hard Drive, 250 MB, SCSI, 3.5" (replaced by 661-0182)
661-0892	Hard Drive, 2 GB, SCSI, 3.5"
661-0896	Hard Drive, 320 MB, SCSI, 2.5" (replaced by 661-1298)
661-0897	Board, Logic, 66 MHz
661-0898	Board, DC Controller
661-0899	Board, Mechanical Controller
661-0900	Fuser Assembly, 110 V
661-0901	Fuser Assembly, 220 V
661-0902	Laser / Scanner Assembly
661-0903	Power Supply, 110 V
661-0904	Power Supply, 220 V
661-0905	High-Voltage Power Supply
661-0906	Transfer Drum Assembly
661-0907	Cassette Pickup Assembly
661-0908	Sheet Feeder, Whole Unit
661-0909	Camera, QuickTake 150, Whole Unit
661-0910	Board, Main Deflection, with Chassis
661-0911	Board, I / O Controller Japan Only
661-0912	Hard Drive, 1.3 GB, IDE, 2.5" Japan Only
661-0913	CD-ROM Drive, 4x, SCSI, Apple CD 600e, Trayloading, Internal
661-0914	Board, CRT / Video
661-0915	Board, DOS Compatible, 68LC040
661-0916	Board, Logic, 22-Pin (replaced by 661-1783)
661-0917	Card, Processor, 601, 100 MHz
661-0918	DIMM, DRAM, 8 MB, 70 ns, 168-pin
661-0919	DIMM, DRAM, 16 MB, 70 ns, 168-pin
661-0920	Power Supply, 150 W
661-0921	Board, Logic, 22-Pin (replaced by 661-1784)
661-0923	Power Supply, 225 W, 3.3 V
661-0924	Board, Logic, 22-Pin, Rev. A
661-0925	Card, Processor, 604, 120 MHz

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0926	Card, Apple Accelerated Graphics
661-0927	DIMM, Cache, 512 KB, 11ns, 160-Pin
661-0928	Boards, Analog and Video, Rev. A
661-0930	Power Supply, Rev. A, without Thermistor Connector
661-0931	Board, Logic, 603, 75 MHz, Rev. A
661-0932	Power Supply, Sheet Feeder, Universal
661-0934	Trackpad, V1.4
661-0935	Keyboard (discontinued and replaced by 922-3109)
661-0936	Display, CTFT, 10.4", with Cable, CPRC / International Only
661-0937	Display, CFSTN, Color, 10.4", with Cable
661-0938	Display, MFSTN, Grayscale, 9.5", with Cable
661-0940	Board, Analog
661-0943	Hard Drive, 750 MB, SCSI, 2.5", CPRC / International Only
661-0944	Hard Drive, 1.1 GB, IDE, 2.5"
661-0945	CRT Assembly, Domestic
661-0946	CRT Assembly, Australia
661-0947	CRT Assembly, European
661-0950	SIMM, SRAM Cache, 1 MB, 15 ns
661-0951	Hard Drive, 4 GB, SCSI, 3.5"
661-0952	CRT, U.S., 15", Rev. A
661-0954	CRT Assembly, U.S., 15", Rev. B
661-0955	Hard Drive, 1 GB, IDE, 3.5"
661-0956	Hard Drive, 2 GB, Fast / Wide SCSI, 3.5", IBM
661-0957	Hard Drive, 750 MB, IDE, 2.5", 17 mm
661-0958	Hard Drive, 4 GB, Fast / Wide SCSI, 3.5", IBM
661-0959	CD-ROM Drive, 4x, SCSI, Apple CD 600e, Trayloading, External
661-0962	Monitor, Apple Multiple Scan 14, US, Whole Unit
661-0963	Keyboard
661-0964	Monitor, Apple Multiple Scan 14, Whole Unit, Europe
661-0965	Monitor, Apple Multiple Scan 14, Whole Unit, Japan
661-0966	Monitor, Apple Multiple Scan 14, Whole Unit, Far East
661-0967	Monitor, Apple Multiple Scan 14, Whole Unit, Australia
661-0974	Hard Drive, 500 MB, SCSI, 3.5'(replaced by 661-1102)
661-0975	Board, Logic, Ethernet

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-0977	Camera, Video Conferencing, Desktop, CCD, Color
661-0978	Card, Nubus, H.320, Apple Video Conferencing, Japan Only
661-0979	Board, Logic, Requires Auxiliary Fan
661-0980	Chassis, CD with Caddy
661-0981	Shield, All-In-One Enclosure
661-0982	Board, Daughter, Japan Only
661-0983	Display, CTFT, 10.4", CPRC / International Only
661-0985	Card, Ethernet, 100 BaseTX, PCI
661-0986	Card, Ethernet, 10Base2 / 10BaseT / AAUI, PCI
661-0987	Card, Token Ring, PCI
661-0989	Board, Logic, 603e, 100 MHz, 8 MB, 512K
661-0990	Board, Logic, 603e, 100 MHz, 16 MB, 512K
661-0991	Board, Logic, 603e, 100 MHz, 16 MB, 1MB, VGA
661-0992	Board, Logic, 603e, 117 MHz, 16 MB, 1 MB, SVGA
661-0993	Board, Logic, 80 MHz, WS 9150
661-0994	Floppy Drive, 1.4 MB, Graphite
661-0995	Card, MPEG Media System
661-0996	Board, Main Deflection, Rev. B
661-0998	Hard Drive, 4 GB, SCSI, 3.5", 50-pin
661-0999	Hard Drive, 800 MB, IDE, 3.5"
661-1000	Board, Logic
661-1002	Card, Processor, 604, 132 MHz
661-1007	Power Supply, Rev. B
661-1008	Board, Logic, 603, 75 MHz, 16-bit
661-1010	Printer, StyleWriter II, Whole Unit, 220 V
661-1016	Board, Daughter PB 165
661-1017	Card, '486 PC, DOS Compatible, Quadra 610
661-1020	Display, Flat Panel, PB 145B (replaced by 661-8745)
661-1021	SIMM, VRAM, 512K, 80 ns, 68-pin
661-1022	Board, Logic
661-1023	Card, Power Macintosh AV
661-1024	SIMM, Cache, 256K, Power Macintosh
661-1026	Board, Logic
661-1027	Card, Video, 4 MB, Power Macintosh

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-1028	Battery, NiMH
661-1029	Board, Logic, 040, 33 MHz, 8 MB
661-1031	Display, TFT, Color, SVGA, 10.4", with Cable
661-1032	Trackpad (replaced by 922-2694)
661-1033	Card, RAM, 16 MB
661-1034	Board, Mother, with Fuse
661-1035	DIMM, Cache, 256K, 11ns, 160-Pin
661-1036	DIMM, VRAM, 1 MB, 70 ns, 112-pin
661-1038	Board, Logic
661-1040	Monitor, Apple Basic Color,Whole Unit
661-1041	Board, Logic, 603e, 100 MHz
661-1044	Monitor, AppleVision 1710, South, Head Unit, Replaced by 661-2013
661-1046	Monitor, Apple Multiple Scan 20, Rev. B, Whole Unit, Canada
661-1048	Card, Modem, 14.4
661-1053	Power Supply, 82 W
661-1055	Board, Video
661-1056	Board, Power Supply
661-1058	Hard Drive, 500 MB, IDE, 2.5"
661-1059	Board, Logic
661-1060	PCMCIA Expansion Module, Rev. C
661-1067	Card, RAM, 12 MB
661-1070	Boards, Main Deflection and CRT / Video
661-1072	Board, Logic, 603e, 120 MHz, 8 MB
661-1073	Card, Video-In, Rev. B
661-1076	Hard Drive, 2 GB, SCSI, 3.5"
661-1078	Card, Internal Modem, 28.8, Global Village (replaced by 661-1301)
661-1080	Board, Logic
661-1083	Board, Logic
661-1084	Optical Assembly
661-1085	Board, Power Supply, 100-230, without Inverter Board
661-1087	Hard Drive, 4 GB, Ultra Wide SCSI, 3.5"
661-1088	Board, Logic
661-1089	Optical Assembly
661-1095	Board, I / O Controller

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-1096	Board, DC Controller (replaced by 661-1441)
661-1097	Laser / Scanner Assembly
661-1098	Fuser Assembly, 110 V
661-1099	Fuser Assembly, 220 V
661-1100	Power Supply Assembly, 110 V
661-1101	Power Supply, 220V
661-1102	Hard Drive, 800 MB, SCSI, 3.5"
661-1103	Card, RAM, 4 MB, 100 ns
661-1105	Battery, Rechargeable, MessagePad 110 / 120
661-1106	Hard Drive, 1.2 GB, IDE, 3.5"
661-1107	Hard Drive, 1.6 GB, IDE, 3.5"
661-1111	Board, Logic
661-1113	Card, Graphics Accelerator, QuickDraw 3D
661-1114	Board, Logic, 4 MB, 2-72 Pin SIMM slots, without FPU, DOS Compatible
661-1115	Board, Logic, 4 MB, FPU, DOS Compatible, Int'l
661-1116	Board, Logic, 603e, 100 MHz
661-1117	Power Supply, Rev. B (For 5200 or 5300 Series use only with 661-1118 and / or
661-1118	Boards, Analog and Video, Rev. B (Use only with 661-1117 and / or 922-2043)
661-1119	Automatic Document Feeder, Whole Unit
661-1120	Transparency Adapter, Whole Unit
661-1123	Card, PCI, PC Compatibility, 100 MHz, 7"
661-1124	Card, PCI, PC Compatibility, 100 MHz, 12"
661-1125	Board, Logic, Network Server 500 / 700
661-1126	Card, Processor, 604, 150 MHz, Network Server
661-1127	DIMM, Cache, 1 MB, 11 ns, 160-pin
661-1128	DIMM, DRAM, 8 MB, 60 ns, 168-pin, Parity
661-1129	DIMM, DRAM, 16 MB, 60 ns, 168-pin, Parity
661-1130	DIMM, DRAM, 32 MB, 60 ns, 168-pin, Parity
661-1131	Power Supply, 425 W
661-1132	Flyback Transformer Assembly
661-1133	Board, Power Supply, 14", All-In-One
661-1134	Boards, Analog / Video, 14", All-In-One
661-1135	CRT, N. Hemisphere, Anti-Static, Anti-Glare, 14", All-In-One
661-1136	CRT, S. Hemisphere, Anti-Static, Anti-Glare, 14", All In One (International Only)

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-1137	CRT, EQ Pol, Anti-Static, Anti-Glare, 14", All In One (International Only)
661-1138	Power Supply, Black Switch
661-1139	Hard Drive, 1.2 GB, IDE, 3.5"
661-1142	Hard Drive, 1.2 GB, SCSI, 3.5"
661-1143	Board, Main Deflection
661-1144	Card, Processor, 604, 132 MHz, Network Server
661-1145	Power Supply, 325 W
661-1146	Card, Processor, 604, 150 MHz
661-1147	Card, TV / FM Tuner
661-1148	Keyboard, AppleDesign, Graphite (discontinued and replaced by 922-2327)
661-1149	Keyboard, AppleDesign, Graphite (discontinued and replaced by 922-2327)
661-1150	CD-ROM Drive, 600i, Graphite
661-1151	Mouse, Apple Desktop Bus, Graphite, International Only (discontinued and replaced by
661-1152	Chassis, Manual Insert, CD300i+, Tray Loading, Use w / 922-1284
661-1153	Board, Logic, 22-Pin, PM 8500, Rev B.
661-1154	Board, Logic, 22-Pin
661-1156	Board, Logic, 22-Pin, PM 9500, Rev. B
661-1157	Card, Processor, 604, 132 MHz
661-1158	Card, RAID, with Battery, Network Server
661-1165	Card, Video Editing, MJPEG
661-1167	CD-ROM Drive, 4x, SCSI, Apple CD 600i, Rev. B
661-1169	Power Supply, 150 W
661-1170	Card, Ethernet, AAUI
661-1171	Card, Ethernet, Twisted Pair
661-1172	Card, Ethernet, Thin Coax
661-1174	Card, L2 Cache, 256K
661-1175	Board, Logic, 120 MHz
661-1178	Hard Drive, 2 GB, Fast / Wide SCSI, 3.5", Seagate
661-1179	Hard Drive, 4 GB, Fast / Wide SCSI, 3.5", Seagate
661-1180	Board, Logic, Requires Auxiliary Fan (replaced by 661-1080)
661-1181	Card, Video-In, Rev. D, 60-Pin Dual In-Line Connector
661-1182	Boards, Analog and Video (Return with Analog-to-Video Cable) (replaced by 661-1356)
661-1183	Battery, Backup, RAID Card
661-1184	SIMM, DRAM, 4 MB, RAID Card

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-1186	Monitor, Apple Multiple Scan 14, Whole Unit, with MS to 640x480 Adapter
661-1187	Monitor, MultiScan 14 with Adapter, Whole Unit
661-1188	Board, Logic, 8 MB
661-1189	Display, DLSCN, SVGA, 11.3", CPRC / International Only
661-1190	Board, PC / IR
661-1191	Board, Daughter, 603e, 117 MHz
661-1192	Card, Video
661-1193	Display Assembly
661-1194	Case, Top (includes Logic Board)
661-1195	Card, ROM
661-1196	Card, RAM, 8 MB, Customer Slot (replaced by 661-1350)
661-1199	Board, Logic, 603ev, 180 MHz, 8 MB (replaced by 661-1452)
661-1201	Board, Logic, 603e, 8 MB, 160 MHz
661-1202	Hard Drive, 2.4 GB, IDE, 3.5"
661-1213	Board, Main Deflection, with Chassis
661-1215	Card, Processor, 604e, 200 MHz, Network Server
661-1219	Board, Logic, Rev. B, 24-Pin
661-1220	Board, Logic, 24-Pin
661-1221	Board, Logic, 24-Pin
661-1222	Card, Processor, 604e, 180 MHz
661-1223	Card, Processor, 604e, 200 MHz
661-1231	Display, CTFT, SVGA, 11.3", CPRC / International Only
661-1235	Board, Logic, 603ev, 180 MHz, 16 MB
661-1236	Display, CTFT, SVGA, CPRC / International Only
661-1237	Board, Power Supply
661-1238	Board, Logic, 603ev, 200 MHz, 16 MB
661-1239	DIMM, L2 Cache, 256K, 160-Pin
661-1240	CD-ROM Drive, 8x, SCSI, AppleCD 1200i
661-1241	Hard Drive, 2 GB, IDE, 2.5", 17mm
661-1242	Power Supply, 390 W
661-1244	Power Supply, 150 W
661-1245	Hard Drive, 1 GB, IDE, 2.5"
661-1246	Tape Drive, 8mm, 20 / 40 GB, Network Server
661-1247	Hard Drive, 9 GB, Fast / Wide SCSI, 3.5"

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-1248	Power Supply, 200 W
661-1250	Card, Processor, 604, 150 MHz
661-1253	Hard Drive, 750 MB, IDE, 2.5", 12.5 mm
661-1254	Hard Drive, 3 GB, IDE, 3.5"
661-1255	Hard Drive, 2 GB, IDE, 3.5"
661-1259	Card, Processor, 604, 132 MHz (replaced by 661-1157)
661-1265	Board, Logic, 603e, 120 MHz
661-1266	Board, Logic, 24-Pin
661-1267	Card, Processor, 604e, 166 MHz
661-1269	Card, MultiProcessor, 604e, 200 MHz
661-1271	Board, Logic, 603ev, 200 MHz (replaced by 661-1453)
661-1272	Card, Processor, 604, 120 MHz, PM 7500 / 7600 Only
661-1275	Card, PCBA, Video-in
661-1278	DIMM, ROM / SRAM, 4M / 256K Cache, 160-Pin
661-1280	Card, MultiProcessor, 604e, 180 MHz
661-1281	Board, Logic, 603ev, 160 MHz, 8 MB, Low Profile HeatSink (replaced by 661-1454)
661-1282	Board, Logic, 603ev, 180 MHz, 8 MB, Low Profile Heat Sink
661-1283	Card, Ethernet / Modem
661-1284	Card, Ethernet
661-1285	Card, TV Tuner, without Cover
661-1286	CD-ROM Drive, 6x, SCSI (replaced by 661-1358)
661-1287	Card, Modem, 28.8 / 33.6, Geoport for US, Canada, Japan, Asia
661-1289	CD-ROM Drive, 8X, SCSI, Graphite
661-1290	CD-ROM Drive, 6x, SCSI
661-1291	Board, Logic, 603e, 16 MB, 160 MHz
661-1292	Card, RAM, 4 MB, Factory Slot
661-1293	Card, RAM, 8 MB, OEM, Factory Slot
661-1298	Hard Drive, 1 GB, SCSI, 2.5"
661-1299	Card, Modem, 28.8, V34, Comm Slot (Japan Only)
661-1301	Card, Modem, 28.8, Global Village
661-1302	Board, Logic, Power Mac / Server G3, 3-Slot
661-1305	Card, Processor, 604e, 180 MHz
661-1306	Connector, GeoPort Telecom
661-1307	Card, Processor, 604e, 200 MHz

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-1308	Board, Daughter, 603e, 133 MHz
661-1310	DIMM, Cache, 256K, 11ns, 160-Pin
661-1311	Head Unit, Northern Hemisphere, International Only
661-1312	Board, CRT / Video
661-1314	DIMM, DRAM, 8 MB, 70 ns, 168-pin, EDO
661-1315	DIMM, DRAM, 16 MB, 168-pin, EDO
661-1316	DIMM, DRAM, 32 MB, 168-pin, EDO
661-1317	CD-ROM Drive, 8x, ATAPI
661-1320	Board, Logic, 603ev, 275 MHz (Replaced by 661-1507)
661-1322	Board, Logic, 603ev, 225 MHz (Replaced by 661-1505)
661-1324	Board, Logic, 603ev, 180 MHz, EDO
661-1325	Board, Logic, 603ev, 200 MHz, EDO (replaced by 661-1453)
661-1326	Board, Logic, 603ev, 120 MHz, EDO (replaced by 661-1072)
661-1327	Board, Logic, 603ev, 160 MHz, EDO
661-1329	Base Unit
661-1330	Board, Logic, 603ev, 200 MHz, EDO, Low Profile HeatSink
661-1331	Zip Drive, 100 MB, SCSI
661-1332	Board, Logic, 603ev, 250 MHz (Replaced by 661-1506)
661-1333	Hard Drive, 1.3 GB, IDE, 2.5"
661-1334	Board, Logic
661-1335	Mechanical Assembly
661-1336	Board, Logic, 603ev, 240 MHz, 16 MB
661-1337	Display, 10.4" Japan Only
661-1338	Board, Logic, 16 MB, 180 MHz, Japan Only
661-1339	Card, CPU, 603e, 180 MHz, Japan Only
661-1341	Board, I / O & Power Supply, Japan Only
661-1342	Hard Drive, 4 GB, IDE, 3.5"
661-1343	Hard Drive, 3 GB, IDE, 2.5", 17mm (Replaced by 661-1493)
661-1344	Card, RAM, 16 MB, 120-pin
661-1345	DIMM, Cache, 256K, 11 ns, 160-pin
661-1346	DIMM, Cache, 256K, 9 ns, 160-Pin
661-1347	Card, PCI, PC Compatibility, 166 MHz, Pentium, 12"
661-1348	Card, PC Serial / Parallel, PCI
661-1349	Card, Processor, 604e, 233 MHz

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-1350	Card, RAM, 8 MB, Customer Slot
661-1353	Card, PCI, PC Compatibility, PR166, 6x86, 12"
661-1354	Board, Logic
661-1355	Mechanical Assembly
661-1356	Board Set, Analog / Video, Rev. D
661-1357	CD-ROM Drive, 12x, SCSI, with Enclosure
661-1358	CD-ROM Drive, 8x, SCSI, with Enclosure
661-1359	Floppy Drive, 1.44 MB, Graphite, with Enclosure
661-1360	Floppy Drive, 1.4 MB, Graphite, with Enclosure
661-1361	Hard Drive, 2 GB, IDE, 2.5", 12.5 mm
661-1366	Card, PCBA, Comm Bridge
661-1367	Card, PCBA, PCI Bridge
661-1368	Card, PCBA, Video-in Bridge
661-1371	Card, PCI, Ultra SCSI, JackHammer / SE
661-1372	Head Unit, AppleVision 750 Display, North, International Only
661-1373	Board, CRT / Video
661-1374	Board, Main Deflection, with Chassis
661-1377	Head Unit, AppleVision 750 Display, Southern Hemisphere, International Only
661-1380	Board, Daughter, 603e, 166 MHz
661-1381	Board, Logic, 8MB
661-1390	Floppy Drive, Apple SuperDrive, 1.4 MB, Manual Insert, 5 V Only
661-1400	CD-ROM Drive, 24x, SCSI
661-1401	CD-ROM Drive, 24X, ATAPI
661-1404	Modem, 33.6 External Geoport, Color
661-1405	Camera, QuickTake 200, Whole Unit
661-1406	DIMM, DRAM, 16 MB, 168-pin, EDO, 3.3V
661-1407	DIMM, VRAM, 60 ns, 120-pin, EDO
661-1408	Board, Logic, 603ev, 200 MHz
661-1409	Card, Video, IMS, 4 MB
661-1412	Head Unit, Southern Hemisphere, International Only
661-1413	CD-ROM Drive, 12x, ATAPI, Apple CD 1800i
661-1415	CD-ROM Drive, 12x, SCSI, Apple CD 1800i
661-1418	Fuser Assembly, 110 V
661-1420	Board, I / O Controller

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-1423	Fuser Assembly, 220 V
661-1426	CD-ROM Drive, 8x, SCSI (replaced by 661-1358)
661-1428	CD-ROM Drive, 12x, SCSI, with Enclosure
661-1430	Mechanical Assembly
661-1431	Board, Logic
661-1432	Board, Logic, 603ev, 300 MHz (Replaced by 661-1508)
661-1433	DIMM, DRAM, 32MB, 60ns, 168-pin, EDO, 3.3V
661-1435	DIMM, VRAM, 2 MB, 60 ns, 120-Pin, EDO
661-1438	Card, Video, IMS, 8 MB
661-1439	Card, Processor, 604e, 250 MHz
661-1441	Board, DC Controller
661-1442	Card, Processor, 604e, 300 MHz
661-1443	Card, Processor, 604e, 350 MHz
661-1445	Power Supply, 150 W
661-1446	DIMM, SDRAM, 32 MB, 168-Pin
661-1450	Hard Drive, 4 GB, SCSI, 3.5", 50-pin
661-1451	Hard Drive, 6 GB, IDE, 3.5"
661-1452	Board, Logic, 603ev, 180 MHz, EDO
661-1453	Board, Logic, 603ev, 200 MHz, EDO
661-1454	Board, Logic, 603ev, 160 MHz, EDO
661-1456	Card, I / O, Audio and Video
661-1457	Card, I / O, Audio Only
661-1460	Module, Processor, 233 MHz
661-1461	Module, Processor, 266 MHz
661-1462	Card, Processor, 604e, 200 MHz
661-1466	Boards, Main Deflection and CRT / Video
661-1472	Board, Logic, G3, 250 MHz, 32 MB
661-1473	Board, Power Supply
661-1475	Card, Ethernet / Modem
661-1476	CD-ROM Drive, 20X, with Enclosure
661-1477	DIMM, Cache, 256K, 160-pin
661-1480	Card, Ethernet, 10 / 100 BaseT
661-1481	Card, Video, Xclaim 3D, 4 MB
661-1482	Hard Drive, 5 GB, IDE, 2.5"

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-1493	Hard Drive, 4 GB, 2.5", IDE, 12.5 mm
661-1494	Card, Processor, 604e, 233 MHz, 85° C
661-1496	Power Supply, 200 W
661-1497	DIMM, Cache, 256K, 9 ns, 160-Pin
661-1500	Monitor, ColorSync 20 Display, North, Whole Unit, Europe Only
661-1503	Card, Video, 3D, IX Micro, 8 MB (replaced by 661-2072)
661-1504	Modem, 56K, Americas, GV
661-1505	Board, Logic (603ev, 225 MHz) with Cache (DIMM, L2 Cache, 256K, 160-Pin)
661-1506	Board, Logic (603ev, 250 MHz) with Cache (DIMM, L2 Cache, 256K, 160-Pin)
661-1507	Board, Logic (603ev, 275 MHz) with Cache (DIMM, L2 Cache, 512k, 160-Pin)
661-1508	Board, Logic (603ev, 300 MHz) with Cache (DIMM, L2 Cache, 512k, 160-Pin)
661-1510	Modem, Apple / GV, 56.6K
661-1513	DVD-ROM Drive, 2x, ATAPI
661-1514	DVD-ROM, 1.5X, 17 mm
661-1515	Trackball Assembly
661-1516	CD-ROM Drive, 20X, 17 mm with Door
661-1518	Hard Drive, 2 GB, SCSI, 3.5"
661-1605	Board, I / O, Rev. 3.0, NTX
661-1606	Board, Power Supply, 220 / 240V, ImageWriter II / L
661-1610	Board, Logic, Pseudostatic RAM
661-1611	Keypad, Numeric, Lightweight
661-1612	Keyboard, Lightweight
661-1613	Card, PSRAM, 3 MB
661-1614	Card, PSRAM, 1 MB
661-1615	Board, Logic
661-1616	Power Supply
661-1617	Card, Token Ring 4 / 16 NB
661-1618	Board, CRT Video, Rev. B, International
661-1619	Card, Cache, Macintosh Ilci
661-1621	Modem, Internal Fax / Data, 2400 Baud, U.S.
661-1623	Floppy Drive, 1.44 MB, 19 mm-high (replaced by 661-1651)
661-1625	Card, Disk Controller, 3.5, Apple II
661-1634	Board, Main Deflection (replaced by 661-1671)
661-1635	Board, CRT Video

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-1636	Hard Drive, 400 MB, SCSI, 3.5" (replaced by 661-0219)
661-1642	Card, Macintosh Display, 8 / 24 GC, Rev. B
661-1644	Hard Drive, 40 MB, SCSI, 2.5" (replaced by 661-1298)
661-1646	CD-ROM Drive, 2x, SCSI, Apple CD 300, Caddy Loading, External
661-1648	Power Supply, Apple CD 150
661-1650	Board, Main Deflection, without E. Star Compliance
661-1651	Floppy Drive, 1.44 MB, 19 mm-high
661-1652	Keyboard, U.S.
661-1653	Board, Logic, 25 MHz, Duo 210
661-1654	Trackball Assembly
661-1655	Display, FSTN, Duo 210
661-1656	Battery with Door, Type 1 (replaced by 661-0053)
661-1657	Board, Logic
661-1658	Card, RAM, 8 MB
661-1659	Card, RAM, 4 MB
661-1660	Power Supply
661-1662	Modem, Express, 14.4 Baud, International
661-1663	Floppy Adapter
661-1664	Board, Logic
661-1665	Modem, Express, 14.4 Baud, U.S.
661-1666	CRT Assembly, Domestic
661-1667	CRT Assembly, Australia
661-1668	CRT Assembly, European
661-1669	Monitor, Display Plus, 14 Color, .29 Dot, Whole Unit
661-1670	Monitor, Apple Basic Color, Non-VGA, Whole Unit (replaced by 661-1186)
661-1671	Board, Main Deflection, Rev. B
661-1672	Board, Logic, 33 MHz, Duo 230 / 250
661-1673	Display, FSTN, Duo 230
661-1674	Card, SCSI
661-1675	Board, Logic, 25 MHz, 4 MB
661-1676	Board, Logic, 33 MHz, 8 MB, E-net, FPU, Quadra 800 / AWS 80
661-1677	Board, Logic, 4 MB, FPU, Ethernet
661-1678	Board, Logic, 25 MHz, 8 MB, E-Net, FPU
661-1679	Board, Logic, 4 MB, FPU

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-1681	Board, Logic, 20 MHz, 4 MB, Centris 610
661-1682	Board, Logic, 20 MHz, E-Net, 4 MB Centris 610 / AWS 60
661-1685	Bubble Jet Head Unit
661-1686	Display, Active Matrix, Duo 250, CPRC / International Only
661-1687	Power Supply, 200 W
661-1688	Power Supply, 86 W
661-1689	Speaker, Main, AppleDesign Powered Speakers (replaced by 661-1737)
661-1692	Modem, Data / Fax, 2400 Baud, External
661-1693	Battery Pack, NicadMessagePad & MessagePad 100
661-1697	PowerCD, NTSC, Blue
661-1699	Board, Main Deflection
661-1700	Board, Logic, 40 MHz, Quadra 840AV
661-1701	SIMM, DRAM, 4 MB, 60 ns, 72-pin
661-1702	SIMM, DRAM, 8 MB, 60 ns, 72-pin
661-1703	GeoPort Telecom Adapter, US / Canada / Hong Kong
661-1704	Board, Logic, 25 MHz, 4 MB, Centris / Quadra 660AV
661-1705	CD-ROM Drive, 1x, SCSI, Apple CD 150, Caddy Loading, External
661-1706	Power Supply, Apple CD 300
661-1707	Board, Logic, EtherNet
661-1708	Logic Board
661-1709	Purge Unit
661-1710	Carriage Ink Supply
661-1711	Ink Compartment Unit
661-1712	Carriage Board, Color IJ
661-1713	Power Supply, 120V
661-1714	Power Supply, 220V
661-1715	Board, Daughter, PB 145B
661-1716	Speaker, Satellite, AppleDesign Powered Speakers
661-1717	Board, Logic, Duo 270c
661-1718	NuBus Adaptor, Centris 610 / AWS 60
661-1719	Adapter, NuBus, Macintosh Centris 660AV
661-1722	Keyboard II, Black (discontinued and replaced by 922-2327)
661-1723	Mouse, Ergonomic, Black (discontinued and replaced by 922-2328)
661-1724	Board, Logic, 33 MHz

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-1726	Power CD, NTSC, Gray
661-1727	Power CD, PAL, Gray
661-1728	Power CD, PAL, Blue
661-1729	Base, Power CD, Battery Pack / SCSI, Blue
661-1730	Base, Power CD, Battery Pack / SCSI, Gray
661-1731	Tuner PCBA, Assembly
661-1732	Board, Logic, Performa 475
661-1733	Power Supply, 36 W
661-1734	Display, Active Matrix, Color, Duo 270c / 280c
661-1735	Battery with Door, Type 2 (replaced by 661-0053)
661-1736	Board, Logic, 33 MHz, Performa 460 / 466 / 467
661-1737	Speaker, Main, with Sub Woofer Jack, AppleDesign Powered Speakers
661-1741	Card, Pro Audio Spectrum 16 / SCSI
661-1745	Card, Modem, PCMCIA
661-1748	Card, Video, 2 MB, Power Mac
661-1750	Hard Drive, 500 MB, SCSI, 3.5", In-Warranty Exchange ONLY
661-1751	Hard Drive, 500 MB, IDE, 2.5", In-Warranty Exchange ONLY
661-1753	Hard Drive, 320 MB, SCSI, 2.5", In-Warranty Exchange ONLY (replaced by 661-1298)
661-1783	Board, Logic, 22-Pin
661-1784	Board, Logic, 22-Pin, PM 8500 / 120
661-1830	Board, Logic, 33 MHz, Color Classic II, LC 520 / 550, Performa 550
661-2000	Board, I / O Controller, LWS 300
661-2001	Board, I / O Controller, LWS 310
661-2002	Board, DC Controller
661-2003	Laser and Optic Assembly
661-2004	Scanner Motor
661-2005	High-Voltage Power Supply
661-2006	Power Supply, 110 / 115 V
661-2007	Power Supply, 220 / 240 V
661-2008	Fuser Assembly, 110 / 115V
661-2009	Fuser Assembly, 220 / 240V
661-2011	Card, Ultra Wide SCSI PCI (replaced by 661-2095)
661-2012	DIMM, SDRAM, 64 MB, 168-pin, Low Profile
661-2013	Monitor, ColorSync 17, South, Whole Unit

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-2015	DIMM, L2 Cache, 512K, 160-Pin
661-2017	Display, XGA, 13.3", CPRC / International Only
661-2019	Board, I / O Logic, TV-out, 4 MB VRAM
661-2021	Board, Microprocessor, 292 MHz, 1 MB Cache
661-2023	SGRAM, SO-DIMM, 4 MB,12ns, 144-pin
661-2024	Zip Drive, ATAPI
661-2025	DIMM, SDRAM, 128 MB, 168-Pin, 1.25" High
661-2027	SDRAM, 64 MB, 100 MHz
661-2028	SDRAM, 32 MB, 100 MHz
661-2030	Display, XGA, 14.1", CPRC / International Only
661-2031	Board, PMU
661-2035	Board, Microprocessor, 233 MHz, No Cache
661-2036	Board, Microprocessor, 250 MHz, 1 MB Cache
661-2038	CD-ROM Drive, 24X, ATAPI
661-2039	Card, Power Supply
661-2041	Board, Analog / Video
661-2042	Board, Power Supply
661-2043	Card, I / O, Audio Only, Version 2
661-2044	Card, I / O, Audio and Video, Version 2
661-2045	Tape Drive, DAT, DDS-2, 120 M
661-2047	Hard Drive, 9 GB, Ultra Wide SCSI, 3.5", IBM
661-2048	Floppy Drive, with Enclosure
661-2050	Hard Drive, 4 GB, Ultra Wide SCSI, 3.5", IBM
661-2053	Display, STN, 12.1", CPRC / International Only
661-2054	Hard Drive, 8 GB, IDE, 3.5"
661-2055	Hard Drive, 12 GB, IDE, 3.5"
661-2056	Hard Drive, 2 GB, 2.5", IDE, 12.5 mm
661-2057	Hard Drive, 8 GB, 2.5", IDE, 17 mm
661-2058	Board, I / O Logic, No TV-out, 2 MB VRAM
661-2059	Processor, 300 MHz
661-2061	Board, Logic, iMac
661-2063	Board, Logic, Power Mac / Server G3, 3-Slot, Version 2 (replaced by 661-2093)
661-2064	Card, FireWire, DVC
661-2065	SDRAM, 128 MB, 100 MHz

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-2066	Tape Drive, DDS-3, 125 M
661-2067	DIMM, SDRAM, 128 MB, 168-Pin, Low Profile, 1.15" High
661-2068	Card, Sound
661-2069	Battery, Lithium Ion, Rechargeable
661-2071	Card, Audio / Video, DVD
661-2072	Card, Video, 3D, IX Micro, 8 MB, Rev. B
661-2076	CD-ROM Drive, 24X
661-2077	Card, Processor, 233 MHz (replaced by 661-2193)
661-2078	Module, Processor, 333 MHz
661-2079	SDRAM, SO-DIMM, 32 MB, 100 MHz
661-2080	Board, Analog / Video
661-2081	Board, Power Supply
661-2082	Card, DVD-Video PC
661-2085	Modem, 56K, Internal, US / Japan / Canada / Taiwan / Hong Kong / Singapore
661-2087	Board, I / O Logic, TV-out, 4 MB SGRAM
661-2088	Board, Microprocessor, 300 MHz, 1 MB Cache
661-2089	Board, Microprocessor, 233 MHz, 512K Cache
661-2091	Display, TFT, 12.1", CPRC / International Only
661-2093	Board, Logic, Power Mac / Server G3, 3-Slot, No Voltage Regulator, Version 3
661-2094	Board, I / O Logic, TV-out, 2 MB VRAM (replaced by 661-2087)
661-2095	Card, Ultra Wide SCSI PCI, Rev. B
661-2097	Board, Microprocessor, 266 MHz, 1 MB Cache
661-2098	Modem, 56K, North America / Asia
661-2099	Modem, 56K, Euro / Aust, CPRC / International Only
661-2100	Board, Main Deflection and CRT / Video
661-2101	Hard Drive, 12 GB, IDE, 3.5" (replaced by 661-2140)
661-2102	Modem, 56K, Internal, Australia / New Zealand
661-2103	Processor Module, 400 MHz
661-2104	Board, Logic, PowerMac G3 / Server G3 (Blue and White)
661-2105	Processor Module, 300 MHz
661-2106	Processor Module, 350 MHz
661-2107	Power Supply
661-2109	Card, Video, MPEG 2, DVD, Decoder Module
661-2110	Card, I / O, Audio Only, Version 3

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number **Part Name**

661-2111	Card, I / O, Audio and Video, Version 3
661-2112	Card, Processor, 233MHz, Rev. 2 (replaced by 661-2193)
661-2113	Board, Logic, iMac, Version 2
661-2115	Board, Main Deflection
661-2116	Board, CRT / Video
661-2117	Board, Power
661-2133	Hard Drive, 4 GB, IDE, 3.5"
661-2134	Hard Drive, 4 GB, IDE, 3.5"
661-2135	Hard Drive, 4 GB, IDE, 3.5"
661-2136	Hard Drive, 6 GB, IDE, 3.5"
661-2137	Hard Drive, 6 GB, IDE, 3.5"
661-2138	Hard Drive, 8 GB, IDE, 3.5"
661-2139	Hard Drive, 8 GB, IDE, 3.5"
661-2140	Hard Drive, 12 GB, IDE, 3.5"
661-2141	Hard Drive, 9 GB, Ultra2 LVD SCSI, 10K rpm, 3.5"
661-2142	Hard Drive, 9 GB, Ultra2 LVD SCSI, 7200 rpm, 3.5"
661-2143	Hard Drive, 9 GB, Ultra2 LVD SCSI, 7200 rpm, 3.5"
661-2145	DIMM, SDRAM, 64 MB, 168-pin
661-2146	DIMM, SDRAM, 128 MB, 168-pin
661-2147	DIMM, SDRAM, 256 MB, 168-Pin
661-2148	Card, Ultra2 LVD SCSI, Single Channel, PCI
661-2150	Card, Video, 16 MB, Rage 128
661-2161	Drive, Zip, ATAPI
661-2162	Drive, DVD-RAM (ATAPI)
661-2163	Drive, DVD-ROM, ATAPI
661-2164	Drive, CD-ROM, 24x, ATAPI
661-2165	Card, Processor, 266 MHz
661-2165	Card, Processor, 266 MHz
661-2166	Board, Analog / Video, Rev. 2
661-2167	Board, Power Supply, Rev. 2
661-2169	Hard Drive, 6 GB, IDE, 3.5"
661-2170	Card, Ethernet, Four Port, 10 / 100, PCI
661-2171	Card, Ultra2 LVD SCSI, Dual Channel, PCI
661-2172	Card, Ethernet, Gigabit, PCI

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-2173	Card, Ultra SCSI, PCI
661-2185	Hard Drive, 36 GB, Ultra2 LVD SCSI, 7200 rpm, 3.5", 1.6" Height
661-2191	Drive, CD-ROM, 32x, ATAPI
661-2193	Card, Processor, 233 MHz, Rev. 3
661-2195	SDRAM, SO-DIMM, 64 MB, 100 MHz
661-2199	Card, Xclaim VR, 4 MB
661-71182	Power Supply, Internal, Apple IIc
661-72083	Card, TGS Interface
661-72128	Mechanical Assembly
661-74024	Keyboard Mech Datanetics, Apple II (replaced by 661-91073)
661-74025	Kybd Array Non-Sculp, Apple II (replaced by 661-91073)
661-75134	Main Electronics Assembly
661-75222	Monitor IIc
661-76153	Power Supply (replaced by 661-0461)
661-76156	Floppy Drive, 400K Mechanism, 3.5"
661-76214	Board, Power Sweep, 220 V
661-8013	Modem, Express, 14.4 Baud, CPRC / International Only
661-8014	Hard Drive, 80 MB, SCSI, 2.5", with Brackets (replaced by 661-1298)
661-8745	Display Replacement Kit, FSTN
661-91006	Card, IEEE, Apple II
661-91008	Card, Communication, Apple II (replaced by 661-91067)
661-91020	Keyboard Datanetic, Apple II (replaced by 661-91073)
661-91021	Keyboard Array RFI Sculp, Apple II (replaced by 661-91073)
661-91023	Keyboard Elec Encoder, Apple II
661-91026	Card, Language, Apple II
661-91039	Power Supply, Astec, Non-RFI, Apple II (replaced by 661-0455)
661-91040	Power Supply, RFI, Apple II (replaced by 661-0455)
661-91042	Power Supply, Old, Apple II (replaced by 661-91040)
661-91043	Power Supply, UL, Apple II (replaced by 661-91040)
661-91047	Card, Parallel Printer, Apple II (replaced by 661-91080)
661-91064	Card, ROM, Apple II (replaced by 661-91026)
661-91065	Card, Serial, Apple II (replaced by 661-91067)
661-91067	Card, Super Serial, Apple II
661-91073	Keyboard Alp SW RFI Sculp, Apple II

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

661-91075	Keyboard Alp Switchable Non-Sculp, Apple II (replaced by 661-91073)
661-91080	Card, Parallel Interface, Apple II
661-91084	Board, Logic, Apple IIe
661-91085	Keyboard, Apple IIe
661-91095	Card, SchoolBus Interface
661-91096	Card, 80 Column, Apple IIe (replaced by 661-91097)
661-91097	Card, 80 Column / 64K, Apple IIe
661-91150	Card, Apple Communications Protocol
661-91151	Power Supply, Apple II / IIe (replaced by 661-0455)
661-91177	Board, Logic, Apple IIc
661-91181	Keyboard, Apple IIc (replaced by 661-0294)
661-91185	Card, AppleMouse II Interface
661-91204	Motherboard with RAM, Apple II (replaced by 661-91207)
661-91205	Motherboard, RFI with RAM, Apple II (replaced by 661-91207)
661-91206	Motherboard with RAM, Apple II+ (replaced by 661-91207)
661-91207	Motherboard, RFI, with RAM, Apple II+
661-92001	Card, Disk II Analog
661-92002	Card, Analog
661-92011	Card, Disk Controller, Apple II
661-92012	Mechanism Assembly, Disk II
661-92015	Mechanism Assembly, Disk III, External
661-92130	Card, DuoDisk Analog
661-92131	Card, Controller, Uni / DuoDisk
661-93191	Card, Profile Interface, Apple II
661-94119	Board, Logic, Rev. A, Apple IIe (replaced by 661-91084)
661-95132	Hand Controllers, Apple IIe-IIc
661-95133	Joystick, Apple IIe-IIc, Platinum
661-95139	Keyboard, SMK Short Stem (replaced by 661-91085)
661-95232	Keyboard, Alps Short Stem (replaced by 661-91085)
661-95233	Keyboard, SMK Long Stem (replaced by 661-91085)
661-96152	Board, Logic, 128K (replaced by 661-96236)
661-96154	Keyboard, Beige (replaced by 661-0416)
661-96155	Mouse, Beige (replaced by 661-0259)
661-96236	Board, Logic, Macintosh 512K / Ke

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

670-4102	Modem, Internal, Fax / Data, 2400, International
675-5101	Cover, Subassembly Bottom
675-5103	Case Assembly, Top
676-5101	Subassembly, Bottom Cover
676-5103	Cover Assembly, Top
678-5059	Caddy, CD
699-0097	Gimbal Assembly, Joystick
699-0130	Power Supply
699-0142	Luggage Tag, Original, Pkg. of 2
699-0155	Luggage Tag, Lightweight
699-0211	PCB, Line Filter
699-0220	RF Modulator
699-0228	Cable, RF Modulator
699-0242	RF Modulator Switch Box
699-0271	Inverter, FSTN, Blue, PB 140 / 145
699-0272	Inverter, FSTN, Red, PB 140 / 145 (use with 661-0681 only)
699-0273	Inverter, Active Matrix, Green, PB 170
699-0305	Cassette, B5, Platinum
699-0322	Manual Feed Assembly
699-0323	Registration Shutter Assembly
699-0324	Power Interlock Assembly, 110 V
699-0326	Cassette, A4, Platinum
699-0347	Cassette, Legal, Platinum
699-0357	Cassette, Letter, Platinum
699-0424	Power Pack, AC, 110 V
699-0450	Fan (replaced by 699-0469)
699-0469	Fan
699-0479	Board, Cable Interface, HDI-20 to Flex
699-0497	Clutch, Left
699-0498	Clutch, Right
699-0505	Power Adapter / Charger
699-0508	Strap, Carrying Case
699-0514	Shaft Carrier
699-0515	Invertor PCA, Lightweight

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

699-0517	Power Adapter (replaced by 922-0376)
699-2050	Power Adapter, 120 V, 58-62 Hz, USA
699-5017	Fan, 160 SC
699-5070	Clutch
699-5071	Microphone Assembly (replaced by 076-0430)
699-5073	Microphone Assembly, Quadra 900 & WS 9150
699-5098	Microphone, with Cable and Clip, Granite
699-5103	Microphone (replaced by 076-0430)
699-5877	Card, ISDN, Power Supply
699-8001	Ball, Mouse (replaced by 922-0998)
699-8030	Cassette, Letter
699-8031	Cassette, A4
699-8032	Cassette, Legal
699-8033	Cassette, B5
699-8034	Cassette, Envelope
699-8038	Ball, Mouse, 21.9 mm Diameter, Black (replaced by 922-1692)
705-0015	Alps Short Stem Keyswitch
705-0023	Switch, Power Supply, Rocker, Two-Pole
705-0040	Key Switch, Low Profile (For P / N 661-0294)
705-0041	On-Off Switch
705-0044	Keyswitch, Locking, Mitsumi
705-0045	Switch, SCSI Select Assembly (replaced by 922-1250)
705-0065	Switch, Power Supply, Rocker, Three-Pole
705-0070	Keyswitch, Alps Long Stem
705-0072	Hand Controller, Pushbutton Switch
705-0075	Keyswitch, SMK, Short Stem
705-0077	Keyswitch, Alps Alpha Lock
705-0079	SMK Short Stem Keyswitch
705-0080	SMK Caps Lock Short Stem
705-0082	SMK Caps Lock, Long Stem
705-0084	SMK Low Friction Long Stem (replaced by 705-0081)
705-0085	SNK Low Friction Short Stem
705-0102	KeySwitch Alternate(For P / N 661-0294) (replaced by 661-91181)
705-0104	Keyswitch, Mitsumi

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

705-0108	Microswitch, Toner Cassette
705-0109	Microswitch, 115 VAC, 15A
705-0110	Rocker Switch, 250 VAC, 20A
705-0123	Rocker Switch, 250 VAC, 20A, Platinum (replaced by 705-0110)
705-0175	Keyswitch with two keys
705-1025	Switch, Power
710-0007	Lamp, BI-Pin, 5V.115A
720-0003	Thermal Protector, Fuser
720-0502	Fan, 110V, 60 Hz
720-0513	Fan
720-0518	Fan, Power Supply
725-0009	Insulator, Mother Board
725-0014	Bottom Shield Insulator
725-0018	Washer, Mylar
725-0020	Insulator, Analog Board
740-0001	Fuse, Power Supply, 1 Amp, 250 V
740-0011	Fuse, .5 A, 250 V, Quick Acting, Pigtail
740-0021	Fuse, 3.15 A, 250 V, Fast Blow
740-0022	Fuse, 5 Amp 250V
740-0061	Fuse, Med Time Lag 3.154A, 250V (replaced by 922-0516)
740-0102	Fuse, 3 A, 3AG, 220 V, Slow Blow
740-0106	Fuse, .5 A, 250 V, Quick Acting, Clip
740-0108	Fuse, 3.15 A, 250 V
740-0109	Fuse, 6.3 A, 250 V, F101
740-0302	Fuse, 5A, 125V
740-0304	Fuse, 1 A, 250 V Quick Blow
740-0305	Fuse, 2 A, 250 V
740-0308	Fuse
740-0309	Fuse, 3.15 Amp
740-0401	Fuse, 4 A, 125 V, Medium Time Lag
740-1104	Fuse, 4 Amp, 250V, 5 Pk
742-0003	Battery, Alkaline, 4.5 A
742-0009	Battery, Lithium, with Leads
742-0011	Battery, Lithium, 3.6—3.9V, without Leads

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

750-0102	Network, Dip, Shunt, 4 Wire
805-0005	Chasis Base, Disk II
805-0110	Plate, Nut, 25-pin
805-0115	Disk Clamp, Alle
805-0137	Shield, Access Cover, Rear Case
805-0138	Shield, Display, EMI, PB 140 / 145 / 145B / 160 / 165 / 170
805-0156	Shield, Inner Metal
805-0168	Bracket, Apple IIGS Upgrade Keyboard
805-0169	Fence, EMI
805-0200	Plate, Pivot Retaining
805-0202	Spring, Ratchet
805-0217	Shield, Internal 800K Drive
805-0225	Bracket, Hard Drive, Pkg. of 2 (replaced by 922-0705)
805-0375	Bracket, Fan SCSI Device
805-0376	Drive Carrier, Hard Drive, 3.5" / 5.25", External
805-0378	Clamp, External Drive Cable
805-0382	Bracket, Fan
805-0388	Shield, Bottom Tray, 1.4 MB Drive
805-0397	Shield, Inverter (replaced by 076-0588)
805-0400	Foot, Elevation, Spring
805-0412	Retainer, 17 mm Drive (replaced by 922-0009)
805-0414	Retainer, 19 mm Drive (replaced by 922-0006)
805-0575	Clip, Upper Ground
805-0576	Clip, Lower Ground
805-0577	Shroud, RFI, Macintosh
805-0756	Shield, Top, Disk Drive, Apple IIc
805-0765	Shield, Internal 400K Drive
805-0766	Chassis, Macintosh
805-0807	Shield, External Drive Cable
805-0811	Bracket, Eject Switch
805-0877	Ground Clip
805-0890	Shield, Bottom
805-0891	Shield, Top
805-0908	Retainer, Slot Cover

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

805-0910	Clip, Ground
805-0913	Case, Shield
805-0914	Plate, Back, Drive 2
805-0923	Cover, Shield
805-0924	Bracket, LED
805-0925	Clamp, Cable PC 5.25
805-0927	Shield, Disk Drive Bottom
805-0928	Shield, Disk Drive Top
805-0938	Chassis
805-0939	Bracket
805-0950	Carrier, Hard Drive, 3.5", SCSI, Internal
805-0952	Carrier, Hard Drive, 3.5", SCSI, Internal (Low Side, Mounting Holes)
805-0961	Carrier, 1.4 MB Apple SuperDrive
805-0969	Shroud, RFI
805-0970	Connector, Battery
805-0973	Gasket, Foam, RFI
805-0976	Gasket, RFI, Modem
805-0980	Carrier, Hard Drive, SCSI, 3.5"
805-1120	Spring, Latch
805-1527	Shield, Disk Drive Slot Cover
805-5000	Shield
805-5001	Shield, Top, Drive 1
805-5002	Shield, Top, Drive 2
805-5028	Shield Plate
805-5029	Seat Insulating
805-5047	Shroud, RFI
805-5050	Carrier, 800K / SuperDrive
805-5051	Carrier, Hard Drive, Internal, 5.25", SCSI
805-5060	Shroud, RFI
805-5062	Drive Mount, Macintosh II / IIx / IIcx
805-5066	Carrier, Hard Drive, Internal, 3.5", SCSI (High Side Mounting Holes)
805-5070	Fence, EMI
805-5078	Carrier, Hard Drive, 3.5", SCSI, Internal
805-5081	Carrier, Hard Drive, 5.25", External, 160 SC

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

805-5106	Carrier, Hard Drive 3.5" / 5.25" / DDS-DC Drive
805-5111	Carrier, 1.4 MB Apple SuperDrive Macintosh LC & Performa 400 Series
810-0359	Lid, Apple II w / EMI
810-0360	Housing, Apple II w / EMI
810-0373	Bezel, Front, Macintosh
810-0379	Bezel, Front, Beige
810-0385	Bezel, Front, Platinum
810-0399	Bezel, Front, with Speaker, Slot Cover, Macintosh SE
810-0422	Bezel, Front, with Speaker, Slot Cover, FDHD / SuperDrive, Mac SE
810-0585	Base Pan, Smoke
810-0608	Cover, Top, White
810-0610	Cover, Top, Platinum
810-6028	Cover, Top (replaced by 810-6038)
810-6030	Fan
810-6031	Speaker / LED Assembly
810-6035	Nubus Cap
810-6038	Cover, Top, with Latches
810-6040	Drive Mount
810-6042	Case, Keyboard Top, AK II, Version A
810-6043	Case, Keyboard Top, AK II, Version B
810-6044	Case, Keyboard Bottom, AK II, Version A
810-6045	Case, Keyboard Bottom, AK II, Version B
815-0182	Adapter, 12 Degree
815-0186	Bottom Cover, Disk / / /
815-0187	Door, Disk / / /
815-0377	Actuator, Write Protect, Alps
815-0409	Retainer, Mouse Ball
815-0416	Case, Bottom ADB Keyboard
815-0417	Case, Top ADB Keyboard
815-0418	Case, Keypad Spacer ADB Keyboard
815-0458	Base
815-0459	Cover, Top
815-0558	Monitor Stand, Tilt-Swivel
815-0559	Filler, Handle Cavity, Platinum

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

815-0578	Cover, Modem Port
815-0586	Light Pipe, Power
815-0587	Door, Disk Drive, Platinum, Latch
815-0637	Door, Beige
815-0728	Case, Keyboard Top, Macintosh
815-0737	Switch, Reset / Interrupt, Beige
815-0754	Case, Keyboard Bottom, Macintosh
815-0763	Switch, Reset / Interrupt, Platinum
815-0772	Adapter, Straight
815-0778	Enclosure, Rear Housing, Beige
815-0779	Enclosure, Bezel, Beige
815-0780	Enclosure, Mask, Beige (replaced by 815-1050)
815-0781	Contrast Knob, Beige
815-0786	Filler, Handle Cavity, Beige
815-0787	Power Switch Knob, Beige
815-0795	Cover, Lower, Macintosh 400K External Drive
815-0796	Cover, Upper, Macintosh 400K External Drive
815-0798	Bezel, Macintosh External 400K Drive
815-0810	Bezel, Disk Drive
815-0811	Latch, Door, Disk Drive
815-0813	Back Panel
815-0835	Lens, Power On, Apple II
815-0836	Lens, LED
815-0884	Case, Front
815-0904	Case, Top
815-0905	Case, Bottom
815-0936	Case, Keyboard Top, Beige
815-0937	Case, Keyboard Bottom, Beige
815-0938	Door, Battery, Beige
815-0948	Case, Bottom
815-0955	Case, Top, Plastic, Platinum
815-0956	Case, Bottom Plastic, Platinum
815-0969	Cover, Plastic Daisy Chain
815-0971	Door, Battery, Platinum

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

815-0974	Lens
815-0975	Security D-Ring, Beige
815-0983	Case, Keyboard Top, Platinum
815-0984	Case, Keyboard Bottom, Platinum
815-0985	Security D-Ring, Platinum
815-0986	Door, Rear Housing
815-1008	Switch, Reset / Interrupt
815-1016	Case, Keyboard Top, Apple Keyboard
815-1017	Case, Keyboard Bottom, Apple Keyboard
815-1018	Case, Keyboard Top, Apple Extended Keyboard
815-1019	Case, Keyboard Bottom, Apple Extended Keyboard
815-1043	Cover, Bottom
815-1044	Cover, Top
815-1045	Lens, LED
815-1048	Enclosure, Rear Housing, Platinum
815-1049	Enclosure, Bezel, Platinum
815-1050	Enclosure, Mask, Platinum
815-1051	Contrast Knob, Platinum
815-1052	Power Switch Knob, Platinum
815-1059	Cover, Keyboard
815-1068	Lever
815-1084	Speaker Snap
815-1085	Knob, Volume Control
815-1092	Bezel, Floppy
815-1093	Spacer, Keyboard
815-1098	Cover, Clutch
815-1108	Cover, Center Pivot
815-1109	Retainer, Clutch
815-1110	Retainer, Floppy
815-1111	Modem Cap
815-1113	Bezel, Standard
815-1133	Ball, Trackball
815-1134	Retainer, Trackball
815-1136	Retainer, Snap-On, ADB Mouse, 25.4 mm Gray Mouse Ball

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

815-1138	Rack, Adjustable Foot, AEK II
815-1139	Foot, Rear, Adjustable, AEK II
815-1154	Cover, Access, Rear Case
815-1156	Bobbin, Cable Storage
815-1164	Cover, Disk Drive Slot
815-1182	Height Adjustment Bar
815-1193	Feed Roller Guide
815-1195	Door, Rear Housing Access
815-1197	Retaining Collar
815-1198	Actuator, PS901
815-1201	Actuator, Delivery Sensor
815-1202	Lever, High-Voltage Contact
815-1203	Lever, Shutter
815-1204	Actuator, PS13
815-1206	Cord Cover
815-1207	Cord Cover, Front
815-1209	Actuator, PS501
815-1210	DC Controller Support
815-1216	Insulator, Power / Sweep Board
815-1230	Cover, Clutch, Center
815-1231	Cover, Clutch, End
815-1233	I / O Door (replaced by 922-1697)
815-1236	Foot, Rubber
815-1237	Foot, Elevation, Right (replaced by 922-1691)
815-1240	Door, Battery (replaced by 922-1700)
815-1247	Actuator, Contrast, PB 140 / 145 / 145B / 150 / 160 / 165 / 165c / 180
815-1248	Actuator, Brightness, PB 140 / 145 / 145B / 150 / 160 / 165 / 165c / 180
815-1262	Cover, Top
815-1263	Cover, Bottom
815-1266	Foot, Elevation, Washer
815-1278	Foot, Elevation, Left
815-1305	Actuator, Brightness, Long, PB 170 / 180c
815-5042	Volume Lever
815-5071	Bracket, Fan

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

815-5073	Case, Top
815-5076	Volume Lever
815-6024	Reset / Interrupt Switch
815-6030	Drive Mount, Macintosh Ilcx / Ilci
815-6031	Bracket, Speaker
815-6032	Light Pipe, Power-On
815-6033	Button, On / Off
815-6034	Reset / Interrupt Switch
815-6036	Light Pipe, HDA
815-6237	Button, On / Off
815-6246	Bracket, 030 Expansion
815-6247	Light Pipe, Power-On
815-6249	Actuator, Reset
815-6250	Actuator, Interrupt
815-6251	Light Pipe, Power-On
815-6262	Latch, Side Cover
815-6270	Actuator, Reset / Interrupt (replaced by 922-1260)
815-6271	Light Pipe, Hard Drive
815-6272	Light Pipe, Power-On
821-0655	Cable, Flex, 19 mm-high Floppy Drive
825-0005	Nameplate, Front, Disk II
825-0009	Cover, Case Slots, Disk II
825-0011	Label, Multiple Drive ID #1
825-0012	Label, Multiple Drive ID #2
825-0036	Apple II+ Nameplate
825-0299	Label, Product ID, PowerBook 100
825-0352	Label, Power-On
825-0359	Nameplate, Apple IIe
825-0493	Label, Rear Cover, Product ID
825-0547	Label, Logo Bezel
825-0548	Label, Drive #
825-0587	Label, FCC, Quadra 950
825-0613	Label, Logo Housing
825-0742	Label, Macintosh

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

825-0907	Logo
825-1014	Label, Agency Approval, Macintosh 512K
825-1064	Label, Macintosh Signature, 128K
825-1065	Label, Macintosh Signature, 512K
825-1254	Label, Agency Approval, Beige
825-1256	Apple Logo
825-1340	Label, Logo, Platinum
825-1345	Label, Agency Approval, Platinum
825-1726	Label, Rear Cover, Product ID
825-1732	Label, FCC, Modem
825-1831	Label, Bottom Assy, Product ID
825-2021	Label, Agency Approval
825-2043	Label, Agency Approval
825-2078	Label, Product ID, Rear Cover
825-2744	Label, Product ID, Multi Scan 20
825-2745	Label, Product ID, Multi Scan 17 Display
825-4018	Label, Agency Approval
826-0481	Label, Repair Log
830-0002	Apple II Hedlock Fastener
830-0003	Apple II PCB Standoff Fastener
830-0081	Spacer, Keyboard Dual Locking
830-0240	Fastener, Snap in Plastic
830-0262	Cable Clip A
830-0263	Cable Clip B
830-0270	Rivet, Nylon Snap-In, Black
835-0006	Screw, Hexagonal Nut Plate
835-0174	U Type Nut
835-0176	Nut U-Tupe .022 Thk.
844-0018	Screw, FDHD SuperDrive (replaced by 922-3159)
860-0044	Standoff, Platinum
860-0053	Washer, Split Lock Metric, 3.5m
860-0242	Washer, M3. 5x4.0 I.D.x7.0 O.D.
860-0243	Washer, 6.1 I.D. x 12 O.D., Brass
860-0282	Washer, Lock, Internal Tooth

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

860-0295	Separation Pad
860-0296	Bushing, Pickup Shaft
860-0297	Bushing, Feeder Assembly
860-0298	Bushing, Feed Shaft
865-0001	Feet, Rubber
865-0003	Rubber Foot
865-0021	Foot, Bumper
865-0024	Foot, Platinum (replaced by 922-0040)
865-0026	Feet, Rubber, Bottom
865-0027	Handle, Apple IIc
865-0029	Knob, Brightness, Platinum
865-0030	Handle (replaced by 865-0027)
865-0047	Knob, Brightness
865-0051	Foot, Platinum (replaced by 922-1693)
865-0054	Foot, Flat
865-0055	Handle
865-0057	Foot, Front, AEK II
865-0060	Foot, Corner
865-0066	Foot, Platinum (replaced by 922-1694)
865-0067	Foot Pad, Rear, AEK II
865-0068	Insulator, Battery
865-0800	Foot, Rubber, Side
865-0867	Button Assy, Eject
870-0023	Spring, Disk Door, Latch
870-0030	Spring, Foot Return, AEK II
870-0044	Spring, Cassette Sizing
870-0093	Roller, Cassette
870-0094	Shaft, Cassette Pickup Roller
870-0095	Print Density Slider
870-0096	Roller, Cassette Pickup B
870-0097	Shaft, Cassette Feeder Roller
870-0098	Roller, Fuser Lower
870-0099	Roller, Fuser Upper
870-0100	Roller, Multipurpose Pickup

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

870-0101	Roller, Cassette Pickup A
870-0102	Roller, Envelope Cassette
870-0103	Roller, Transfer
870-0104	Roller, Passive Delivery
875-0049	Grounding Washer
875-0063	Shielding Strip
875-0084	Ring, Paper Pickup
875-0085	Ring, Ratchet B
875-0086	Ring, Ratchet A
875-0110	Gasket, EMI Shielding
875-0112	Plug, Rubber, Display Bezel
880-0044	Gear 34T, Cassette
880-0045	Gear 39T, Cassette
880-0046	Gear 37T, Cassette
880-0047	Gear 33T / 19T, Cassette
880-0048	Gear 17T, Cassette
880-0049	Gear 20T, Front Cover
880-0050	Gear 30T, Front Cover
880-0051	Gear 27T, Transfer Roller
880-0052	Gear 30T, Feeder
890-0193	Ground Plate, Upper Chassis, Right
890-0194	Ground Plate, Upper Chassis, Left
890-0286	Sensor, Paper
890-0423	Fiber Holder Block
890-0424	Rod Mount
890-0426	Motor, Stepping DC
890-0427	Heater, Fuser 110 / 115 V
890-0428	Heater, Fuser 220 / 240 V
890-0606	Cable, Pickup Assembly
890-0607	Transfer Roller Mount, Right
890-0608	Drive Assembly
890-0609	Drum Drive Assembly
890-1196	Nut Plate, Right
890-1199	Nut Plate, Left

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

890-1200	Sensor Mounting Plate
890-1205	Ground Plate C
890-1208	Plate, Ground B (replaced by 948-0156)
890-8603	Transfer Roller Mount, Left
890-8604	Cable Assembly, Bottom
890-8605	Cable Assembly, Multipurpose
890-8608	High-Voltage Contact Assembly
905-0001	Contrast / Brightness Control, AppleColor RGB
905-0002	Contrast Control, Monochrome Monitor
905-0003	Board, Contrast Control J, Rev. A (replaced by 905-0012)
905-0004	Board, Contrast Control
905-0007	Contrast Brightness Assembly
905-0009	Contrast / Brightness Assembly
905-0010	Contrast / Brightness Assembly, International
905-0011	LED Contrast Brightness Assembly
905-0012	Board, Contrast Control J, Rev. B
910-0058	High-Voltage Capacitor, Rev. A Only
914-0439	Packaging Diskette
915-0001	Transformer, 120V
915-0009	Transformer, Monochrome Monitor
915-0029	Universal Transformer
915-0030	Transformer, 110V
915-0031	Universal Transformer
915-0038	Transformer Assy, 110 V
915-0039	Transformer, 100 / 240 V (Universal)
915-0042	Transformer / Voltage Sw. Assy, 100-240V
922-0001	Door Retainer Pins, HDI-20 External Floppy Drive
922-0002	ROM Upgrade Kit, Ethernet, Macintosh LC
922-0003	Cable, Hard Drive, LED, Amber, Fits 1" Height Drives
922-0004	Fuse, 3.15 A, Slo Blo, Pkg. of 5
922-0005	Keyswitch Set, AEK II, White, Pkg. of 10
922-0006	Retainer, 19 mm Drive
922-0008	Bracket, Mounting, 40 MB Hard Drive, use with 661-1632
922-0009	Retainer, 17 mm Drive

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0012	Screw, M3x0.5x4MM, Pkg. of 5
922-0013	Controller Card Cup Kit
922-0014	Gasket, Sound, Mother Board, Pkg. of 10
922-0015	Fuse, 5A, Pkg. of 10
922-0017	Plate Assembly, Carrier Motor, 24-bit
922-0018	Plate, Carrier Shaft, Right, 24-bit
922-0020	Lamp, 24-bit, Pkg. of 5 (replaced by 922-1729)
922-0021	Cable, Optical Assembly / Board, 24-bit
922-0022	Cable, Power Supply Board, 24-bit
922-0023	Spacer, Mother Board, Pkg. of 10
922-0024	Inverter, A / M GS, PB 180
922-0025	Inverter, FSTN, Blue, Rev. C, PB 145 / 160 / 165
922-0026	Bezel, Display, PB 160
922-0027	Cable, Flex, Hard Drive
922-0029	Cover, Clutch, Center PB 145B / 160 / 165 / 165c / 180 / 180c
922-0030	Bezel, Display, PB 180
922-0031	Switch, On / Off
922-0032	Chassis Assembly
922-0033	Bezel, Contrast / Brightness / LED Assembly
922-0034	Housing, Rear, Plastic
922-0035	Cable, Video
922-0036	Contrast Brightness / LED Assembly
922-0037	Monitor Stand, Tilt-Swivel
922-0040	Feet, Rubber, 25x12x6 mm,Pkg. of 20
922-0043	Power Adapter, 17 W
922-0044	Housing, Display
922-0045	Insulator, Mother Board, PB 160 / 165 / 180 / 180c, Pkg. of 10
922-0046	Cover, Sound Jack
922-0047	Case, Bottom (replaced by 076-0872)
922-0048	Case, Top, PB 160 / 180 (replaced by 922-0717)
922-0050	Bezel, Display, PB 145
922-0051	Cable, Power, Hard Drive / CD-ROM
922-0052	Cable Assembly, CD-ROM, Audio (replaced by 922-0842)
922-0053	Cable, SCSI, Hard Drive / CD-ROM

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0054	Power Cord
922-0055	Speaker
922-0056	Housing, Top Cover (replaced by 922-0405)
922-0057	Housing, Bottom Case (replaced by 922-0406)
922-0058	Chassis, Internal
922-0059	Bezel, Front
922-0060	Bezel, CD-ROM Drive, Blank (replaced by 922-1373)
922-0061	Bezel, CD 300, Slotted (replaced by 922-0404)
922-0063	Logo / Product Name Plate, Macintosh Ilvx
922-0064	Logo / Product Name Plate, Performa 600
922-0065	Logo / Product Name Plate, Macintosh Ilvi
922-0066	Carrier, Hard Drive
922-0067	Rails, CD Carrier, Pkg. of 6
922-0069	Screw, Tap, Hex, Wash, #8-16, Pkg. of 6
922-0077	Screw, M2.5X8mm, Pkg. of 10
922-0080	Cap, Modem
922-0081	Battery Charger, External, Type 1, Duo (replaced by 922-0576)
922-0082	Power Adapter, 25 W (replaced by 922-1202)
922-0083	Microphone
922-0084	Ball, Trackball, PB Duo
922-0085	Retainer, Trackball
922-0086	Battery Case, Type 1 / 2 / 3
922-0087	Foot, Flip, Left, Pkg. of 10
922-0088	Foot, Flip, Right, Pkg. of 10
922-0089	Bumper, Rubber, Pkg. of 2
922-0090	Clip, Clutch Retainer, Pkg. of 2
922-0091	CPU Stiffener, Duo 210 / 230 / 250 (replaced by 922-0433)
922-0092	Display Switch Assembly
922-0093	Actuator, Display Assembly
922-0094	Card, Modem Interface, International
922-0095	Card, Modem Interface, Domestic
922-0096	Board, On / Off
922-0097	Hook, Logic Board Snap-In, Pkg. of 10
922-0098	Palm Rest, Left Side, Apple Adjustable Keyboard

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0099	Palm Rest, Right Side, Apple Adjustable Keyboard
922-0100	Palm Rest, Apple Adjustable Keypad
922-0101	Clip, EMI Bottom Housing, Pkg. of 10
922-0102	Card, Nubus Adapter
922-0103	Mechanical Latch Assembly
922-0104	Ejector Assembly
922-0105	Speaker
922-0106	Subassembly, Plastic
922-0107	Coprocessor, Math (Use with LC 520/550/560 and Performa 550/560 Only)
922-0108	Lock Plug, with 2 Keys
922-0109	Feet, Pkg. of 4
922-0110	Guide, Nubus Adapter Card
922-0111	Cable, Floppy
922-0112	Cable, Floppy Drive
922-0114	Insulator
922-0115	Clip, EMI, CD-ROM, Pkg. of 25
922-0116	Screw, M3.5x0.6x20mm, Pkg. of 10
922-0117	Screw, Tap, M3.5x7 mm, Pan Head, T-10, Pkg. of 10
922-0118	Screw, M3.5X1.57X30MM, Pkg. of 10
922-0119	Screw, M3.5X0.6X10mm, Pkg. of 10
922-0120	Screw, M3.5x0.6x6mm, Pkg. of 10
922-0121	Motor
922-0122	Feeder Frame
922-0123	Cover, Bottom
922-0124	Cover, Right
922-0125	Sizing Guide
922-0126	Tray Extension
922-0127	Envelope Weight
922-0128	Envelope Weight Arm
922-0129	Cover, Left
922-0130	Cover, Front
922-0131	Guide Plate
922-0132	Guide Plate Ground
922-0133	Cable, Guide Plate Grounding

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0134	Feed Roller, Secondary
922-0135	Separation Assembly Coupling
922-0136	Pressure Block
922-0137	Actuator, Sensing
922-0138	Passive Roller Shaft
922-0139	Cable, Printer Interface
922-0140	Separation Assembly Shaft
922-0141	Drive Assembly
922-0142	Cable Clamp
922-0143	Separation Drive Plate
922-0144	Separation Assembly
922-0145	Pickup Roller Shaft, Rear
922-0146	Pickup Roller Shaft, Forward
922-0147	Primary Feed Shaft
922-0149	Motor Assembly
922-0151	Cover, Rear
922-0152	Frame, Right
922-0153	Frame, Left
922-0154	Cover, Right
922-0155	Controller Block Cover
922-0156	Rear Cover Grounding Plate
922-0157	Cover, Front
922-0158	Front Cover Support Rod
922-0159	Base Pan
922-0160	Foot, Base Pan
922-0161	Controller Block
922-0162	Cassette Size Actuator Cover
922-0163	Cassette Size Actuator
922-0164	Cover, Left
922-0165	Feeder Roller Housing
922-0166	Passive Roller Housing
922-0167	Guide Rail
922-0168	Drive Block Plate
922-0169	Drive Block Mount

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0170	Roller, Feeder
922-0171	Pickup Cam
922-0172	Shaft, Feeder
922-0173	Shaft, Pickup
922-0174	Solenoid, Cassette Pickup
922-0175	Passive Roller Mount
922-0176	Pendulum
922-0177	Paper Weight
922-0178	Roller, Pickup
922-0179	500 Sheet Cassette
922-0180	Fuse, 125 V, Power Supply, Pkg. of 10
922-0181	Fuse, 250 V, Power Supply, Pkg. of 10
922-0182	Feet, Bottom, Pkg. of 4
922-0183	Label, Serial Number, Blank, Pkg. of 10
922-0184	Cover, Rear
922-0185	Upper Case, Unit
922-0186	Cover, Front
922-0187	Tray, Output
922-0188	Cover, Cut Sheet Feeder
922-0189	Paper Support
922-0190	Spring, Front Cover, Pkg. of 4
922-0191	Roller, Eject, Pkg. of 2
922-0192	Roller, Cut Sheet Feeder
922-0193	Belt, Carriage
922-0194	Carriage Unit
922-0195	Motor, Carriage
922-0196	Clip, Shaft, Pkg. of 10
922-0197	Clip, Carriage Release, Pkg. of 10
922-0198	Case, Bottom
922-0199	Housing, Top Case
922-0200	Face-Up Tray Assembly
922-0201	Inductor, Insulator
922-0202	Fan
922-0203	Main Motor

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0204	Board, Interface, Power Supply to HVPS
922-0205	Transfer Roller
922-0206	Board, Pickup Controller
922-0207	Pickup Block Motor
922-0208	Board, Pickup Sensor
922-0209	Drive Belt
922-0210	Cable, LED Display
922-0211	Cable, Scanner-DC Controller
922-0212	Cable, Laser-DC Controller
922-0213	Cable, Engine Interface
922-0214	Cable, Main Motor
922-0215	Cable, Power Supply to DC Controller
922-0216	Cable, Power Supply to I / O Controller
922-0217	Cable, HVPS to DC Controller
922-0218	Cable, Pickup Controller-DC Controller
922-0219	Cable, Sheet Feeder Interface
922-0221	Cover, Multipurpose Tray
922-0222	Cover, Cassette Stop
922-0223	Cover, Right Corner
922-0224	Cover, Power Inlet
922-0225	Cover, Rear
922-0226	Expansion Slot Cap
922-0227	Multipurpose Tray
922-0228	Multipurpose Tray Extension
922-0229	Cover Liner
922-0230	LED Shield
922-0231	Cover, Front
922-0232	LED Display
922-0233	Door, Fuser Access
922-0234	Top Cover Assembly
922-0235	Cover, Toner Access
922-0236	Cover Interlock Arm
922-0237	Output Tray Extension
922-0238	Output Tray Extension Holder

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0239	Cover, Paper Output
922-0240	Cleaning Brush
922-0241	Laser Shutter
922-0242	Toner Cartridge Guide, Left
922-0243	Toner Cartridge Guide, Right
922-0244	Toner Cartridge Support
922-0245	Cassette Guide, Left
922-0246	Laser Shutter Arm
922-0247	Foot
922-0248	Lateral Brace
922-0249	Cassette Guide, Right
922-0250	Toner Pressure Arm, Left
922-0251	Toner Pressure Arm, Right
922-0252	Latch, MP Tray, Mounting Clips, Pkg. of 5
922-0253	Closure Panel
922-0254	Fan Duct A
922-0255	Fan Duct B
922-0256	Fan Shield
922-0257	DC Controller Mount
922-0258	Strap Hinge
922-0259	Shield, Controller Board Connectors
922-0260	Bracket, I / O Shield
922-0261	Hard Drive Mount
922-0262	I / O Shield
922-0263	I / O Cover Plate
922-0265	Feeder Guide
922-0266	Passive Transfer Roller
922-0267	Transfer Block Assembly
922-0268	HVPS Connecting Block
922-0269	HVPS Cover
922-0270	Paper Weight A
922-0271	Paper Weight B
922-0272	Sheet Feeder Connecting Block
922-0273	Cable Cover

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0274	Drive Assembly
922-0275	Solenoid, Cassette Pickup
922-0276	Pickup Block Frame, Left
922-0277	Gear Mount
922-0278	Solenoid, Multipurpose Pickup
922-0280	Roller, Cassette Pickup
922-0281	Roller, MP Tray Pickup
922-0282	Guide, MP Tray, Upper
922-0283	Paper Guide
922-0284	Guide, Opening
922-0285	Cable, Envelope Feeder Interface
922-0286	MP Tray Guide Assembly
922-0287	Actuator, Paper-End
922-0288	Guide
922-0289	Sensor Holder Assembly
922-0290	Multipurpose Guide Plate
922-0291	Transfer Guide Assembly
922-0292	Delivery Roller Assembly (replaced by 922-2637)
922-0293	Delivery Frame
922-0294	Drive Belt End Plate
922-0295	Roller, Upper Passive Delivery
922-0296	Roller, Lower Delivery
922-0297	Roller, Upper Delivery
922-0298	Upper Delivery Guide
922-0299	Delivery / Interlock Sensor
922-0300	Fuser Roller, Upper
922-0301	Fuser Roller, Lower
922-0302	Paper Entrance Guide
922-0303	Separation Guide, Upper
922-0304	Fuser Cover, Right
922-0305	Fuser Cover Cap, Left
922-0306	Fuser Cable Cover
922-0307	Separation Guide, Lower
922-0308	Actuator, Delivery Sensing

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0309	Fuser Cover, Left
922-0310	Fuser Heating Bulb (110 / 115V)
922-0311	Fuser Heating Bulb (220 / 240)
922-0312	Fuser Thermistor
922-0313	Fuser Thermoprotector
922-0314	Cable, Fuser Connector
922-0315	Fuser Cable Guide
922-0316	Cable, SCSI Device to Case, AppleCD 150
922-0317	Cable, SCSI Select Assembly, AppleCD 150 / 300
922-0318	Cable, Rear Audio Out Assembly, AppleCD 150 / 300
922-0319	Case, Top, AppleCD 150 / 300
922-0320	Case, Bottom, AppleCD 150 / 300
922-0325	LED Lens, 24-bit, Pkg. of 10
922-0326	Arm, Trigger, 24-bit
922-0327	Holder, Ferrite Core, 24-bit
922-0328	Plate, Motor, 24-bit
922-0329	Label, Bottom Assembly, Product ID, 24-bit
922-0330	Plate, Shield, 24-bit
922-0331	Plate, Front, 24-bit
922-0332	Housing, Inside, 24-bit
922-0333	Cover, Optical Assembly, 24-bit
922-0334	Stopper, Carrier, 24-bit, Pkg. of 10
922-0336	Release Mechanism
922-0337	Cable, Hard Drive
922-0338	Cable, Hard Drive Power
922-0339	Gear, 20T Fuser, Version B
922-0340	Cable, ADB, Keyboard to Keypad
922-0343	Feet, Apple Adjustable Keyboard
922-0345	Retainer, ADB Mouse II, 22.23 mm Gray Mouse Ball - M
922-0347	Cable, SCSI Device to Case, AppleCD 300
922-0348	Feet, Rubber, AppleCD 150 / 300, Pkg. of 25
922-0349	Ball, Mouse, 22.23 mm Diameter, Gray
922-0350	Retainer, ADB Mouse II, 21.9 mm Black Mouse Ball - L
922-0351	Cable, Floppy Drive

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0352	Cable, SCSI Drive (replaced by 922-0804)
922-0353	Speaker
922-0354	Cable, LED, Power
922-0355	Bezel, CD, Slotted
922-0356	Column, Top Cover Support
922-0357	Actuator, On / Off
922-0358	Bezel, Blank
922-0359	Chassis, Drive Assembly
922-0360	Housing, Bottom (replaced by 922-0806)
922-0361	Insulator Sheet, Centris 610 / AWS 60
922-0362	Panel, Rear, Quadra 800 / AWS 80
922-0363	Panel, Front, Quadra 800 (replaced by 076-0472)
922-0364	Label, Name Plate, Centris 610
922-0365	Rear Housing Assembly, I / O Bezel
922-0366	Shield, 5.25" Drive Bay
922-0367	Shield, Hard Drive
922-0368	Housing, Top Cover Assembly (replaced by 652-0037)
922-0369	Fuse, 2 A, 250 V, Pkg. of 10
922-0370	Fuse, 1 A, 200 V, Pkg. of 10
922-0373	Cable Assembly, Flex, PB 165c
922-0374	Inverter, DC to AC, PB 165c
922-0375	Converter, DC to DC, PB 165c
922-0376	Power Adapter, U.S. / Japan
922-0377	Bezel, Display, PB 165c
922-0378	Inverter, DC / AC, PB 180c
922-0379	Converter, DC / DC, PB 180c
922-0380	Cable Assembly, Flex, Display, PB 180c
922-0381	Housing, Display, PB 165c
922-0382	Cassette, Letter
922-0383	Cassette, Universal
922-0384	Cassette, A4
922-0385	Front Panel Controls and LEDs Assembly
922-0386	Audio Enclosure
922-0387	Speakers, Pkg. of 2

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0388	Cable, Video
922-0389	Microphone
922-0390	Bezel, Apple AudioVision Display
922-0391	Housing, Rear
922-0392	Screw, Torx, K40 1.79x16, TP Flat, Pkg. of 10
922-0393	Retainer, NuBus
922-0394	Housing, Speaker
922-0395	Screw, Thumb Slotted, 6-32, Pkg. of 4
922-0396	Brace, Chassis Support
922-0397	Label, FCC, Quadra 800
922-0398	Cable, Hard Drive
922-0399	Shield, SuperDrive - Long
922-0400	Shield, CD-ROM (replaced by 922-0826)
922-0401	Screw, M3x8mm, Pan Head, Phillips, Pkg. of 10
922-0402	Cover, Voltage Select, 24-bit
922-0404	Bezel, AppleCD 300
922-0405	Housing, Top Cover
922-0406	Housing, Bottom Case
922-0409	Template, Apple Adjustable Keypad
922-0411	Label, Blank, Serial No., White, PB Duo 210 / 230, Pkg. of 10
922-0412	Cable, Converter to Inverter, PB 180c
922-0414	Bezel, Display, PB 180c
922-0415	Housing, Display, PB 180c
922-0416	Label, Product ID / FCC, PB 180c, Pkg. of 10 (replaced by 076-0872)
922-0417	Shield, Display EMI, PB 180c
922-0418	Shield, Inverter, Pkg. of 5
922-0419	Cable, Adapter, 45-pin
922-0420	Base Assembly
922-0421	Monitor Stand
922-0422	Insulator, Inverter DC to AC, PB 180c, Pkg. of 5
922-0423	Power Adapter, 110 V
922-0424	Power Adapter, 220 V
922-0425	Power Adapter, Japan
922-0426	Power Adapter, Australia

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0427	Power Adapter, United Kingdom
922-0428	Cable, Parallel to Serial
922-0429	Control Panel Assembly
922-0430	Stand
922-0431	Board, Inverter, Duo 270c / 280c
922-0432	Speaker Assembly, Duo 270c / 280c
922-0433	CPU Stiffener, Duo 210 / 230 / 250 / 270c (replaced by 076-0339)
922-0435	Door, Battery, Type 2 / 3
922-0443	Bezel, Drive, LC 520, FD Manual
922-0444	Bezel, Drive, LC 520, FD Manual, CD 300i
922-0445	Carrier, Floppy Drive, Manual Insert
922-0447	Label, Product ID, LC II
922-0448	Label, Product ID, LC III
922-0449	Shield, EMI, PB 165c
922-0450	Fixing Film Assembly, 110 V
922-0451	Fixing Film Assembly, 220 V
922-0452	Pickup Motor Assembly
922-0453	HVT Connector Assembly
922-0454	Drive Assembly
922-0455	Motor Assembly
922-0456	Fan
922-0457	Scanner Interconnect Assembly
922-0458	Solenoid, Pickup
922-0459	Cassette, Universal
922-0460	Cover, Power Connector
922-0461	Cover, Interface Connector
922-0462	Cover, Assembly
922-0463	Door, Top
922-0464	Door, Rear
922-0465	Light Pipe Assembly
922-0466	Delivery Roller Assembly
922-0467	Passive Delivery Rollers
922-0468	Mirror Assembly
922-0469	Feeder Guide Assembly

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0470	Arm Registration Assembly
922-0471	Roller Assembly
922-0472	Intake Guide
922-0473	Lock (Pkg. of 5)
922-0474	Roller, Paper Pickup
922-0475	Cover Interlock Actuator
922-0477	Transfer Mount Assembly, Left
922-0478	Transfer Mount Assembly, Right
922-0480	Grounding Plate
922-0481	Chassis
922-0483	Optional Feeder Drive Assembly
922-0484	Fuse, 125 V, 10 A (Pkg. of 10)
922-0485	Fuse, 201 V (Pkg. of 10)
922-0486	Fuse, 250 V, 3.15 A (Pkg. of 10)
922-0487	Bezel, Display, PB 145B
922-0489	Label, Product ID, PB 145B, Pkg. of 10 (replaced by 076-0870)
922-0491	Power Cord, U.S.
922-0498	Case, Bottom, PB 145B (replaced by 076-0870)
922-0499	Connector, LocalTalk, RJ-11, DB9
922-0500	Terminators, LocalTalk, RJ-11 (Bag of 10)
922-0501	Connector, LocalTalk, RJ-11, Mini DIN-8
922-0502	Fuse, 4.0 A, 250 V, Pkg. of 5
922-0503	Connector and Cable Assembly, Logic Board, LC 520 / 550
922-0504	Cable, SCSI Internal
922-0505	Cable, Audio, Internal
922-0506	Rubber Feet (Bag of 50)
922-0512	IC, ROM, 1 MB x 8, 150 ns, 32-pin, LL, Rev. 2.0
922-0513	IC, ROM, 1 MB x 8, 150 ns, 32-pin, LM, Rev. 2.0
922-0516	Fuse, 3.15 A, 250 V, Pkg. of 5
922-0518	Insulator, Heatsink, Floppy Drive, Pkg. of 10
922-0519	Cover, Top, with Door
922-0521	Cover, Top, Rev. B (replaced by 922-0519)
922-0522	Plug, Microphone Port (Bag of 10)
922-0523	Bezel, Floppy Drive, Manual Insert

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0524	IC, ROM, 1 MB x 8, 150 ns, 32-pin, UM, Rev. 2.0
922-0525	IC, ROM, 1 MB x 8, 150 ns, 32-pin, UU, Rev. 2.0
922-0527	Paper Support
922-0528	Guide, Printer Paper
922-0529	Cover, Front
922-0530	Cover, Upper
922-0531	Cover, Ink Cartridge
922-0532	Label, Ink Cartridge Left
922-0533	Label, Ink Cartridge Right
922-0534	Coupler, Pkg. of 5 (replaced by 922-0252)
922-0535	Cover, Rear
922-0537	Cover, Inner
922-0538	Roller Assembly, Inner Cover
922-0540	Lubricant, Molykote
922-0541	Fuse, 250V, 2A (Pkg. of 10)
922-0542	Front Panel, Manual Insert Floppy
922-0543	Shield, Display, EMI, PB 145B / 165 / 180
922-0544	Plug, AC Adapter, Pkg. of 5
922-0545	Top Cover, Manual Insert Floppy
922-0548	Housing, Top Cover, with Manual Insert Floppy Drive
922-0549	Remote Control, I / R (replaced by 922-1201)
922-0550	Label, Product ID, Performa 466, Pkg. of 10
922-0551	Label, Product ID, Performa 467, Pkg. of 10
922-0552	Label, Product ID, Performa 460, Pkg. of 10
922-0555	Label, Product ID, Performa 475, Pkg. of 10
922-0558	Bezel, Drive, Performa 550, FD Manual, CD 300i
922-0560	Power Adapter, In-Line
922-0562	Battery Recharger, MessagePad & MessagePad 100
922-0563	Case, Carrying, Leather, MessagePad & MessagePad 100
922-0564	Cable, Macintosh Connect
922-0565	Cable, PC Connect
922-0566	Cable, Converter to Inverter, PB 165c
922-0567	Power Adapter, Power CD, U.S.
922-0568	Cable, Audio / Video, Power CD

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0569	Case, Carrying, Sport, MessagePad & MessagePad 100
922-0570	Battery Booster Pack
922-0571	Power Adapter, PowerCD, Japan
922-0572	Power Adapter, Power CD, United Kingdom
922-0573	Power Adapter, Power CD, European
922-0574	Remote Control, Power CD, Blue
922-0575	Remote Control, Power CD, Gray
922-0576	Battery Charger, External, Type 1 / 2 / 3
922-0577	Cable, Display, Duo 270c / 280c
922-0578	Actuator, Brightness, Duo 270c / 280c
922-0579	Shield, Display, EMI, Duo 270c / 280c
922-0581	Rails, Drive Mounting
922-0582	Housing, Top Cover
922-0583	Housing, Bottom Case
922-0584	Label, Product ID, Quadra 605
922-0586	Label, Product ID, Macintosh Quadra 650
922-0588	Label, Product ID, Quadra 610, Pkg. of 10
922-0591	Insulator, Sound Jack, Mother Board
922-0592	Fan, Fuser
922-0593	Sensor, Pre-Registration
922-0594	Sensor, Toner
922-0595	Sensor
922-0596	Sensor, Paper Out (Tray 2)
922-0597	Sensor, Paper Out (Tray 3)
922-0598	Clutch, Transfer (Tray 2)
922-0599	Clutch, Transfer (Tray 3)
922-0600	Solenoid, Feed (Tray 2)
922-0601	Solenoid, Feed (Tray 3)
922-0603	Chute Assembly, Transfer
922-0604	Clutch, Registration
922-0606	Erase Assembly
922-0607	Harness Assembly, Pop-Up
922-0608	Harness Assembly, Exit
922-0609	Latch, Push, Control Panel

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number Part Name

922-0610	Lever, Push Latch
922-0611	Roller Assembly, Exit
922-0612	Roller Assembly, Feed
922-0613	Sensor, Paper Size (Tray 2)
922-0614	Sensor, Paper Size (Tray 3)
922-0615	Belt, LaserWriter Pro 810
922-0616	Cover Assembly, Console, LaserWriter Pro 810
922-0618	Panel, Front, AWS 80
922-0619	Bezel, DDS-DC, Mini-T, v2 (replaced by 922-0969)
922-0620	Bezel, Blank, Version 2
922-0621	Carrier, Hard Drive / Tape Drive, 3.5"
922-0622	Label, FCC, AWS 80
922-0623	Label, Name Plate, AWS 60
922-0624	Label, Product ID, AWS 60, Pkg. of 10
922-0625	Sensor, Paper Out, (Tray 1)
922-0626	Sensor, Paper Size (Tray 1)
922-0627	Clutch, Transfer (Tray 1)
922-0628	Solenoid, Feed (Tray 1)
922-0630	Motor Drive Assembly
922-0631	Paper Transfer Unit
922-0632	Cable, Power Supply, High-Voltage
922-0633	Fuser Exit Bracket Assembly
922-0634	Fuser Roller
922-0635	Exit Sensor
922-0636	Fuser Bulb (110V)
922-0637	Fuser Bulb (220V)
922-0638	Main Motor
922-0639	Drive Assembly
922-0640	Transfer Roller
922-0641	Switch Assembly
922-0642	Paper Delivery Guide
922-0643	Gear, 27T, Fuser Heater Roller
922-0644	Fuser Pressure Roller
922-0645	Cover Bracket, Right

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0646	I / O Bracket
922-0649	Shield, CD-ROM Drive, Apple CD 300, v2
922-0650	Bottom Cover, Left, 500 Sheet Feeder
922-0651	Bottom Cover, Right, 500 Sheet Feeder
922-0652	Cover, Rear, 500 Sheet Feeder
922-0658	Spring, Grounding
922-0660	Shield, I / O Board
922-0661	Battery Recharger, 110V, U.S.
922-0662	Printhead
922-0663	Board, Sensor
922-0665	Purge Unit
922-0667	Motor, Carriage
922-0668	Motor, Paper Feed
922-0669	Encoder
922-0670	Photo Interrupter
922-0671	Cable, Macintosh, DIN-8 to DIN-8
922-0673	Battery Cover
922-0674	Neck Strap
922-0675	Cable, PC Adapter, DB9 / DB25, Black
922-0676	Cable, DIN-8 to DB9, Black
922-0682	Spur Holder Unit
922-0683	Cable, Home Position
922-0684	Control Panel Assembly
922-0685	Board, Microprocessor Control
922-0686	Board, Serial I / O
922-0687	Board Assembly, Base ADB
922-0689	Belt, Carriage
922-0693	Board, Serial I / O
922-0694	Board, Control Panel
922-0695	Board, Microprocessor Control
922-0696	AC Inlet
922-0697	Monitor Stand, Tilt-Swivel
922-0698	AC Inlet
922-0699	Label, Product ID, LC 475, Pkg. of 10

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0702	Bezel, Drive, LC 575, FD Manual, CD 300i
922-0704	Door, I / O (LC 575)
922-0705	Bracket, Hard Drive, 2.5", Pkg. of 2
922-0706	Cable, DOS Compatibility, External
922-0708	Bracket, Adapter Card
922-0709	Housing, Rear
922-0710	Cover, Control Panel
922-0713	Cable, Modem PCMCIA, RJ11
922-0714	Case, Modem, Pkg. of 10
922-0715	Bezel, Drive, Performa 560, FD Manual, CD 300i
922-0716	Bezel, Drive, Manual, 300i, Performa 520 (Japan only)
922-0717	Case, Top
922-0719	Label, Product ID, Power Mac 6100 / 60, Pkg. of 10
922-0720	Housing, Rear, I / O Bezel
922-0721	Cable, HDI45 to DB15, Display Adapter
922-0722	Panel, Rear
922-0723	Cable, SCSI, CD / Tape
922-0724	Cable, CD Audio, Pkg. of 5
922-0730	Bezel
922-0731	Housing, Rear
922-0732	Cable, Video
922-0733	Focus VR Control
922-0734	Panel, Rear, Conn
922-0735	Fuse, 6.3 A, 250 V, Pkg. of 10
922-0736	Cable, Mac / PC Adapter
922-0737	Panel, Support, with Buttons
922-0740	Cable, Phone RJ-11, 7 ft.
922-0741	Label, Product ID, Quadra 660AV, Pkg. of 10
922-0742	Bezel
922-0743	Support, Control Board
922-0744	Panel, Rear, Conn
922-0745	Fuse, 4 A, 250 V, Pkg. of 10
922-0749	Cable, Video
922-0750	Battery, Alkaline, 4.5 V, Velcro Mount

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0751	Battery Booster Pack
922-0753	Battery Recharger, MessagePad 110 / 120
922-0754	Stylus, MessagePad 110 / 120, Pkg. of 5
922-0755	Battery Cover, MessagePad 110, Pkg. of 5
922-0756	Battery Cover, Lithium, MessagePad 110, Pkg. of 5
922-0757	Rubber Foot, MessagePad 110 (Bag of 50)
922-0759	Stylus, Recharger Cradle, MessagePad 110 / 120
922-0761	Case, LC, Leather, MessagePad 110 / 120 / 130
922-0762	Cable, SCSI
922-0763	Carrier, Floppy Drive, 1.4 MB, Manual Insert
922-0764	Bezel, Drive, LC 550 / 575, FD Manual
922-0765	Bezel, Drive, LC 575 & Performa 550 / 575 / 577 / 578 FD Manual, CD 300i+ (replaced by 922-0766)
922-0766	Connector, CD Audio
922-0768	Adapter, PDS, Power Macintosh
922-0769	Cable, Trackpad
922-0770	Bracket, Hard Drive (replaced by 922-1209)
922-0771	Clutch Covers, Pkg. of 10
922-0773	Shield, Daughter Board, EMI, Pkg. of 2
922-0774	Board, Inverter
922-0775	Board, Interconnect
922-0776	Cable, Interconnect to Inverter, Pkg. of 5
922-0778	Cable, Interconnect to Logic Board
922-0779	Cable, Hard Drive to Logic Board, Pkg. of 10
922-0780	Cable, Floppy Drive to Logic Board, Pkg. of 10
922-0783	Microphone, Pkg. of 5
922-0785	Carrier, Trackpad, Pkg. of 10
922-0786	Battery, Backup, with Cable
922-0787	Battery Cover, Backup, Pkg. of 10
922-0788	Cover, Base, Center, Pkg. of 10
922-0789	Access Cover, Display
922-0790	Door, Rear, Pkg. of 10
922-0791	Power Adapter, 36 W (replaced by 922-1202)
922-0792	Case, Top
922-0793	Case Top, PB Duo 280c

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0796	Cable, Display, Duo 280
922-0800	Bezel, CD-ROM Drive, Trayloading, Pkg. of 5
922-0801	Label, Product ID, Power Mac 7100 / 66, Pkg. of 10
922-0802	Label, Product ID, Power Mac 7100 / 66 AV, Pkg. of 10
922-0803	Cable, SCSI, Hard Drive
922-0804	Cable, SCSI Drive, Pkg. of 5
922-0805	Bezel, CD-ROM Drive, Trayloading, Pkg. of 10
922-0806	Housing, Bottom
922-0807	Housing, Top
922-0808	Insulator Sheet, Pkg. of 10
922-0809	Shield, Floppy Drive, Pkg. of 10
922-0811	Bezel, CD-ROM Drive, Trayloading, Pkg. of 5
922-0812	Shield, CD-ROM Drive, Trayloading, Pkg. of 5
922-0813	Shield, Floppy Drive, Pkg. of 5
922-0814	Panel, Front, Power Mac 8100 / 80
922-0815	Panel, Front, Power Mac 8100 / 80 AV
922-0816	Cable, DIN7 S-Video to Composite Video, Input
922-0817	Cable, DIN7 S-Video to Composite Video, Output
922-0818	Monitor Stand, Tilt-Swivel
922-0819	Cut Sheet Feeder
922-0820	Cable, Flex, Display, FSTN
922-0821	Door, Battery Bay, Pkg. of 5
922-0823	Plug, Adapter, AC
922-0824	Cap, Modem, Pkg. of 10
922-0825	Power Adapter, 40 W, U.S.
922-0826	Shield, CD-ROM Drive, Trayloading, Pkg. of 10
922-0827	Label, FCC, Pkg. of 10
922-0828	Label, Product ID, Power Mac 6100 / 60 AV, Pkg. of 10
922-0830	Label, FCC, Pkg. of 10
922-0831	Cable, Video, External
922-0832	Bezel, Front, Performa 200
922-0833	Housing, Top Case, Performa 400
922-0837	Cable, Power Supply to Logic Board, 22-pin to 10-pin
922-0838	Cable, Power Supply to Logic Board, 22-pin

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0839	Cable, SCSI Drive, Mini-T, v1
922-0840	Cable, Floppy Drive, Mini-T, v1
922-0841	Cable, LED
922-0842	Cable, CD-ROM, Audio
922-0843	Actuator, Reset / Interrupt
922-0844	Chassis, Internal / Bottom, Mini-T (replaced by 922-0888)
922-0845	Bezel, Blank, Mini-T, v1
922-0846	Bezel, CD-ROM Drive, Mini-T
922-0847	Housing, Top (replaced by 922-1277)
922-0849	Bezel, SuperDrive
922-0850	Carrier, CD-ROM Drive
922-0851	Guard, Logic Board, Pkg. of 5
922-0852	Label, FCC, WS 95, Pkg. of 5
922-0854	Bezel, Tape Drive
922-0855	Bezel, CD-ROM Drive
922-0856	Panel, Front, WS 95, with Speaker
922-0857	Adapter, DDS-DC Tape Drive, for use with 805-5106
922-0858	Cable, SCSI Select with Switch, Tape Drive
922-0860	Label, Product ID, WS 95, Pkg. of 5
922-0862	Feet, Enclosure (Pkg. of 4)
922-0863	Label, FCC, Pkg. of 10
922-0864	Panel, Rear, Macintosh Centris 660AV
922-0865	Label, Name Plate, Macintosh Quadra 660AV (Bag of 10) (replaced by 922-0741)
922-0866	Insulator Sheet
922-0867	Microphone, Apple PlainTalk
922-0868	Label, Product ID, Macintosh Centris 660AV, Pkg. of 10
922-0870	Cable, Composite Video
922-0871	Cable, SCSI Drive, Mini-T, v2
922-0872	Cable, Floppy Drive
922-0873	Cable, CD Audio, Mini-T, v2 (replaced by 922-0724)
922-0878	Label, Product ID, Macintosh Centris 660AV, Europe, Pkg. of 10
922-0879	Clip, ESD Floppy (Bag of 10), Macintosh Centris 660AV
922-0880	Receiver, I / R
922-0881	Bezel, Front, Black

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0882	Bezel, Front, with CD, Black
922-0883	Housing, Rear, Black
922-0884	Door, I / O, Black
922-0885	Cable, ADB, Black (replaced by 590-0616)
922-0886	Power Cord, Black
922-0887	Gasket, Top Housing, Pkg. of 10
922-0888	Chassis, Internal / Bottom
922-0889	Cover, Inner
922-0890	Cover, Top
922-0893	Cable, Power, Hard Drive, Daisy Chain
922-0894	Cable, SCSI Select with Switch, 2 GB
922-0895	Screw, Net, Sems, M3x.5, Pan Head, Pkg. of 25
922-0896	Case, Leather, MessagePad 110 / 120 / 130
922-0898	Housing, Bottom
922-0899	Panel, Front
922-0900	Enclosure with Power Supply, Apple CD 300e+ (replaced by 922-1486)
922-0901	Bezel, Apple CD 300e+
922-0902	Expansion Plug, Pkg. of 5
922-0904	Label, Product ID, LC 575
922-0905	Label, Quick Reference, MessagePad 100, Pkg. of 10
922-0906	Strap, Power Supply, Pkg. of 5
922-0907	Label, Product ID, Performa 575 , Pkg. of 10
922-0908	Label, Product ID, Performa 577, Pkg. of 10
922-0909	Label, Product ID, Performa 578, Pkg. of 10
922-0910	CPU Stiffener with Feet
922-0911	Inverter, Display, PB 145B (replaced by 699-0272)
922-0912	Label, Product ID, Performa 550
922-0914	Latch Mechanism, Display, with Spring (replaced by 922-2319)
922-0917	Cover, Power Cord
922-0918	Roller, Paper Feed (replaced by 922-0612)
922-0919	Inner Turn-Chute
922-0920	Spring, Outer Turn-Chute w / Tube
922-0921	Spring, Inner Turn-Chute
922-0922	Outer Turn-Chute

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0923	Tray, Manual Feed
922-0924	Bracket, Toner Sensor
922-0925	Bracket, EP Cartridge Sensor
922-0927	Transfer Charger / Detack Assembly, LW Pro 810
922-0928	Tray, Exit
922-0929	Cleaner, Heat Roller
922-0930	Outer Turn-Chute
922-0931	Feeder, Power, Multi-Media
922-0932	Cassette, Paper, 11 x 8.5
922-0935	Labels, FCC
922-0937	Power Cord, U.S.
922-0939	Board, DAA, Europe
922-0940	Cover, Right Corner
922-0941	Cover, Power Inlet
922-0942	Cover, Rear
922-0943	Cable, DC Controller to Scanner
922-0944	Fan, Power Supply
922-0945	Cable, DC Controller to I / O Controller
922-0946	Motor, Main
922-0947	Fan, Internal
922-0948	Fan, Controller Board
922-0949	Roller, Transfer
922-0950	Drive Assembly
922-0951	Roller, Cassette Pickup
922-0952	Board, Pickup Controller
922-0953	Motor, Pickup Block
922-0954	Fuser, Roller
922-0955	Roller, Pressure
922-0956	Fuser Bulb, 110 / 115 V
922-0957	Fuser Bulb, 220 / 240 V
922-0958	Motor
922-0959	Roller, Pickup (Pkg. of 5)
922-0960	Cable, DC Controller to Laser
922-0961	Carrier, 5-Drive, 3.5"

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-0962	Port Cover, Blank, Pkg. of 5
922-0963	Port Cover, Ethernet, Pkg. of 5
922-0965	Label, Product ID, WS 6150, Pkg. of 10
922-0967	Board, PDS Terminator
922-0968	Label, FCC
922-0969	Bezel, Tape Drive, Pkg. of 5
922-0970	Panel, Front, WS 8150
922-0971	Housing, Main
922-0972	Panel, Front, with Speaker
922-0973	Carrier, Floppy Drive
922-0974	Cable, SCSI Select with Switch
922-0975	Label, FCC, WS 9150, Pkg. of 10
922-0976	Bezel, Tape Drive, Pkg. of 5
922-0977	Carrier, Tape Drive
922-0978	Bezel, CD-ROM Drive, Trayloading, Pkg. of 5
922-0979	Screw, CR REC PAN M3x.5x6
922-0981	Cable, Hard Drive, Pkg. of 5
922-0982	Cable, Flex, Floppy Drive, Pkg. of 5
922-0983	Cable, Display, Ribbon, Pkg. of 5
922-0984	Cable, Display, Inverter
922-0985	Insulator, Motherboard, Pkg. of 5
922-0986	Housing, Display
922-0987	Shield, Display, EMI, Pkg. of 5
922-0988	Bezel, Display
922-0989	Case, Top
922-0990	Case, Bottom, with Labels
922-0991	Bracket, Floppy, Left, Pkg. of 10
922-0992	Bracket, Floppy, Right, Pkg. of 10
922-0993	Housing, Top Cover
922-0994	Headphone
922-0995	Screw, M3x5mm, Thumb, Slotted, Pkg. of 25
922-0996	Cable, SCSI Select with Switch, 1 GB
922-0997	Board, DAA, U.S.
922-0998	Ball, Mouse, 25.4 mm Diameter, Gray, Pkg. of 1

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1000	Main Motor
922-1001	Fan
922-1002	Toner Cartridge Sensor Assembly
922-1003	Board, Cassette Feeder
922-1004	Board, Optional Cassette Feeder
922-1005	Solenoid, Manual Feed Pickup
922-1006	Solenoid, Cassette Pickup
922-1007	Solenoid, Cassette Feed
922-1008	Cable, Laser Scanner Motor
922-1009	Cable, HVPS & Toner Sensor
922-1010	Cable, Beam Detect
922-1011	Cover, Top
922-1012	Cover, Rear
922-1013	Cover, Left Side
922-1014	Cover, Right Side
922-1015	Manual Feed Tray
922-1016	Front Access Door Cap
922-1018	Output Tray Extension
922-1019	Manual Feed Tray Extension
922-1020	Cover Bracket, Left
922-1021	Cover Bracket, Right
922-1022	Output Tray Backstop
922-1023	Manual Feed Ramp
922-1024	Release Lever, Left
922-1025	Release Lever, Right
922-1026	Front Access Door
922-1027	Paper Delivery Guide
922-1028	Transfer Roller (replaced by 922-0640)
922-1029	Paper Feed Roller
922-1030	Pickup Roller Assembly
922-1031	Pickup Roller
922-1032	Manual Feed Pickup Plate
922-1033	LED Assembly
922-1034	Paper Separation Assembly

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1035	Paper Separation Pad
922-1036	Cable, LED
922-1037	Actuator, Manual Feed Sensor
922-1038	Manual Feed Sensor Spring
922-1039	Manual Feed Sensor
922-1040	Paper Charge Deflector
922-1041	Paper Registration Sensor
922-1042	Registration Sensor Spring
922-1043	Actuator, Paper Registration
922-1044	Front Door Ground Spring
922-1045	Power Switch Actuator Spring
922-1046	Release Lever Spring
922-1047	Fuser Heater Bulb 110 / 115V
922-1048	Fuser Heater Bulb 220 / 240V
922-1049	Fuser Heater Roller
922-1050	Gear, 27T, Fuser Heater Roller
922-1051	Actuator, Delivery Sensor
922-1052	Fuser Delivery Roller
922-1053	Fuser Paper Guide
922-1054	Fuser Pressure Roller
922-1055	Fuser Top Cover
922-1056	Temperature Sensor 110V
922-1057	Temperature Sensor 220V
922-1058	Pressure Roller Bearing
922-1059	Pressure Roller Spring
922-1060	Fuser Roller Thermoprotector
922-1061	Engine Thermoprotector
922-1062	Gear Shaft, Right
922-1063	Gear 16T, Right
922-1064	Fuse Contact
922-1065	Paper Guide Springs
922-1066	Exit Bearing
922-1067	Gear, Exit
922-1068	Static Eliminator

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1069	Drive Assembly
922-1070	Gear, Toner Cartridge Drive (replaced by 922-1069)
922-1071	Paper Delivery Sensor
922-1072	Actuator, Power Switch
922-1073	Cable, Cassette Feeder
922-1074	Gear, Front Door
922-1075	Pivot Shaft
922-1076	Gear, Left Double
922-1077	Gear, Right Double
922-1078	Toner Cartridge Sensor Cover
922-1079	Cable Guide
922-1080	I / O Controller Mount
922-1081	I / O Shield
922-1082	I / O Bracket, LWS 300
922-1083	I / O Bracket, LWS 310
922-1084	Actuator, PS601
922-1085	Cassette Pickup Roller Shaft
922-1086	Cassette Pickup Roller
922-1087	Cassette Feed Roller Shaft
922-1088	Gear 41T, Cassette
922-1089	Gear T32, Cassette
922-1090	Gear T21 / 36, Cassette
922-1091	Cassette Sizing Spring
922-1092	Cassette Grounding Spring
922-1093	Cover, Left Bottom
922-1094	Cover, Right Bottom
922-1095	Cassette Roller Bushing
922-1096	Cable, Optional Feeder Interface
922-1097	Grounding Spring, Optional Feeder
922-1098	Clip, Optional Feeder
922-1099	Connector Cover, Optional Feeder
922-1100	Cassette, Universal
922-1101	Cassette, Envelope
922-1102	Cassette, Legal

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1103	Postcard Attachment
922-1104	Cable, Adapter, 15-pin 3 row to DB-15
922-1105	High-Voltage Contact Assembly
922-1106	Label, Product ID, External 1.4 MB Floppy, Pkg. of 10 (use with 603-5121)
922-1107	Label, Product ID / FCC, PB 165, Pkg. of 10 (replaced by 076-0872)
922-1108	Bezel, Display, PB 165
922-1109	Retainer, Mouse IIB, with Hole, Pkg. of 1
922-1110	Cassette, 500 Sheet Feeder, A4
922-1111	Cassette, 500 Sheet Feeder, Letter
922-1112	Retainer Ring, Mouse II, 35mm Black
922-1113	Cable, Interconnect to Display, Pkg. of 2
922-1114	Cable, Interconnect to Display, Pkg. of 2
922-1115	Cable, Interconnect to Display, Pkg. of 2
922-1116	Fuse, 7A, Pkg. of 20
922-1117	Power Adapter, U.S. / Japan
922-1118	Board, DAA, Pacific Rim
922-1119	Label, Product ID, LC 550
922-1120	Inverter, Logic Board
922-1121	Adapter Kit, Memory
922-1123	Bracket, Hard Drive, with Spacer, Pkg. of 10
922-1124	Carrier, Hard Drive / Floppy Drive / Zip Drive
922-1125	Cable, Adapter, Multi Scan 17 to Mac II
922-1126	Cover, Front
922-1127	Drive Assembly
922-1128	Motor Assembly
922-1129	Feed Roller, Secondary
922-1130	Fan, Duct B
922-1131	Cable, Pickup Controller-DC Controller
922-1132	Label, Product ID LC 630 & LC 630 DOS Compatible, Pkg. of 10
922-1133	Carrier, Floppy Drive
922-1134	Fan, Duct A
922-1135	Monitor Stand, Tilt-Swivel
922-1136	Cover, User Controls
922-1137	Cut Sheet Feeder

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1138	Tray, Output, Ext. Guide, Pkg. of 3
922-1139	Tray, Output
922-1140	Cover, Front
922-1141	Case, Top
922-1142	Cover, Rear
922-1143	Purge Unit
922-1144	Cover, Bottom, with Feet
922-1145	Carriage Unit
922-1146	Belt, Carriage, Pkg. of 5
922-1147	Cable, Carriage Ribbon
922-1148	Motor, Carriage
922-1149	Motor, Paper Feed
922-1150	Roller, Eject, Pkg. of 2
922-1151	Roller, Pickup, Pkg. of 2
922-1152	Label, Product ID, Quadra 630, Pkg. of 10
922-1154	Chassis, Shield / Wiring Harness
922-1155	Shield, Top Cover
922-1156	Bracket, Drive Front Security
922-1157	Bezel, w / Slots for Tray CD and Manual Insert Floppy
922-1158	Panel, Left Side, Plastic
922-1159	Panel, Right Side, Plastic
922-1160	Bracket, Chassis, Rear, w / 3-inch Fan
922-1161	Cover, Top, Plastic
922-1162	Panel, Rear, Plastic
922-1163	Door, I / O, Plastic (use with 922-1164) (replaced by 922-2439)
922-1164	Fence, Logic Board (use with 922-1163) (replaced by 922-2314)
922-1166	Cover, Interface, Pkg. of 5
922-1167	Cover, Logic Board
922-1169	Label, Product ID, Performa 636, Pkg. of 10
922-1170	Label, Product ID, Performa 636 w / CD, Pkg. of 10
922-1171	Label, Product ID, Performa 638 w / CD, Pkg. of 10
922-1172	Label, Product ID, Performa 630
922-1173	Label, Product ID, Performa 630 w / CD
922-1174	Label, Product ID, Performa 635 w / CD

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1175	Speaker
922-1176	Chassis and Shield, Bottom
922-1177	Guide, Logic Board, Right, Pkg. of 10
922-1178	Cover Plate, Rear, Plastic
922-1179	Power Adapter
922-1180	Fuse, 5A, Pkg. of 20
922-1182	Door, Battery Contact, Pkg. of 10
922-1184	Plug, Bezel, CD Slot, Pkg. of 10
922-1185	Cable, SCSI, Active Terminator
922-1186	Guide, Logic Board, Left, Pkg. of 10
922-1187	Cover, Top with Glass
922-1188	Cover, Bottom
922-1189	Cover, Top
922-1190	Label, Product ID, Color OneScanner / B, Pkg. of 5
922-1191	Lid Hinge
922-1192	Plate, Carrier Shaft, Right
922-1193	Motor Carrier
922-1194	Plate, Motor
922-1195	Housing, Inside
922-1196	Plate, Shield, Left
922-1197	Cover, Optical Assembly
922-1198	Holder, Lamp
922-1199	Cover, Logic Board
922-1200	Cable, Power Supply
922-1201	Remote Control
922-1202	Power Adapter, 36 W
922-1203	Screw, Sems, M3.5x0.6x6.0, Pkg. of 25
922-1204	Cable, Hard Drive
922-1207	Cable, SCSI Select
922-1208	Cable, International Fax to Modem
922-1209	Bracket, Hard Drive, Pkg. of 5
922-1211	Label, Product ID, Performa 637 w / CD, Pkg. of 10
922-1212	Shield, Display, EMI, Pkg. of 5
922-1213	Cover, Tuner, without Hole, Pkg. of 10

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number Part Name

922-1214	Label, Product ID, Performa 6110CD, Pkg. of 10
922-1215	Label, Product ID, Performa 6112CD, Pkg. of 10
922-1216	Label, Product ID, Performa 6115CD, Pkg. of 10
922-1217	Label, Product ID, Performa 6117CD, Pkg. of 10
922-1218	Label, Product ID, Performa 6118CD, Pkg. of 10
922-1219	Case, Ink Tank
922-1220	Cable, Video
922-1222	Board, DAA, Japan
922-1224	Ring, Rubber, Pickup Roller, Pkg. of 5
922-1226	Housing, Display, Duo 210 / 230, CPRC / International Only
922-1227	Housing, Display, Duo 250 / 280, CPRC / International Only
922-1228	Cable, Display, Duo 210 / 230, CPRC / International Only
922-1229	Cable, Display, Duo 250, CPRC / International Only
922-1230	Bezel, Blank, Tape Drive, Pkg. of 5
922-1231	Cover, Top, Performa 6100 Series
922-1233	Fan, Lower
922-1234	Screw, Tap, SEM, 6-32x3 / 8 (Pkg. of 10)
922-1237	Cable, Audio, DOS Compatibility, Pkg. of 10
922-1238	Cable, Hard Drive to Power Adapter, Pkg. of 10
922-1239	Screw, M3x6mm, Pan, with Washer, Pkg. of 25
922-1240	Standoff, DOS Card, 11mm, Pkg. of 25
922-1241	Spring, Battery Eject, Pkg. of 20
922-1242	Retainer, Mouse IIB, with Hole, Pkg. of 10 - M
922-1243	Cable, Hard Drive, Yellow LED
922-1244	Cable, LED, 400 MB Hard Drive
922-1245	Cable, Hard Drive, LED, Amber
922-1247	Cable, SCSI Select, 400 MB Hard Drive
922-1248	Cable, SCSI Select, 230 / 500 MB Hard Drive
922-1250	Switch, SCSI Select Assembly
922-1251	Label, Product ID, PB 520, Pkg. of 10
922-1252	Label, Product ID, PB 520c, Pkg. of 10
922-1253	Label, Product ID, PB 540, Pkg. of 10
922-1254	Label, Product ID, PB 540c, Pkg. of 10
922-1255	Panel, Front

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1258	Label, Product ID, Power Mac 6100 / 66, Pkg. of 10
922-1259	Label, Product ID, Power Mac 6100 / 66 AV, Pkg. of 10
922-1260	Actuator, Reset / Interrupt, Pkg. of 10
922-1261	Ethernet, 5 Port Hub (replaced by 661-0280)
922-1262	Battery, Lithium, 3.6V, without Leads
922-1263	Heat Sink, 68040 Processor, Pkg. of 10
922-1264	Fastener, Hook and Loop Macintosh Processor Upgrade (Pkg. of 5)
922-1267	Label, Product ID, WS 8150, Pkg. of 10
922-1270	Label, Product ID, Power Mac 8100 / 100, Pkg. of 10
922-1271	Label, Product ID, Power Mac 8100 / 100 AV, Pkg. of 10
922-1272	Label, Product ID, Power Mac 8100 / 110, Pkg. of 10
922-1273	Label, Product ID, Power Mac 7100 / 80, Pkg. of 10
922-1274	Label, Product ID, Power Mac 7100 / 80 AV, Pkg. of 10
922-1275	Screw, Hard Drive, Pkg. of 10
922-1276	Gear, Q, Motor Drive
922-1277	Housing, Top, with Dome
922-1278	Cap, PCMCIA Expansion Module, Pkg. of 5
922-1279	Clip, Ground, Logic Board, Pkg. of 25 (replaced by 922-2320)
922-1281	Power Adapter, with Cable, 110 V
922-1282	Power Adapter, with Cable, 220 V
922-1284	Connector and Cable Assembly, Logic Board, For Use with 661-1152, Performa / LC 500
922-1285	Battery Cover, MessagePad 120, Pkg. of 5
922-1286	Standoff, Sound Card, 10mm, Pkg. of 25
922-1287	Standoff, 10 mm, M3 Thread, Pkg. of 25
922-1288	Cable, DOS Compatible, 26-pin, Pkg. of 5
922-1289	Cable, DOS Compatible, 16-pin, Pkg. of 5
922-1290	Cover, Front
922-1291	Carriage Unit
922-1292	Cover, Pickup Trim
922-1294	Cassette Size Cover
922-1295	Multipurpose Tray Extension Cover
922-1296	Carousel Knob
922-1297	Carousel Knob Bushing
922-1298	Toner Carousel Interlock

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1299	Power Switch Button
922-1300	Panel, Toner Carousel Guide
922-1301	Cover, Rear
922-1302	Cover, Left
922-1303	Cover, Top
922-1304	Cover, Power Switch
922-1305	Cover, Pickup Block
922-1306	Cover, Air Filter
922-1307	Air Filter
922-1308	Toner Sensor Holder
922-1310	Density Sensor Assembly
922-1311	Board, Cassette Pickup Assembly
922-1312	Cover, Multipurpose Door
922-1313	Guide, Multipurpose Width
922-1315	Toner Release Assembly
922-1316	Carousel, Manual Rotary Assembly
922-1317	Door, Front
922-1318	Cover, Top Access Door
922-1319	Board, I / O Interconnect
922-1320	Power Switch
922-1321	Cable, Fuser Interconnect
922-1322	Multipurpose Pickup Assembly
922-1323	Cassette Pickup Motor Cover
922-1324	Multipurpose Pickup Assembly Cover
922-1325	Cable, Door Switch
922-1326	Cable, DC Controller Harness, Rear
922-1327	Cable, DC Controller Harness, Front
922-1328	Cable, Toner Sensor
922-1329	Cable, Carousel Sensor
922-1330	Cable, Solenoid Harness
922-1331	Cable, Cassette Pickup
922-1332	Cable, High-Voltage
922-1333	Cable, Density Control Panel
922-1334	Printer Drive Assembly

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1335	Drum Drive Assembly
922-1336	Cleaning Drive Assembly
922-1337	Discharge Roller Drive Assembly
922-1338	Attraction Roller Drive Assembly
922-1339	Cover, Fuser Access
922-1340	Paper Delivery Assembly
922-1341	Delivery Drive Assembly
922-1342	Disposal Box Cover Assembly
922-1343	Cable, Ribbon, J110-J401
922-1344	Cable, Ribbon, J112-J2007
922-1345	Cable, Ribbon, J108-J802
922-1346	Cable, Ribbon, J103-J501
922-1348	Fan, Fuser
922-1349	Fan, Main
922-1350	Fan, I / O Controller
922-1351	Switch, Door, SW2
922-1352	Photo-Interruptor 1
922-1353	Photo-Interruptor 2
922-1354	Separation Discharge Assembly
922-1355	Board, Sheet Feeder Controller
922-1356	Sensor, Cassette Sheet Feeder
922-1357	Cable, Main Sheet Feeder
922-1358	Pickup Assembly, Sheet Feeder, Front
922-1359	Pickup Assembly, Sheet Feeder, Rear
922-1360	Roller Assembly, Sheet Feeder, Front
922-1361	Feed Roller, Sheet Feeder
922-1362	Roller Assembly, Sheet Feeder, Rear
922-1363	Transfer Drum Lever
922-1364	Transfer Drum Knob
922-1365	Cable, Cassette Size
922-1366	Card, Adapter, DOS Compatible
922-1368	Transfer Drum Cleaning Assembly
922-1369	Toner Carousel Assembly
922-1370	Motor, Main, M2

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1371	Lens, Close-Up
922-1372	Spacer, PGA, 601 Processor Upgrade
922-1373	Bezel, CD-ROM Drive, Blank, Pkg. of 5
922-1374	Fan / Bracket Assembly
922-1375	Foot, Rubber, MessagePad 120, Pkg. of 50
922-1378	Adapter, Expansion, Pkg. of 5
922-1379	Cable, Power, Hard Drive / CD-ROM / Fan
922-1380	Cable, Sensor Harness
922-1381	Screw, SEMS, 6x32, PN, Pkg. of 25
922-1382	Screw, PAN, M3x.5x8, Pkg. of 25
922-1384	Cover
922-1385	Door, Top
922-1386	Intake Guide
922-1387	Status Panel
922-1388	Board, Front Panel Display
922-1389	Speaker, Rev. A
922-1390	Chassis, Rev. A
922-1391	Fan
922-1392	Microphone, Rev. A
922-1394	Label, Product ID, Performa 5200 CD, Pkg. of 25
922-1395	Housing, Rear, Rev. A
922-1396	Plug, Screw Cover, Rear Housing, Pkg. of 25
922-1397	Door, I / O
922-1398	Bezel, Drive and Control
922-1399	Monitor Stand, Tilt-Swivel
922-1400	Bezel, Front, Rev. A (replaced by 652-0042)
922-1403	Solenoid 1
922-1404	Solenoid 2
922-1406	Solenoid 3
922-1407	Sensor, Oil Assembly
922-1413	Bumper, Display, Pkg. of 10
922-1415	Board, Infrared
922-1417	Power Adapter
922-1418	Battery, Backup, Pkg. of 5

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1419	Cable, Flex, Hard Drive
922-1420	Cable, Flex, Trackpad
922-1421	Cable, Flex, Infrared
922-1422	Board, PCMCIA Switch, Pkg. of 5
922-1424	Actuator, Sleep, Pkg. of 10
922-1425	Heatsink, CPU, Pkg. of 10
922-1426	Bracket, Hard Drive, Pkg. of 2
922-1427	CPU Stiffener (replaced by 922-2666)
922-1428	Button, Trackpad, Pkg. of 5 (replaced by 922-2670)
922-1429	Door, PCMCIA Bay, Pkg. of 10
922-1430	Retainer, Door, O-Ring, Pkg. of 10
922-1431	Nameplate, Bezel, Pkg. of 10
922-1432	Drawer, PCMCIA
922-1433	Shield, Input / Output, EMI, Pkg. of 10
922-1434	Leaf Spring, Heatsink, Pkg. of 10
922-1435	Shield, Hard Drive, EMI, Pkg. of 5
922-1436	Window, Infrared, Pkg. of 10
922-1437	Actuator, Reset, Pkg. of 10
922-1438	Door, Input / Output, Pkg. of 10
922-1439	Cable, Display, CTFT, 10.4", Hosiden
922-1440	Cable, Display, CTFT, 10.4", Sharp
922-1441	Cable, Display, CFSTN, 10.4", Sharp
922-1443	Cable, Display, CFSTN, 10.4", Sanyo / Torisen
922-1444	Cable, Display, MFSTN, 9.5", Casio
922-1445	Board, Inverter, CPRC / International Only
922-1446	Nameplate, Product ID, PB 5300c, Pkg. of 10
922-1447	Nameplate, Product ID, PowerBook 5300cs, Pkg. of 10
922-1448	Nameplate, Product ID, PowerBook 5300, Pkg. of 10
922-1450	Bumper, Display, Pkg. of 10
922-1451	Power Cord, AC
922-1452	Monitor Stand, Tilt-Swivel
922-1453	Housing, Rear
922-1455	Bezel, Front
922-1457	Cover, Bottom

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1458	Adapter, Macintosh to VGA
922-1459	Board, Front Panel Control
922-1460	Chassis, Internal
922-1461	Bezel, I / O
922-1462	Snaps, Bezel, Pkg. of 10
922-1463	Bezel, FD
922-1464	Bezel, CD / FD
922-1465	Shield, Display, EMI, Pkg. of 5
922-1466	Feet, Rubber, Pkg. of 10
922-1467	Shield, Frame, Power Supply
922-1468	Shield, EMI, Analog Board
922-1469	Roller, Cut Sheet Feeder
922-1470	Label, Product ID, Pkg. of 25 (replaced by 922-1626)
922-1471	Housing, Rear (replaced by 922-1615)
922-1472	Speaker
922-1473	Washer, Rubber, Pkg. of 25
922-1474	Bezel, Monitor, LC 580 Series
922-1475	Power Adapter, with Cable, U.K.
922-1476	Shield, Plate, EMI
922-1477	Guide, Analog Card, Right, Pkg. of 10
922-1478	Guide, Analog Card, Left, Pkg. of 10
922-1479	Cover, Top
922-1480	Cover, Upper Case (Replaced by 922-2326)
922-1481	Cable, Ribbon, Pkg. of 5
922-1482	Case, Bottom
922-1483	Lock Plate, Pkg. of 5
922-1484	Label, Product ID, Performa 640 with DOS, Pkg. of 25
922-1486	Enclosure with Power Supply, Apple CD 600e Plus
922-1487	Power Adapter, with Cable, Australia
922-1488	Case, Ink Tank
922-1489	Printer Loopback Test Plug
922-1490	Label, Product ID, Performa 580 CD, Pkg. of 10
922-1492	Power Adapter, with Cable, Japan
922-1493	Keyboard Slip Cover

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1494	Bracket, Hard Drive
922-1495	Sound Enclosure
922-1496	Cassette, Universal
922-1497	Cassette, A4
922-1498	Cassette, Letter
922-1500	Screw, Double Sems, M3x0.5 Pan, Pkg. of 10
922-1501	Screw, Shoulder, Pkg. of 10
922-1502	Microphone
922-1503	Cable, Ground, Braided, 300mm, Pkg. of 10
922-1504	Cable, Ground, Braided, 120mm, Pkg. of 10
922-1506	Cleaning Brush
922-1507	Lever, Test Print
922-1508	Bezel, Front, DOS Compatible
922-1509	Board, Intermediate
922-1510	Label, Product ID, Performa 6200, Pkg. of 25
922-1511	Board, On-Screen Display Switches
922-1513	Cable, Monitor Adjustment
922-1514	Cable, 1284 Parallel
922-1515	Label, Product ID, Performa 6116, Pkg. of 25
922-1516	Screw Cover, Rear Housing Plug, Pkg. of 10
922-1517	Label, FCC, Pkg. of 10
922-1518	Label, FCC, Pkg. of 10
922-1519	Label, FCC, Pkg. of 10
922-1520	Cable, External Video Connector
922-1521	Cable, Integrated, Power / Video, Desktop Camera
922-1523	Fence, Main Logic Board
922-1524	Cable, Hard Drive / CD-ROM Drive, SCSI
922-1525	Fan Assembly (replaced by 922-2732)
922-1527	Panel, Rear
922-1528	Chassis, Internal
922-1529	Housing, Top
922-1530	Guard, Logic Board
922-1532	Label, FCC, Power Macintosh 9500, Pkg. of 10
922-1533	Label, Product ID, Power Macintosh 9500 / 120, Pkg. of 10

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1534	Bezel, Blank, Pkg. of 5 (replaced by 922-0620)
922-1535	Panel, Front, without Bezels
922-1536	Panel, Rear
922-1537	Chassis, Internal
922-1539	Guard, Logic Board
922-1542	Panel, Front, without Bezels
922-1543	Actuator, Power, Pkg. of 10
922-1544	Label, FCC, Power Macintosh 8500, Pkg. of 10
922-1545	Label, Product ID, Power Macintosh 8500 / 120, Pkg. of 10
922-1546	Toner Disposal Box
922-1549	Syringe
922-1551	Cable, Power
922-1552	Cable, Display, CTFT, 10.4", Sharp, CPRC / International Only
922-1553	Board, Interconnect, CPRC / International Only
922-1554	Cable, Interconnect to Inverter, CPRC / International Only
922-1558	Toner Sensor, Emitter
922-1559	Toner Sensor, Receiver
922-1561	Sensor, Temperature / Humidity
922-1562	Density Control Panel
922-1565	Door, I / O, Plastic (use with 922-1567)
922-1567	Fence, Logic Board, For Use with 922-1565 (replaced by 922-2314)
922-1568	Cable, 34-Pin-to-34-Pin, MPEG Board-to-Video-In Board, Rev. A or B, Pkg. of 5
922-1569	Cable, Temperature / Humidity
922-1570	Board, Microprocessor Control, Rev. B
922-1571	Bracket, Processor Fan
922-1572	Panel, Front, with Speaker, WS 9150 / 120
922-1573	Label, FCC, WS 9150 / 120, Pkg. of 10
922-1574	Cable, SCSI
922-1575	Label, Product ID, WS 8150 / 110, Pkg. of 10
922-1576	Label, FCC, Workgroup Server 8150 / 110, Pkg. of 10
922-1577	Label, Product ID, WS 6150 / 66, Pkg. of 10
922-1578	Label, FCC, WS 6150 / 66, Pkg. of 10
922-1579	Cable, SCSI Select, 1 GB
922-1580	Photoconductor Tray

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1581	Transfer Drum Shipping Screw
922-1582	Cover, Clutch, Pkg. of 5, CPRC / International Only
922-1583	Cover, Base, Center, Pkg. of 5, CPRC / International Only
922-1584	Door, Rear, Pkg. of 5, CPRC / International Only
922-1585	Cap, Modem, Pkg. of 5, CPRC / International Only
922-1586	Cover, Access, Display, CPRC / International Only
922-1587	Carrier, Trackpad, Pkg. of 5, CPRC / International Only
922-1588	Foot, Rubber, Pkg. of 10
922-1589	Bumper, Display, Pkg. of 5, CPRC / International Only
922-1590	Ozone Filter
922-1591	Label, Product ID, Power Macintosh 9500 / 132, Pkg. of 10
922-1592	Cotton Gloves, 6 Pair
922-1594	Battery Attachment, Portable
922-1595	Brush, Cleaning, Pkg. of 5
922-1596	Cable, Audio
922-1597	Board, Sound Control with Buttons
922-1598	Tool, Ambient Light
922-1599	Board, Sound (Replaced by 922-3547)
922-1600	Speaker, 77mm, 3W, 13 ohm
922-1602	Bezel, Sound Enclosure
922-1610	High-Voltage Separation Assembly
922-1614	Cable, Revolution Clutch
922-1615	Housing, Rear
922-1616	Fan, Processor
922-1617	Cable, Display, CTFT, Color, VGA, 10.4", Toshiba
922-1618	Cable, Display, CTFT, SVGA, 10.4", Toshiba
922-1619	Cable, Display, MFSTN, 9.5", Sharp
922-1621	Strain Relief Plate
922-1623	Sensor Assembly, Cassette Sizing
922-1624	Label, Product ID, Performa 588, Pkg. of 25
922-1626	Label, Product ID, Pkg. of 25
922-1627	Label, Product ID, Performa 5200CD
922-1628	Cover, Blank, PCI Card, Pkg. of 10
922-1629	Label, FCC, Pkg. of 10

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1630	Label, Product ID, Power Macintosh 7200 / 90
922-1632	Board, Floppy Drive
922-1633	Handset, ISDN, H.320, Nubus Card
922-1634	Cable, ISDN Handset, H.320, Nubus Card
922-1635	Cable, Flat, QuickTime Conferencing
922-1636	Cable, Floppy Drive, Pkg. of 5
922-1637	Cable, Hard Drive / CD-ROM Drive, SCSI
922-1638	Cable, CD-ROM Audio, Pkg. of 5
922-1639	Speaker
922-1640	Housing, Speaker
922-1641	Chassis, Bottom
922-1642	Housing, Top
922-1643	Column, Top Cover Support
922-1644	Actuator, Power, Pkg. of 10
922-1646	Label, FCC, Pkg. of 10
922-1647	Label, Product ID, Power Macintosh 7500 / 100, Pkg. of 10
922-1648	Shield, Floppy / Hard Drive, Pkg. of 5
922-1649	Bezel, CD-ROM Drive, Pkg. of 5
922-1650	Shield, CD-ROM Drive, Pkg. of 5
922-1651	Bezel, Blank, 3.5" Drive Bay, Pkg. of 5
922-1652	Shield, Blank, 3.5" Drive Bay, Pkg. of 5
922-1653	Bezel, Blank, 5.25" Drive Bay, Pkg. of 5
922-1654	Shield, Blank Bezel, 5.25" Drive Bay, Pkg. of 5
922-1655	Panel, Rear
922-1656	Latch, Internal Chassis, Pkg. of 10
922-1657	Chassis, Drive
922-1658	Rail, Drive, Pkg. of 10
922-1659	Foot, Pkg. of 10
922-1660	Cover, Expansion Card (replaced by 922-3221)
922-1661	Support Foot, Internal Chassis, Pkg. of 10
922-1662	Cover, Left
922-1663	Nameplate, Product ID, PowerBook 190, Pkg. of 10
922-1664	Nameplate, Product ID, PowerBook 190cs, Pkg. of 10
922-1665	Label, FCC, Pkg. of 10

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1666	Insulator, Display, EMI, 9.5"
922-1667	Insulator, Display, EMI, 10.4"
922-1668	Label, FCC, Pkg. of 10
922-1669	Cover, Video Expansion, Pkg. of 10
922-1670	Cover, Sound-In, Pkg. of 10
922-1671	Screw, M3.5x5MM, Pkg. of 10
922-1672	Screw, M3.1x10, Torx-T10, Pkg. of 10
922-1673	Board, Inverter
922-1674	Cable, Floppy Drive, Pkg. of 10
922-1675	Screw, Tap, Pan, Torx T-8, M4x1.8x12 mm, Pkg. of 10
922-1676	Screw, Tapping, Button Head, Torx T-8, Pkg. of 10
922-1677	Cable, Microphone, 2-Wire
922-1678	Screw, Tap, M4x25 mm, Pan, Torx T-15, Pkg. of 10
922-1679	Cable, Sound Board to Intermediate, 9-pin
922-1680	Screw, Tap, M4x6mm, Pan, Pozi, Pkg. of 10
922-1681	Screw, Tap, Pan, M3x1.06x4 mm, Pkg. of 10
922-1682	Screw, Hard Drive Bracket to Hard Drive, MacFet M3x.5x4
922-1683	Screw, Floppy Bracket to Floppy Drive, PH M2xM4
922-1685	Cap, Battery, Pkg. of 5
922-1686	I / O Cover, MessagePad 120 with 2.0
922-1687	I / R Cover, MessagePad 120 with 2.0
922-1688	On / Off Knob, MessagePad 120 with 2.0
922-1689	Board, Inverter
922-1690	Label, Product ID / FCC, PB 180, Pkg. of 10 (replaced by 076-0872)
922-1691	Foot, Elevation, Right
922-1692	Ball, Mouse, 21.9 mm Diameter, Black
922-1693	Foot, Platinum, Pkg. of 5
922-1694	Foot, Platinum, Pkg. of 5
922-1695	Rod, Support, CSF Output Tray, Pkg. of 2
922-1697	I / O Door
922-1698	Retainer, Trackball, Pkg. of 5
922-1699	Retainer Ring, Trackball, Pkg. of 5
922-1700	Door, Battery
922-1701	Ball, Trackball, Pkg. of 5

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1702	Ball, Trackball, Pkg. of 2
922-1704	Insulator, Power Supply, Pkg. of 5
922-1706	Insulator, Hard Drive, 1.3 & 2 GB, Pkg. of 5
922-1708	Cable, Status Panel
922-1709	Clamp, Fuser Oil Bottle
922-1711	Cable, Ribbon J111-J402
922-1712	Cover, Density Panel
922-1713	Gear, Toner Press Drive
922-1714	Transfer Drum Press Assembly
922-1715	Cover, Lower, Status Panel
922-1717	Stopper, Carousel Knob
922-1718	Front Door Hinge Strap
922-1719	Power Cord, U.S.
922-1720	Cover, Video Out, Pkg. of 5
922-1721	Clip, EMI, Pkg. of 5
922-1722	Panel, Blank, AV Module, Pkg. of 5
922-1723	AV Module, Video-In
922-1725	Label, Product ID, Peforma 6230CD, Pkg. of 25
922-1726	Label, Product ID, Peforma 6220CD, Pkg. of 25
922-1727	Label, Product ID, Performa 6216CD, Pkg. of 25
922-1728	Label, Product ID, Performa 6218CD, Pkg. of 25
922-1729	Lamp, 24-bit
922-1730	Support Arm, Internal Chassis, Pkg. of 5
922-1731	Tape, Kapton
922-1732	Shield, Display Diaper, EMI, CPRC / International Only
922-1733	Label, Product ID / FCC, PB 160, Pkg. of 10 (replaced by 076-0872)
922-1734	Shield, Display Bib, EMI, CPRC / International Only
922-1735	Cable, Display, 10.4", Toshiba, CPRC / International Only
922-1736	Fan, Auxillary, For Use With 661-0979 and 661-1180 Only
922-1738	Label, Product ID, Performa 5215CD, Pkg. of 25
922-1739	Retainer, PCI Card
922-1740	AV Module, Video In / Out
922-1741	Label, Product ID, Performa 631CD, Pkg. of 25
922-1755	Label, Product ID, PB 170, Pkg. of 10 (replaced by 076-0870)

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1780	Monitor stand, Tilt-Swivel
922-1781	Cable, Sound-Out
922-1786	Cover, User Controls
922-1790	Screw Cover, Adhesive Disk, Pkg. of 10
922-1797	Label, Product ID, PB 145, Pkg. of 10 (replaced by 076-0870)
922-1799	Label, Product ID, PB 140, Pkg. of 10 (replaced by 076-0870)
922-1800	Push Button, PCB
922-1801	Speaker Assembly
922-1802	Microphone, Internal
922-1803	Fan Assembly
922-1804	Cable, Flat Assembly
922-1806	Carrier, Hard Drive, 3.5" (replaced by 922-0621)
922-1807	Carrier, SuperDrive
922-1808	Shield, SuperDrive
922-1809	Chassis
922-1810	Shield, Bottom
922-1811	Bezel, Front
922-1813	Plate, Name, Pkg. of 10
922-1814	Housing, Rear
922-1815	Door, I / O
922-1816	Coil, Degauss
922-1818	Bracket, Degauss, Pkg. of 10
922-1819	Screw, Tap, 4-20x.375, Pkg. of 10
922-1820	Adapter, CD / HD Connector
922-1821	Adapter, CD Connector, for use with 661-0023
922-1822	Adapter, CD Audio
922-1823	Adapter, SuperDrive Connector
922-1825	Board, Front Panel Control
922-1826	Speaker with Cable
922-1827	Door, I / O
922-1833	Bezel, Drive, LC 520, FD Auto, CD 300i
922-1834	Bezel, Front
922-1835	Housing, Rear
922-1840	Housing, Rear

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1841	Monitor Stand, Tilt-Swivel
922-1842	Bezel, Monitor, with Power & Adjustment Buttons
922-1843	Cover, Control Panel
922-1844	Fence, Rear with Internal Video and AC Inlet
922-1845	Knobs, Contrast and Brightness, Pkg. of 2
922-1846	Switch, On / Off, with Spring
922-1847	Latch, Control Panel Cover
922-1849	Label, Product ID, Power Mac 7200 / 75
922-1850	Shield, EMI, Interconnect, Display, Japan Only
922-1856	IC, ROM, IOP, Rev. 2.0 (replaced by 922-2458)
922-1857	Bezel, Front, Rev. B
922-1858	Speakers, Rev. B, with Enclosures
922-1861	Housing, Rear, Rev. B
922-1863	Cable, Trackpad
922-1864	Cable, Hard Drive, IDE
922-1865	Cable, Display
922-1866	Case, Top
922-1867	Shield, Display, EMI, Pkg. of 5
922-1868	Button, Trackpad, Pkg. of 10
922-1869	Carrier, Trackpad, Pkg. of 10
922-1870	Heatsink, Logic Board (replaced by 922-2212)
922-1871	Screw, Torx, K22x.98Px5.5mm, Pkg. of 10
922-1873	Screw, Torx, M22x.98Px8mm, Pkg. of 10
922-1874	Spacer, Video Board, Pkg. of 10
922-1877	Cable, Video, External
922-1878	Power Cord, 110 V
922-1879	Label, Product ID / FCC, PB 165c, Pkg. of 10 (replaced by 076-0872)
922-1890	Shield, Trackpad, Pkg. of 10
922-1891	Cover, Nubus Slot
922-1892	Nameplate, Product ID, PowerBook 5300ce, Pkg. of 10
922-1893	Cable, SCSI Select, Conner
922-1895	Gasket, EMI Shield, Leaf Seal, Pkg. of 10
922-1897	Label, Product ID, Performa 6300CD, Pkg. of 25
922-1899	Label, Product ID, Power Macintosh 5300 / 100 LC, Pkg. of 25

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1902	Bezel
922-1903	Cut Sheet Feeder
922-1904	Cable, Carriage, Ribbon
922-1905	Power Adapter, 110 V
922-1906	Motor, Paper Feed
922-1907	Motor, Carriage
922-1908	Cover, Front
922-1909	Case, Top
922-1910	Cover, Rear
922-1911	Cover, Bottom with Feet
922-1912	Carriage Unit
922-1913	Roller, Eject
922-1914	Roller, Pickup
922-1915	Cover, Logic Board
922-1916	Cable, Trackpad
922-1918	Cover, Rear
922-1919	Case, Top
922-1920	Roller, Eject
922-1921	Roller, Pickup
922-1922	Belt, Carriage, Pkg. of 5
922-1923	Motor, Carriage
922-1924	Motor, Paper Feed
922-1925	Cover, Bottom
922-1926	Cover, Front
922-1927	Carriage Unit
922-1928	Cover, I / F, Pkg. of 5
922-1929	Cable, DC to Logic Board
922-1930	Cover, Top, with Hinge
922-1931	Cover, Glass
922-1932	Cover, Glass
922-1933	Clip, Glass Holders, Pkg. of 10
922-1934	Shield, Logic Board
922-1935	Cable, LED
922-1936	Board, Inverter, Power Supply

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1937	Cable, Home Position Sensor
922-1938	Motor, Drive
922-1941	Bushing, Feed Roller
922-1942	Label, Product ID, Performa 5300CD, Pkg. of 25
922-1943	Cover, Main
922-1944	Cover, Left
922-1945	Cassette, Paper 250, Unviersal
922-1946	Cassette Size Sensor Assembly
922-1947	Cable, Cassette Size Sensor to Solenoid
922-1948	Cable, Cassette Size Sensor to Manual Feed
922-1949	Registration Roller Assembly
922-1950	Solenoid, Paper Deflector
922-1951	Paper Deflector Guide
922-1953	Pickup Drive Assembly
922-1954	Solenoid, Cassette Feed
922-1955	Motor, Pickup
922-1956	Registration Chute Assembly
922-1957	Bearing, Feed
922-1959	Cassette Pickup Roller, Pkg. of 2
922-1960	Cassette Paper-Present Actuator
922-1961	Preregistration Pinch Roller Assembly
922-1962	Solenoid, Manual Feed
922-1963	Clutch Gear Bearing, Pkg. of 10
922-1964	Gear, Manual Feed Clutch
922-1965	Manual Feed Paper-Present Sensor
922-1967	Manual Feed Pickup Roller
922-1968	Separation Pad Assembly
922-1969	Roller, Fuser Heater
922-1970	Fuser Heater Bulb, 110 V
922-1971	Fuser Heater Bulb, 220 V
922-1973	Fuser Exit Sensor
922-1974	Delivery Roller Shaft
922-1976	Mirror Assembly
922-1977	Main Drive Assembly

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-1979	Drive Transfer Assembly
922-1981	Transfer Roller Assembly
922-1984	Cable, Laser / Scanner
922-1985	Cable, Start-of-Scan
922-1986	Fan
922-1988	Cable, Exit
922-1989	Static Eliminator
922-1990	Foot Kit, Pkg. of 4
922-1991	Cover Interlock Actuator Assembly
922-1992	Cassette Guide, Right
922-1998	Board, Cassette Size Sensor, 500 Sheet Feeder
922-1999	Turn Roller Assembly, Pkg. of 10 (replaced by 076-0616)
922-2000	500 Sheet Paper Cassette
922-2001	Assembly, Duplexer, Vertical
922-2002	Assembly, Duplexer, Horizontal
922-2006	Button, Brightness, Display, Pkg. of 10
922-2008	Handset, ISDN, H.320, PCI Card (replaced by 922-2525)
922-2011	Bezel, with Slots for Tray CD and Manual Insert Floppy, "PowerPC"
922-2012	Bracket, Security Lock, Rev. B
922-2013	Label, Product ID, Performa 6214CD, Pkg. of 25
922-2014	Power Adapter, Japan
922-2015	Power Adapter, Europe
922-2016	Power Adapter, Australia
922-2017	Power Adapter, UK
922-2018	Label, Product ID, LC 580, Pkg. of 25
922-2019	Cable, RCA to RCA, 6 feet
922-2020	Cable, S-Video to Power, 6 feet, Video Conferencing
922-2021	Cable, Video Interconnect
922-2023	Cable, Video / ADB
922-2024	Glass with Graduated Scale
922-2025	Label, FCC, Quadra 840AV, Pkg. of 10
922-2026	Panel, Front, Quadra 840AV
922-2027	Panel, Rear, Macintosh Quadra 840AV
922-2028	Label, Product ID, Centris 650, Pkg. of 10

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-2029	Cover, Screw, Display, Pkg. of 100
922-2030	Actuator, On / Off, Mini-T, v2
922-2031	Housing, Top Case, Performa 405
922-2032	Housing, Top Case, Performa 430
922-2033	Housing, Top Case, Performa 450
922-2034	Gasket, Modem / Switch, Pkg. of 100
922-2035	Cable, Print Pack
922-2036	Stylus, MessagePad & MessagePad 100, Pkg. of 10
922-2037	Battery Cover, PlasticMessagePad & MessagePad 100, Pkg. of 5
922-2038	Battery Holder, 4AAA
922-2040	Cover, Vinyl, MessagePad & MessagePad 100, Pkg. of 5
922-2042	Gear, Motor, Pkg. of 5
922-2043	Chassis, Rev. B
922-2044	Microphone, Rev. B
922-2045	Pad, Motor Damper, Pkg. of 5
922-2046	Bracket, Motor, Pkg. of 5
922-2047	Paper Separator, ADF
922-2048	Delivery Guide Sheet, ADF
922-2049	Deflector, ADF
922-2055	CPU Stiffener Kit
922-2056	Label, Product ID, Performa 6205, Pkg. of 25
922-2057	Cable, Analog to Power Supply
922-2058	Cable, Analog to Power Supply P703 to CN7, 10-Pin
922-2059	Support Post, Pkg. of 5
922-2061	Cover, Logic Board
922-2063	Purge Unit
922-2064	Cable, Carriage Ribbon
922-2065	Paper Support
922-2066	Shield, EMI, Top Plate, Rev. B
922-2067	Cable, Analog to Power Supply P704 to CN7, 10-Pin
922-2068	Label, Product ID, Multiple Scan 20 Display, Rev. B
922-2069	Label, Product ID, Performa 5320CD, Pkg. of 10
922-2077	Display, LCD
922-2078	Board, Interconnect, Powerplane

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-2079	Board, Interconnect, Mezzanine
922-2080	Board, Interconnect, SCSI Backplane
922-2081	Board, Interconnect, NMI / Reset-Power
922-2082	Board, Interconnect, Drive, Narrow, 50-pin
922-2083	Board, Interconnect, Drive, Wide, 68-pin
922-2084	Locks, Front & Rear, with Keys
922-2085	Cable, Mezzanine-to-Front Panel
922-2086	Cable, NMI Reset Switch
922-2087	Cable, LCD / Speaker / Keylock
922-2088	Cable, AC Interlock, Receptacle and Ground
922-2089	Cable, Rear Keyswitch
922-2090	Cable, Power Backplane to Logic Board
922-2091	Cable, Power Backplane to SCSI Backplane
922-2092	Cable, Fan to Logic Board
922-2093	Cable, Fan to SCSI Backplane
922-2094	Cable, Mezzanine to Floppy Drive
922-2095	Cable, SCSI, Mezzanine to SCSI Backplane, 68-pin, 10"
922-2096	Cable, SCSI, Mezzanine to SCSI Backplane, 68-pin, 20"
922-2097	Cable, Power, SCSI
922-2098	Cable, Hard Drive, LED
922-2099	Cable, SCSI ID, Type 4
922-2100	Cable, SCSI, Flat Ribbon, 68-Pin
922-2101	Cable, SCSI, Flat Ribbon, 50-pin
922-2102	Cable, SCSI ID, Type 1
922-2103	Cable, SCSI ID, Type 2
922-2104	Cable, SCSI ID, Type 3
922-2105	Cable, Rear Drives, Power
922-2106	Cable, Rear Drives, SCSI
922-2107	Cable, Rear Drives, SCSI ID
922-2108	Cover, Top
922-2109	Panel, Side, Left
922-2110	Panel, Side, Right
922-2111	Bezel, Front
922-2112	Door, Front

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-2113	Shelf, Top
922-2114	Shelf, Bottom
922-2115	Shroud, Chassis
922-2116	Shaft, Lock
922-2117	Link, Lock
922-2118	Spring, Torsion, Pkg. of 10
922-2119	Door, Base
922-2120	Base, w / Wheels
922-2121	Wheel
922-2122	Lever, Brake
922-2123	Chassis, Main
922-2124	Duct, Left
922-2125	Plate, Rear, Lower
922-2126	Panel, Rear, I / O
922-2127	Cage, Fan
922-2128	Guide, Processor Card
922-2129	Carrier, Logic Board
922-2130	Handle, Logic Module
922-2131	Panel, Rear
922-2132	Rail, Guide
922-2133	Slide, Drawer
922-2134	Clip, Ground
922-2135	Spring, Ground, Logic Board
922-2136	Shield, EMI, Power Cover
922-2137	Bracket, Rear Hard Drives
922-2138	Bracket, Floppy Drive
922-2139	Standoff, Pkg. of 10
922-2140	Label, FCC, Network Server 500 / 700
922-2141	Nameplate, Product ID, Apple Network Server 700 / 150
922-2142	Fan
922-2143	Bezel, Floppy Drive
922-2144	Carrier, Drive
922-2145	Bezel, Blank
922-2147	Bezel, CD-ROM Drive

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number Part Name

922-2148	Bezel, DAT Drive
922-2151	Label, Product ID, Power Macintosh 7200 / 120, Pkg. of 10
922-2152	Label, Product ID, 7600 / 120, Pkg. of 10
922-2153	Label, Product ID, Power Macintosh 8500 / 132, Pkg. of 10
922-2154	Label, Product ID, Power Macintosh 9500 / 150, Pkg. of 10
922-2155	Bezel, 14" All-In-One
922-2156	Housing, 14" All-In-One
922-2157	Shield, EMI, Monitor, 14" All-In-One
922-2158	Cable, Analog to Video Board, P501A
922-2159	Cable, RGB, Analog to Neck Board, P502A
922-2160	Cable, Power Supply to Analog, 4-wire, P804-P104
922-2163	Chassis, Foxconn, 14", All-In-One
922-2164	Carrying Case, Leather
922-2165	Housing, Rear, Graphite
922-2166	Plug, Rear Housing, Graphite, Pkg. of 5
922-2167	Bezel, Graphite
922-2168	Monitor Stand, Tilt-Swivel Base, Graphite
922-2169	Door, I / O, Graphite
922-2170	Bezel, Front, Graphite
922-2171	Fence, Logic Board, Graphite Plugs
922-2172	Local Talk Adapter
922-2173	Cover, PCI Door, Graphite, Pkg. of 5
922-2174	Cover, Video, Graphite, Pkg. of 5
922-2175	Cover, LCPDS, Graphite, Pkg. of 5
922-2176	Cover, Comm Slot, Graphite, Pkg. of 5
922-2178	Cover, Shield, Comm Slot Plug, Pkg. of 5
922-2179	Cover, Video In / LCPDS, Pkg. of 5
922-2180	Clips, Ground, Logic Board, Pkg. of 25 (replaced by 922-2454)
922-2182	Board, Front Panel Display, 14" All In One
922-2183	Multipurpose Tray
922-2184	Cover, Multipurpose
922-2185	Cover, Top
922-2186	Card, Audio / Video, For Use With 661-1123 and 661-1124
922-2187	Cable, Audio / Video, For Use With 661-1123 and 661-1124

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number **Part Name**

922-2188	Label, FCC ID, 1710 AV Display, Pkg. of 5
922-2189	Label, FCC ID, 1710 Display, Pkg. of 5
922-2190	Door, I / O, with Plug, Rev. B (replaced by 922-2315)
922-2191	Transfer Drum Sheet
922-2192	Spring, Tension, Transfer Drum Sheet, Pkg. of 2
922-2193	EtherTalk Adapter
922-2194	Power Adapter, EtherTalk, USA
922-2195	Power Adapter, EtherTalk, UK
922-2196	Power Adapter, EtherTalk, Australia
922-2197	Power Adapter, EtherTalk, Japan
922-2198	Power Adapter, EtherTalk, Europe
922-2199	Clutch, Pkg. of 2
922-2200	Shield, Top, Rev. B
922-2202	Bracket, Chassis, Rear, with 4-inch Fan
922-2203	Bracket, Chassis, Rear
922-2204	Cover, Top, Rev. B
922-2205	Panel, Side, Left, Rev. B
922-2206	Panel, Side, Right, Rev. B
922-2211	Label, Product, ID, Power Macintosh 5400, Pkg. of 10
922-2212	Heatsink, Logic
922-2213	Gasket, Speaker
922-2214	Label, Product ID, WS 7250 / 120, Pkg. of 10
922-2215	Cable, CD Audio, Black, For Use With 661-1123 and 661-1124
922-2216	Cable, Video Loopback, For Use With Apple PC Compatibility Cards
922-2217	Cable, CD Audio, White, For Use With 661-1123 and 661-1124
922-2219	Label, Product ID, WS 8550 / 132, Pkg. of 10
922-2220	Arm, Link, Density Sensor
922-2221	Axle, Wheel
922-2222	Nameplate, Product ID, Apple Network Server 500 / 132
922-2224	Screw, Sems 6-32 x .250, Pkg. of 10
922-2225	Screw, Machine, M3.5x45, Pkg. of 10
922-2226	Screw, Torx, M5x12mm, Pkg. of 10
922-2227	Screw, M2.5x.45x16mm, Pkg. of 10
922-2228	Screw, Stud, Flush Head, M4x12mm, Pkg. of 10

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number Part Name

922-2229	Screw, Machine, Pan, M3.5x6mm, Pkg. of 10
922-2230	Screw, Machine, Pan, Phillips, M3.5x10mm, Pkg. of 10
922-2231	Screw, Thumb, Pkg. of 10
922-2232	Washer, Nylon, Flat, Pkg. of 10
922-2233	Ink Storage Tank
922-2234	Cover, Mini Din, Graphite
922-2237	Board, Control Panel
922-2238	Board, Sound In
922-2239	Speaker Cover Set, Right and Left
922-2240	Grille, Speaker, Left
922-2241	Cable, Video
922-2242	Monitor Stand, Tilt-Swivel
922-2243	Door, Control Panel
922-2244	Housing, Rear
922-2245	Speaker
922-2247	Shield, Power Supply Board, EMI
922-2249	Cable, RAID, 68-pin
922-2250	Cable, RAID, 26-pin
922-2251	Cable, RAID, 68-pin to 68-pin
922-2252	Cover, Lower, Status Panel (replaced by 922-1715)
922-2253	Bracket, Hard Drives
922-2254	Cable, Hard Drive / CD-ROM Drive / DAT, SCSI
922-2260	Applique / Enhancer, Tackpad, Pkg. of 5
922-2261	Applique / Enhancer, Trackpad, Pkg. of 5
922-2262	Board, ADB
922-2265	Plate, Blank Bezel, Replaced by 922-3387
922-2266	Cable, Intermediate Board to ADB Board
922-2267	Label, Product ID, Power Macintosh 5260, Pkg. of 10 (Discontinued)
922-2269	Insulator, LCD Display
922-2270	Cable, Type 3 to Type 1 Token Ring Adapter, RJ-45 to DB9
922-2272	Chassis, Metal, Rev. A
922-2273	Fence, Logic Board
922-2274	Cover, Top
922-2275	Bezel, Front

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number **Part Name**

922-2276	Cover, Front, Expansion Bay
922-2277	Panel, Left, Performa 6400
922-2278	Panel, Right
922-2279	Panel, Rear
922-2281	Snap, Front, Bezel, Performa, Pkg. of 5
922-2282	Feet, Plastic, Pkg. of 4
922-2285	Face-Up Catch Tray
922-2286	Cassette, Envelope Feed
922-2287	Label, Product ID, Performa 6290, Pkg. of 10
922-2291	Label, Product ID, Power Macintosh 8500 / 150, Pkg. of 10
922-2292	Adapter, PCI Card, Right Angle
922-2293	Fence, Logic Board (replaced by 922-2314)
922-2294	Speaker, Box
922-2295	Label, Product ID, Performa 6320, Pkg. of 10
922-2296	Motor, Drive
922-2298	O-Ring with Transfer Roller
922-2299	Screw, M3.5x0.6x8mm, Pkg. of 10
922-2300	Screw, Custom, M6x1.0x25mm, Pkg. of 10
922-2302	Screw, Tap 4-4x.250, Pkg. of 10
922-2303	Screw, Shoulder, 6-32x1.5, Pkg. of 10
922-2306	Label, Product ID, Performa 5420, Pkg. of 10
922-2310	Cable, RJ11, Modem (replaced by 922-0740)
922-2313	EMI Clip, Processor Card
922-2314	Fence, Logic Board
922-2315	Door, I / O, Tuner
922-2317	Board, CRT / Video, Replaced by 076-0757
922-2318	Actuator, Display Assembly, Pkg. of 5
922-2319	Latch, Display
922-2320	Clip, EMI, Pkg. of 25 (replaced by 922-2454)
922-2321	Cable, FM Twin Lead Dipole, F Connector
922-2322	Cable, SCSI Select, Quantum
922-2323	Shield, PCI Plug, Pkg. of 5
922-2324	Cable, Keyboard, AppleDesign, Graphite
922-2326	Cover, Upper Case, Rev. B

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-2327	Keyboard, AppleDesign, Graphite
922-2328	Mouse, Apple Desktop Bus, Graphite
922-2329	Fence, EtherNet, 10-Base T, Pkg. of 2
922-2330	Fence, EtherNet, Thin Coax, Pkg. of 2
922-2357	Cable, RGB, Internal
922-2358	Plug, Mini-Din, Internal Modem, Pkg. of 5
922-2360	Adapter, Multiscan 14" to Mac IIsi
922-2361	Gasket, EMI Shield
922-2366	Bracket, PCI, Support
922-2367	Knob, Volume control, Subwoofer, Pkg. of 2
922-2368	Hook, Board, Snap-In, Pkg. of 10 (Replaced by 922-0097)
922-2369	Gasket, EMI Shield, Bottom Assembly
922-2371	Board, Right Angle Adapter, 2 Slot, PCI
922-2372	Bracket, Expansion Rear Hatch
922-2373	Hatch, Expansion, Assembly
922-2384	Speaker Assembly, Subwoofer
922-2385	Nameplate, MacIntosh, PB 1400, Pkg. of 10
922-2386	Nameplate, PB 1400c / 117, Pkg. of 3
922-2388	Fence, Logic Board, Graphite
922-2389	Door, I / O, Graphite
922-2390	Cover, Tuner, TV / FM Radio
922-2392	Label, Product ID, Performa 6400, 180Mhz, Pkg. of 10
922-2393	Label, Product ID, Performa 6400, 200Mhz, Pkg. of 10
922-2395	Label, VID, Logic Board and Video Cable, Pkg. of 100
922-2396	Label, REA, Logic Board Repair, Pkg. of 100
922-2397	SIMM, DRAM, 4 MB, 80 ns, 72-pin, REA Program Only
922-2398	Keyboard
922-2401	Label, REA Procedure, Pkg. of 10
922-2402	Label, Product ID, PM 5260 / 120, Pkg.10
922-2403	Cap, Battery, Pkg. of 5
922-2404	Cable, Display, TFT
922-2405	Cable, Inverter
922-2407	Bracket, Clutch, Left, Pkg. of 10
922-2408	Bracket, Clutch, Right, Pkg. of 10

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-2409	Bumper, Rubber, Bezel, Pkg. of 10
922-2410	Door, I / O
922-2411	Window, I / R, Pkg. of 5
922-2412	Cover, Clutch, Middle, Pkg. of 5
922-2413	Cover, Clutch, End, Pkg. of 5
922-2414	Retainer, Speaker, Pkg. of 5
922-2415	Feet, Rubber, Black, Damper for Subwoofer, Pkg. of 25
922-2416	Label, Product ID, Power Macintosh 7600 / 132, Pkg. of 10
922-2417	Label, Product ID, Power Macintosh 8500 / 180, Pkg. of 10
922-2418	Label, Product ID, Power Macintosh 9500 / 200, Pkg. of 10
922-2419	Label, Product ID, Power Macintosh 9500 / 180MP, Pkg. of 10
922-2420	Battery, NiMH (replaced by 922-3078)
922-2421	Cable, Ribbon, Floppy Drive (replaced by 661-1359)
922-2422	Cable, Hard Drive
922-2423	Cable, Flex, Trackpad
922-2424	Clutch, Pkg. of 5
922-2425	Board, PCMCIA, Eject
922-2426	Shield, Hard Drive
922-2427	Speaker
922-2428	Battery Cover, Backup, Pkg. of 5
922-2429	Battery, Backup
922-2432	Bezel, Front
922-2433	Power Button and Spring Assembly
922-2438	Label, FCC ID, Pkg. of 5
922-2439	Door, I / O, with PCI Hole
922-2440	Gaskets, Speaker Grilles, Pkg. of 10
922-2441	Fence, AAUI Ethernet, Comm Slot, Pkg. of 2
922-2442	Knobs, Contrast, Brightness, Volume, Pkg. of 3
922-2447	I / O Board Shield
922-2448	Mylar Sheet, Power Supply
922-2449	Duplex Jam Tray
922-2450	Housing, 500-Sheet Feeder
922-2452	Duplexer Chute
922-2453	Duplexer Chute Clips, Pkg. of 6

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-2454	Clip, Ground, Logic Board, Pkg. of 10, REA Program Only
922-2457	DC Connector
922-2458	IC, ROM, IOP, Rev. 3.0
922-2460	Cable, DAV I / F, 2.5"
922-2461	Cable, DAV, I / F, 5.75"
922-2465	Board, Trackpad (replaced by 922-2694)
922-2467	Cable, Display / Inverter
922-2468	Board, Inverter
922-2469	Board, Infrared
922-2470	Cable, Hard Drive, Flex
922-2471	Battery, Lithium Ion, with Cap
922-2472	Microphone
922-2473	Cable, Infrared
922-2474	Frame, Display
922-2476	Bezel, Display
922-2477	Housing, Display
922-2478	Shield, Display Bezel, EMI
922-2479	Frame, Inverter
922-2480	Grill, Housing, Display, Left
922-2481	Grill, Housing, Display, Right
922-2482	Nameplate, PB 3400c, Pkg. of 5
922-2484	Gasket, Acoustic, Display
922-2485	Heatsink
922-2487	Case, Bottom
922-2488	Grill, Brightness & Speaker
922-2489	CPU Stiffener
922-2490	Plate, Spacer, Expansion Bay, Pkg. of 5
922-2491	Guide, Alignment, Expansion Bay, Pkg. of 5
922-2492	Cover, Clutch, Center
922-2493	Cover, Clutch, Left, Pkg. of 5
922-2494	Cover, Clutch, Right, Pkg. of 5
922-2495	Door, I / O
922-2496	Door, ADB, Pkg. of 5
922-2497	Bracket, Hard Drive

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-2498	Palm Rest
922-2499	Shield, I / O
922-2500	Shield, PCMCIA
922-2502	Bezel and Shield, Tape Drive, 8mm, Network Server
922-2503	Label, Product ID, PM 5400 / 180, Pkg. 10
922-2505	Deflector, Air Flow, Pkg. of 5
922-2510	Plug, PCI I / O, Pkg. of 5
922-2511	Label, Product ID, Power Macintosh 6400 / 180, Pkg. of 10
922-2512	Label, Product ID, Power Macintosh 6400 / 200, Pkg. of 10
922-2513	Label, Product ID, PM6360 / 160, Pkg. of 10
922-2514	Label, Product ID, Performa 6360/160, Pkg. of 10
922-2515	Screw, Pan Head, 6-32x1, 1 / 4, Pkg. of 25
922-2516	Bracket, Tuner, Pkg. of 5
922-2520	Washer, Locking, 5.5 OD, Pkg. of 25
922-2523	Saddle, Wire Routing, Pkg. of 10
922-2525	Handset, ISDN, H.320, PCI Card, QuickTime Conferencing
922-2528	Board, Floppy Drive (replaced by 661-1359)
922-2529	Cover, Bottom, Floppy Drive (replaced by 661-1359)
922-2530	Cover, Top, Floppy Drive (replaced by 661-1359)
922-2531	Door, CD-ROM, 8x
922-2532	Board, CD-ROM Drive (replaced by 661-1358)
922-2533	Cover, Top, CD-ROM Drive
922-2534	Cover, Bottom, CD-ROM Drive (replaced by 661-1358)
922-2535	Housing, Display, 11.3"
922-2536	Case, Bottom
922-2537	Shield, Trackpad
922-2538	Button, Trackpad
922-2539	Board, Inverter
922-2540	Panel, Graphite
922-2541	Panel, Clear
922-2546	Guide, Logic Board, Pkg. of 10
922-2547	Audio / Monitor Connection (replaced by 922-2996)
922-2548	Bracket, Video Expansion
922-2549	Bezel, Display, TFT, 11.3"

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-2550	Guide for Tuner board, Pkg. of 10
922-2551	Spring, EMI, Release Tabs, Pkg. of 10
922-2552	Cover, Left Metal Panel
922-2553	Clip, Tuner Cable, Pkg. of 10
922-2560	Nameplate, Product ID, Network Server 700 / 200
922-2563	Power Cord Lock and Screws Kit, Pkg. of 2
922-2564	Label, Product ID, WS8550 / 200, Pkg. of 10
922-2565	Case, Top (replaced by 922-2861)
922-2566	Heatsink
922-2567	Grill, Speaker
922-2568	Power Adapter, 45 W
922-2569	Fence, Logic Board
922-2570	Shield, ADB, EMI, Logic Board
922-2571	Foot, Rubber, Left
922-2572	Foot, Rubber, Right
922-2573	Plug, Dummy, Video Port
922-2574	Clamp, Display / Inverter Cable
922-2575	Keyboard, U.S., PB 1400
922-2579	Label, Product ID, Performa 5260 / 120, Pkg. of 10
922-2580	Bezel, Display, DLSCN, 11.3"
922-2581	Bracket, Display Housing, Left, Pkg. of 5
922-2582	Bracket, Display Housing, Right, Pkg. of 5
922-2583	Label, Product ID, Floppy Drive, Pkg. of 10 (replaced by 661-1359)
922-2584	Label, Product ID, CD-ROM Drive, Pkg. of 10
922-2585	Cable, Display, DLSCN
922-2586	Insulator, Logic Board
922-2587	PCMCIA Door Assembly
922-2588	Actuator, Power, Light Pipe
922-2589	Cable, LED
922-2590	Cable, SCSI, 50-Pin
922-2591	Cable, Floppy Drive
922-2592	Cable, CD Audio, Pkg. of 5
922-2593	Shield, Top, Tape Drive, 8mm, Network Server
922-2594	Bezel, Floppy Drive, Manual Insert, Pkg. of 5

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number **Part Name**

922-2595	Bezel, CD-ROM Drive, Trayloading, Pkg. of 5
922-2596	Bezel, Blank, Pkg. of 5
922-2597	Shield, Floppy Drive, Pkg. of 5
922-2598	Shield, CD / DVD, Pkg. of 5
922-2599	Carrier, Front Drive, Pkg. of 5
922-2600	Carrier, Rear Drive, Pkg. of 5
922-2601	Panel, Side, Stationary
922-2602	Cover, Top
922-2603	Panel, Rear
922-2604	Bezel, Speaker
922-2605	Cover, Blank, PCI, Pkg. of 10
922-2606	Panel, I / O
922-2607	Panel, I / O
922-2608	Fan Assembly
922-2609	Screw, Tap, Pan, Torx, M4x35, Pkg. of 10
922-2610	Screw, Pan, M3.5x6x6mm, Pkg. of 10
922-2611	Feet, Rubber, 6mm, Pkg. of 10
922-2613	Cover, Display Cable, TFT
922-2614	Cover, Display Cable, DLSCN
922-2616	Ferrite Bead, Pkg. of 5
922-2618	Diffuser, Transparency Unit
922-2619	Cable, Fan, Pkg. of 5
922-2620	Cover, Mylar, Screw, Pkg. of 50
922-2623	Shield, Floppy / Zip Drive, Pkg. of 5
922-2624	Bezel, Zip Drive, Pkg. of 5
922-2625	Nameplate, Power Macintosh 9600 / 200, Pkg. of 5
922-2626	Nameplate, Power Macintosh 9600 / 200MP, Pkg. of 5
922-2627	Cover, Clutch, Center
922-2628	Cover, Clutch, Left
922-2629	Cover, Clutch, Right
922-2631	Chassis, Internal
922-2632	Housing, Speaker
922-2633	Speaker, 16 Ohm, 2 Watts
922-2634	Panel, Side Access

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number Part Name

922-2635	Cable, Phone RJ-11, 6 ft.
922-2637	Delivery Roller Assembly (replaces 922-0292)
922-2638	Cable, LED, 6-slot (replaced by 922-2589)
922-2639	Label, Product ID, Power Macintosh 7300/166, Pkg. of 10
922-2640	Label, Product ID, Power Macintosh 7300 / 180, Pkg. of 10
922-2641	Label, Product ID, Power Macintosh 7300 / 200, Pkg. of 10
922-2644	Speakers, with Enclosures
922-2645	Cable, Video / ADB
922-2646	Housing, Top
922-2647	Housing, Rear
922-2648	Bezel, Front
922-2649	Bezel, Sound Enclosure
922-2650	Board, Sound
922-2651	Guide Rails, Sound Board, Pkg. of 2
922-2652	Board, Power
922-2653	Nameplate, Power Macintosh 8600 / 200, Pkg. of 5
922-2654	Cable, Hard Drive or CD-ROM Drive, IDE, 40-Pin, 4400
922-2655	Label, Product ID, PM 4400/160
922-2656	Adapter, Right Angle, 3 Slot, PCI with Bracket
922-2657	Bezel, Front
922-2658	Cable, SCSI, External, 50 / 25-Pin
922-2659	Shield, Cable
922-2661	Monitor Stand, Tilt-Swivel
922-2662	Housing, Mid
922-2663	Cable, CD-ROM Audio, IDE, 4-Pin
922-2664	Bushing, Front Carousel
922-2665	Bushing, Toner Carousel, Rear
922-2666	Chassis/CPU Stiffener
922-2670	Button, Trackpad, Pkg. of 5
922-2674	Door, Battery, ROM, RAM Access
922-2675	Sleeve, Battery
922-2676	Holder, Name Card
922-2677	Lens, Infrared
922-2678	Handle, Rubber Cushion

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-2679	Feet, Rubber, Pkg. of 4
922-2680	Plug, Screw, Bezel, Pkg. of 4
922-2681	Backlight, Electroluminescent (EL)
922-2682	Stylus
922-2684	Handle, Drive Chassis
922-2685	Latch, Drive Chassis, Pkg. of 5
922-2686	Latch, Logic Board, Pkg. of 10
922-2687	Screw, Pan Head, 3.5x6, Pkg. of 10
922-2688	Security Bar
922-2689	Actuator, Lower Exit
922-2690	Gear, Exit Out
922-2691	Bearing, Exit Roller
922-2692	Battery, Backup
922-2693	Cable, Backup Battery, Pkg. of 5
922-2694	Board, Trackpad, v3.0
922-2696	Label, FCC
922-2697	Label, FCC, Power Macintosh 8600 / 9600, Pkg. of 10
922-2699	LED, Media Bay
922-2700	Button, Reset, Pkg. of 5
922-2702	Button, Trackpad, Pkg. of 5
922-2703	Label, Product ID, Power Macintosh 5400 / 200, Pkg. of 10
922-2704	Bumper, Display, Pkg. of 10
922-2705	Label, Product ID, Power Macintosh 4400 / 200, Pkg. of 10
922-2707	Chassis, Metal, Rev. B
922-2708	Label, Product ID, Power Macintosh 6500 / 225, Pkg. of 10
922-2709	Label, Product ID, Power Macintosh 6500 / 250, Pkg. of 10
922-2720	Clips, Endcaps, Pkg. of 4
922-2721	Adapter, VGA DDC 1 / 2AB
922-2723	Label, FCC, Power Macintosh 4400 / 200, Pkg. of 10
922-2724	Heatsink, CPU, Pkg. of 10
922-2725	Adapter, Right Angle, 1 Comm Slot, 2 PCI Slots, with Bracket
922-2726	Housing, Bottom
922-2727	Board, ADB
922-2731	Label, Product ID, Power Macintosh 5500 / 225, Pkg. of 10

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-2732	Fan Assembly
922-2733	Mouse II, Apple Desktop Bus, Rev. B
922-2734	Cable, DC Power Adapter, 5.25", Zip, Pkg. of 5
922-2735	Cover, Zip Drive
922-2736	Carrier, Zip Drive
922-2739	Screw, Sems, Pan, Phillips, M3x0.5x5, Pkg.of 25
922-2740	Roller, Upper Deliver
922-2757	Cover, Fuser Access
922-2758	Cover, Top Left
922-2759	Cover, Right Top
922-2761	Cover Assembly, Left
922-2762	Cover, Left Lower
922-2763	Cover, Right
922-2764	Cover, Front Left
922-2765	Cover, Exit
922-2766	Cover Assembly, Top
922-2767	Status Panel Assembly
922-2768	Cassette, A3
922-2769	Cover, A3 Cassette
922-2770	Board, Cassette Feed
922-2771	Turn-In Chute
922-2772	Cover, Turn Chute
922-2773	Cassette Guide Assembly, Left
922-2774	Paper-Present Sensor
922-2775	Cassette Guide Assembly, Right
922-2777	Pickup Roller, Cassette (pkg. of 4)
922-2778	Solenoid, Cassette Feed Pickup
922-2779	Turn Clutch
922-2781	Screw, Pan, TORX, M2.5x1.11, Pkg. of 25
922-2790	Hatch, Rear, Assembly
922-2792	Feed Roller, Lower
922-2793	Feed Roller, Upper
922-2795	Cover Assembly, Manual Feed
922-2796	Manual Feed Sensor Assembly

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-2798	Manual Feed Paper-Present Actuator
922-2799	Toner Sensor Assembly
922-2800	Transfer Roller
922-2801	Pickup Roller, Manual Feed (pkg. of 4)
922-2802	Solenoid, Manual Feed Pickup
922-2803	Rubber Registration Roller
922-2804	Fuser Heater, 110 V
922-2805	Main Motor
922-2806	Paper Handling Gear Assembly
922-2807	Drive Bearing, Left
922-2808	Registration Clutch Assembly
922-2809	Main Gear Assembly
922-2810	Latch Lever
922-2811	Cartridge Sensor Assembly
922-2812	Top Cover Interlock Switch
922-2813	Fuser Cover Interlock Switch
922-2814	Fan
922-2815	Power Inlet Holder
922-2816	DC Controller Board Mount
922-2817	Board, Duplex Interface
922-2818	HVPS Spacer
922-2819	Knob, Print Density
922-2820	Fuser Heater, 220 V
922-2832	Keyboard, AppleDesign
922-2833	Clip, ESD, Pkg. of 5
922-2834	Board, Sensor
922-2835	Cover, Main
922-2836	Tray, Paper
922-2838	Cover, Logic Board
922-2839	Lever, Paper Selection
922-2840	Pin, Idler, Pkg. of 5
922-2841	Encoder Strip
922-2842	Spring, Pivot, Pkg. of 5
922-2843	Gear, Drive

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-2844	Actuator, Front Cover
922-2845	Idler, Hub, Pkg. of 5
922-2846	Motor, Carriage
922-2847	Cable, Paper Motor
922-2848	Actuator, Paper Out
922-2849	Pad, Friction
922-2850	Clip, Shaft, Pkg. of 5
922-2851	Belt, Carriage
922-2852	Motor, Paper Feed
922-2853	Plate, Pressure, with Right Wall
922-2854	Capping Assembly
922-2855	Purge Unit
922-2857	Case, Ink Tank
922-2858	Nameplate, CSW 4500
922-2859	Power Adapter, U.S. / Canada
922-2860	Adjuster, Length Assembly
922-2861	Case, Top, V3.0
922-2862	Housing Assembly Without Front Bezel
922-2863	Multipurpose Tray
922-2879	Insulation, Bridge
922-2880	Bracket, Hard Drive / Fan
922-2881	Insulation, Latch
922-2882	Card, Memory, 4 MB
922-2883	Card, Memory, 2 MB
922-2884	Insulation, Video-in Card
922-2885	Vent Rear
922-2886	Door, I / O, Rear
922-2887	Hinge, I / O Door
922-2902	Cable, Video, RCA
922-2903	Cable, Macintosh
922-2904	Viewfinder
922-2905	Wrist Strap
922-2906	Power Adapter, 90-132 VAC, 47-63 Hz, US
922-2907	Power Adapter, 90-132 VAC, 47-63 Hz, Japan

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-2908	Power Adapter, 180-264 VAC, 47-63 Hz, UK
922-2909	Power Adapter, 180-264 VAC, 47-63 Hz, Europe
922-2911	Board, Power Supply
922-2912	Purge Unit
922-2913	Cover, Front
922-2914	Actuator, Access Door, Pkg. of 5
922-2915	Clamp, Ribbon Cable, Pkg. of 5
922-2916	Tray, Paper
922-2917	Cover, Keypad
922-2918	Light Pipe Assembly
922-2919	Cover, Side
922-2920	Cover, Top
922-2921	Feet, Bottom, Pkg. of 5
922-2922	Belt, Carriage
922-2923	Wing, Right
922-2924	Wing, Left
922-2925	Motor, Carriage
922-2926	Encoder Strip
922-2927	Cable, Ribbon Carriage
922-2928	Idler Assembly
922-2929	Cable, Motor Assembly
922-2930	Motor, Paper
922-2931	Guide, Envelope
922-2932	Motor, Purge Unit
922-2933	Turnaround Assembly
922-2934	Absorber Assembly
922-2938	Battery, NiMH
922-2939	Bezel, Display
922-2940	Top Cover, Display
922-2941	Case, Bottom Assembly
922-2951	Power Adapter, Newton, 9 W
922-2953	Cover, Blank, PCI slot, Pkg. of 10
922-2954	Cover, Comm Slot, Pkg. of 5
922-2955	Bracket, Mounting, DB 15, Inside, Pkg. of 5

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-2956	Bracket, Mounting, DB 15, Outside, Pkg. of 5
922-2957	Label, FCC, Power Macintosh 6500, Pkg. of 5
922-2958	Adapter, Right Angle, 1 Comm Slot, 2 PCI Slots, w / Bracket
922-2959	Label, FCC, Power Macintosh 5500, Pkg. of 5
922-2960	Shield, Top, Subassembly, AIO
922-2961	Shield, EMI, Analog / Sweep, 15" AIO
922-2962	Shield, EMI, Power, 15" AIO
922-2963	Cable, VGA Adapter
922-2964	Cable, Phone 1TP
922-2965	Cable, 10 BaseT, 2TP
922-2966	Cable, "Y", RJ45 to RJ11 & RJ45
922-2968	Battery Pack, Rechargeable, NiMh
922-2969	Stylus, Pkg. of 5
922-2971	Cable, Adapter, Message Pad 2000 / 2100 to DIN-9
922-2972	Case, Carrying, Nylon
922-2973	Adapter Plug, UK
922-2974	Adapter Plug, Europe
922-2975	Adapter Plug, Australia
922-2976	Case, Carrying
922-2977	Insulator, Hard Drive, 240 MHz, Pkg. of 5
922-2978	Shield, Blank , 3.5" Drive Bay, Pkg. of 5
922-2979	Cage, PCMCIA Card, Japan Only
922-2980	Board, Inverter, Japan Only
922-2981	Keyboard, Japan
922-2982	Battery, Backup
922-2983	Speaker
922-2984	Cable, External Floppy Drive
922-2985	Cover, Screw, Pkg. of 10
922-2986	Case, Top
922-2987	Cover, Hinge
922-2988	Cover, Audio Jack
922-2989	Shield, Cover, Japan Only
922-2990	Structure Assembly
922-2991	Door, I / O

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-2993	Carrier, Bottom, Pkg. of 5
922-2994	Cable, Audio, Sound-In, Atapi, PM 4400 and 7220, For Use With 661-1347 and 661-1353
922-2995	Cable, Audio, Sound-Out, For Use With 661-1347 and 661-1353
922-2996	Audio / Monitor Connection
922-2997	Cover, Comm Slot Plug, Pkg. of 10
922-2998	Degauss Assembly, CRT
922-3000	Label, Product ID, WS 7350 / 180, Pkg. of 10
922-3002	Nameplate, WS 9650 / 233, Pkg. of 5
922-3003	Adjuster, Width with Cap
922-3004	Cover, Main, with Keypad and Front Cover
922-3005	Tray, Paper
922-3006	Cap, Width Adjuster
922-3008	Nameplate, CSW 4100
922-3009	Capping Assembly
922-3011	Adjuster, Width, with Cap
922-3012	Adjuster, Length Assembly
922-3013	Screw, M2.5x.45x6mm, Pkg. of 10
922-3014	Screw, Mach, Pan, Torx, Pkg. of 10
922-3015	Bracket, Ext Mnt, Video Out, 6500, Pkg. of 5
922-3016	Bracket, Ext Mnt, Video Out, Pkg. of 5
922-3017	Nameplate, Power Macintosh 9600 / 233, Pkg. of 5
922-3018	Bracket Extender, PM 4400 and 7220, For Use With 661-1347
922-3019	Cable, Fan Regulator Adapter (Use with fan part number ending in B40)
922-3027	Case Kit, Bottom, Japan Only
922-3028	Cable, Flex, LCD
922-3029	Power Adapter, 36 W
922-3030	Keyboard, US
922-3031	Power Supply, 110 V
922-3032	Power Supply, 220 V
922-3033	Transport Chute Assembly, 110 V
922-3034	Duplexer
922-3035	Sheet Feeder
922-3036	Thumbscrews (pkg. of 2)
922-3037	Duplexer Paper Pass Sensor

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3038	Duplexer Stack Actuator
922-3039	Duplexer Strap
922-3040	Delivery Tray Paper Weight
922-3041	Duplexer Offset Assembly
922-3042	Duplexer Feed Roller, Upper
922-3043	Duplexer Feed Roller, Lower
922-3044	Duplexer Drive Belt
922-3047	Gear, In Idler
922-3048	Cable, Supply Voltage, 9-Way
922-3049	Cable, Audio, Sound-In, SCSI, For Use With 661-1347
922-3050	Bezel, Tape Drive, Pkg. of 5
922-3051	Sound Enclosure
922-3052	Cable, Ultra Wide, Internal SCSI, 68-Pin
922-3053	Speaker, 77mm, 6 W, 8 ohm
922-3054	Cable, MDB to Power Board, 12-pin
922-3055	Cable, Sound to Power Board, 10-pin
922-3056	Cable, Sound Controls to Power Board
922-3057	Cable, Audio
922-3058	Baffle, Access Panel
922-3059	Cable, Extension, SCSI , Zip Drive, Use with 922-2272
922-3060	Actuator, Upper Exit, Long
922-3061	Actuator Spring, Upper Exit, Long
922-3062	Actuator, Upper Exit, Short
922-3063	Actuator Spring, Upper Exit, Short
922-3064	Nameplate, PB 1400c / 133, Pkg. of 3
922-3065	Nameplate, PB 1400cs / 133, Pkg. of 3
922-3066	Nameplate, PB 1400cs / 117, Pkg. of 3
922-3067	Nameplate, PB 1400c / 166, Pkg. of 5
922-3068	Cassette, Standard
922-3069	Cover, Standard Cassette
922-3070	Air Deflector, Power Macintosh 8600
922-3076	Battery, Lithium Ion
922-3078	Battery, NiMH, 33 W
922-3079	Cable, Flex, Trackpad

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3080	Case, Top
922-3082	Shield, Hard Drive
922-3083	Keyboard II, Apple Extended
922-3085	Fan Assembly
922-3091	Transport Chute Assembly, 220 V
922-3092	Board, DC Controller, 110 V
922-3093	Laser / Scanner Assembly
922-3094	High-Voltage Power Supply
922-3095	Label, Product ID, PM6500 / 275
922-3096	Label, Product ID, PM6500 / 300
922-3097	Label, Product ID, PowerBook 1400 / 117
922-3098	Label, Product ID, PowerBook 1400 / 133
922-3099	Label, Product ID, PowerBook 1400 / 166
922-3100	Product Label, PowerBook 3400, PKG/10
922-3101	Tiewrap, Velcro
922-3103	Gasket, Foam, Keyboard, Pkg. of 4
922-3104	Endcap, Sound Enclosure, Right Side
922-3105	Endcap, Sound Enclosure, Left Side
922-3106	Shield, Tape Drive, Pkg. of 5
922-3107	Terminator, SCSI, 50-Pin
922-3108	Gasket, Plastic
922-3109	Keyboard, U.S.
922-3110	Label, FCC ID, AppleVision 850AV Display, Pkg. of 5
922-3111	Insulator, Display Housing
922-3112	Ground Contact, Display Housing, Pkg. of 5
922-3113	Screw, Sems, Pan, Phillips, M4x0.7
922-3114	Screw, Tap, Met, Phillips, M3x16, Pkg. of 10
922-3115	Screw, Tap, Met, Phillips, Pan, M4x8
922-3116	Screw, Tap, Met, Phillips, Pan, M4x8, Pkg. of 10
922-3117	Screw, Mach, Pan, Torx, M4x0.7x20
922-3118	Screw, Tap, Met, Phillips, Wsh, 3x12, Pkg. of 10
922-3119	Screw, Mach, Pan, Torx, M4x0.7x5.7, Pkg. of 10
922-3120	Label, FCC ID, AppleVision 850 Display, Pkg. of 5
922-3122	Screw, Torx, M3x0.5mm, Pkg. of 10

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3124	Cable, Ground, Audio Power Board
922-3125	Nameplate, Power Macintosh 8600/250
922-3126	Nameplate, Power Macintosh 8600 / 300, Pkg. of 5
922-3127	Nameplate, Power Macintosh 9600 / 300, Pkg. of 5
922-3128	Nameplate, Power Macintosh 9600 / 350, Pkg. of 5
922-3129	Carrier, Bottom Drives, Pkg. of 5
922-3131	Label, Product ID, Power Macintosh G3 Desktop
922-3134	Board, Panel
922-3135	Base Unit
922-3138	Board, Intermediate
922-3139	Label, FCC ID, 750AV Display, Pkg. of 5
922-3140	Label, Product ID, PM 7300 / 180PC, Pkg. of 10
922-3142	Cable, Video
922-3144	Housing, Rear
922-3145	Bezel, Front
922-3147	Power Adapter
922-3151	Door, Audio / Video, Rev. A
922-3152	Monitor Stand, Desktop, Rev. A
922-3153	Monitor Stand, Tilt-Swivel
922-3155	Cable, Shielded ADB Splitter
922-3156	Nameplate, Workgroup Server 9650/350, Pkg. of 5
922-3158	Board, Sound
922-3159	Screw, FDHD Superdrive, Pkg. of 5
922-3204	Cover, Comm Slot Plug, Pkg. of 5
922-3210	Shim, Plastic, PVC, 0.5 mm, Pkg. of 25
922-3212	Label, FCC ID, 750 Display, Pkg. of 5
922-3215	Board, DC Controller, 220 V
922-3216	Power Cord
922-3217	Standoff, Logic Board, Rubber, Pkg. of 10
922-3219	Bezel, CD-ROM, MKE
922-3220	Carrier, Rear Drive, Rev. B, Pkg. of 5
922-3221	Baffle, Expansion Card
922-3225	Bracket Extender, PM 4400 and 7220, For Use With 661-1353
922-3227	Cable, Serial / Parallel Card to PC Compatibility Card

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3228	Rail, Drive
922-3234	Nameplate, Product ID, Power Macintosh G3, MiniTower
922-3239	Screw, Tap, Pan, M3.5x1.56x8, Pkg. of 10
922-3240	Screw and Washer, M3.5x.6x10, Pkg. of 10
922-3250	Cable, I / O to Power Supply J18-P126
922-3255	Cable, 220V (int'l only)
922-3256	Nameplate, PowerBook G3, Pkg. of 5
922-3259	Screw, M3, Pan, Pkg. of 10
922-3260	Heatsink
922-3262	Bead, Ferrite, Trackpad Cable, Pkg. of 5
922-3263	Connector, Jumper, 2-Position, 2 mm, Pkg. of 10
922-3264	Cable, SCSI, 50-Pin
922-3265	Cable, Floppy Drive
922-3266	Cable, Hard Drive, IDE, 40-Pin
922-3267	Screw, SEMS, Pan, Phillips, Pkg. of 10
922-3268	Screw and Washer, Met, Pan, SEMS, M3.56 mm, Pkg. of 10
922-3269	Bezel, Speaker
922-3270	Panel, Side Access
922-3271	Cable, SCSI
922-3272	Cable, IDE, 40-Pin
922-3273	Cable, Power LED
922-3276	Bezel, CD-ROM, MKE
922-3277	Shield, CD-ROM
922-3278	Clip, EMI Ground
922-3279	Cable, Power Actuator
922-3280	Power Actuator, Pkg. of 10
922-3281	Baffle, Card Retainer
922-3282	Housing, Top
922-3283	Shield, Zip Drive (replaced by 922-3556)
922-3284	Bracket, Drive
922-3285	Bezel, Zip Drive
922-3286	Chassis, Bottom
922-3288	Bracket, Mounting, Power Supply
922-3289	Panel, I / O Access

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3290	Panel, Side, Stationary
922-3291	Shield, Rear, PCI
922-3292	Card, Voltage Regulator
922-3293	Clip, EMI, Heatsink, Pkg. of 10
922-3295	Fan Assembly, Without Housing
922-3296	Chassis, Internal
922-3297	Panel, Rear
922-3298	Baffle, Handle
922-3299	Baffle, Fan
922-3300	Housing, Speaker
922-3304	Latch, Knob, L&R
922-3305	Bezel, DVD-ROM Drive
922-3306	Cover, Flip
922-3307	Battery Tray, Alkaline
922-3308	Feet
922-3309	Feet, Rubber, Pkg. of 10
922-3326	Monitor Stand, Flip-Out, Rev. A
922-3329	Cable, Ultra Wide SCSI
922-3330	Case, Bottom / Heat Spreader
922-3331	Door, CD-ROM, 12x
922-3332	Board, I / R
922-3333	Label, Product ID, PowerBook G3, Pkg. of 10
922-3334	Multipurpose Frame Assembly
922-3335	Bezel, Front, TCO 95
922-3336	Bezel, Front, TCO 95
922-3337	Housing, Rear, TCO 95
922-3338	Housing, Rear, TCO 95
922-3339	Housing, Top, TCO 95
922-3340	Label, Product ID, ColorSync 17 Display, TCO 95, Pkg. of 5
922-3341	Housing, Mid, TCO 95
922-3343	Cover, Bottom, TCO 95
922-3344	Label, Product ID, ColorSync 20 Display, TCO 95, Pkg. of 5
922-3348	Keyboard, US
922-3350	Cable, Flex, Data, Display, 13.3", CPRC / International Only

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3353	Cable, Flex, PMU (replaced by 076-0783)
922-3354	Connector, Hard Drive
922-3358	Cable, Flex, Inverter, Display, 13.3", CPRC / International Only
922-3359	Card, Charge, Power Supply
922-3360	Cable / Switch, Flex, Trackpad
922-3361	Cable, Flex, Keyboard
922-3362	Cable, Flex, PC Eject Switch
922-3363	Bracket, Display, 12.1" / 13.3", Magnet Side, CPRC / International Only
922-3364	Bracket, Display, 12.1", Left
922-3366	Shield, EMI, Display, 13.3", CPRC / International Only
922-3367	Standoff, Hex, M2.5x12, Pkg. of 10
922-3368	Clutch, Display, 12.1" / 13.3", CPRC / International Only
922-3370	Fan Assembly, Pkg. of 5
922-3371	Cover, Clutch, Display, 13.3" / 14.1"
922-3372	Bracket, Hard Drive
922-3374	Board, Inverter, Display, 13.3" / 14.1", CPRC / International Only
922-3376	Case, Bottom
922-3377	Stiffener, Top Case
922-3378	Case, Top
922-3379	Speaker Assembly
922-3380	Battery, Backup
922-3382	Cable, Flex, Control Buttons
922-3383	Bracket, Display, 13.3", Left
922-3387	Plate, Blank Bezel, TCO 95
922-3388	Trackpad
922-3389	Window, I / R, Pkg. of 5
922-3390	Foot, Pkg. of 20
922-3394	Insulator, Hard Drive, Pkg. of 5
922-3395	Bumper, Display, 12.1" / 13.3", Pkg. of 10
922-3396	Screw Cover, Display, Pkg. of 10
922-3397	Microphone, Display, 12.1" / 13.3" , Pkg. of 5, CPRC / International Only
922-3398	Latch, Display, 12.1" / 13.3"
922-3400	Adapter, Power, 45 Watt, 2 Prong
922-3401	Cable, Power, Domestic, 2 Prong

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3406	Cable, Flex, Data, Display, 14.1", CPRC / International Only
922-3407	Bracket, Display, 14.1", Magnet Side, CPRC / International Only
922-3409	Clutch / Brace, Display, 14.1", Magnet Side, CPRC / International Only
922-3411	Baffle, PC Card Cardcage
922-3412	Nameplate, Macintosh Sever G3, Pkg. of 5
922-3413	Door, Flip, Expansion Bay
922-3414	Cable, PC Card Eject, Pkg. of 5
922-3416	Cover, Speaker, Pkg. of 2
922-3417	Shield, ESD, Trackpad
922-3418	Hold Down, Trackpad, Pkg. of 10
922-3419	Gasket, Speaker, Pkg. of 10
922-3420	Cable, Video In to MPEG, Rev D, 34-pin to 60-pin
922-3421	Cable, Din-7 to Composit Video, Output
922-3422	Cable, Phone, 1 Twisted Pair, Black
922-3424	Cable, Adapter, VGA, Black
922-3425	Cable, Flex, Data, Display, 12.1" STN, CPRC / International Only
922-3427	Cable, 10 Base T, 2 Twisted Pair, Black
922-3428	Cable, Flex, Inverter, Display, 12.1", CPRC / International Only
922-3429	Board, Inverter, Display, 12.1" , CPRC / International Only
922-3431	Cover, Clutch, Display, 12.1"
922-3436	Base, Tilt / Swivel
922-3437	Carrier, Chassis
922-3438	Bezel, CRT
922-3439	Microphone
922-3440	Door, Front
922-3441	Speaker Enclosure, Right
922-3442	Speaker Enclosure, Left
922-3445	Ground Strap, EMI, PC Card Cardcage, Pkg. of 5
922-3446	Board, Front Panel
922-3447	Shield, Top Cover, CRT
922-3448	Fan
922-3449	Cable, Thermistor
922-3450	Heat Sink, Microprocessor Board
922-3452	Bezel, Display, 13.3", CPRC / International Only

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3453	Bezel, Display, 14.1", CPRC / International Only
922-3454	Bezel, Display, 12.1", CPRC / International Only
922-3455	Housing, Display, 12.1" / 13.3", CPRC / International Only
922-3457	Door, PC Card Cardcage, Pkg. of 10
922-3458	Shield, Stiffener, Pkg. of 5
922-3459	Carrier, Trackpad, Pkg. of 5
922-3460	Housing, Display, 14.1", CPRC / International Only
922-3463	Cable, Flex, Inverter, Display, 14.1", CPRC / International Only
922-3465	Clutch / Brace, Display, 14.1", Left, CPRC / International Only
922-3466	Bracket, Display, 14.1", Left, CPRC / International Only
922-3467	Bumper, Display, 14.1", Pkg. of 10
922-3468	Label, Product ID, Ireland, Pkg. of 10
922-3470	Terminator, Video
922-3472	Shield, EMI, Display, 12.1", CPRC / International Only
922-3473	Panel, Side, Right, Housing
922-3474	Panel, Side, Left, Housing
922-3475	Panel, Side, Rear, Housing
922-3476	Panel, Top, Housing
922-3477	Clips, EMI, Short, Pkg. of 5
922-3478	Clips, EMI, Long, Pkg. of 5
922-3479	Plug, Screw, Top Housing, Pkg. of 10
922-3480	Cable, RGB
922-3481	Cable, Main Power, Chassis
922-3482	Cable, Zip / CD-ROM
922-3483	Cable, Power, Zip
922-3485	Cable, CD-Audio
922-3486	Cable, Hard Drive
922-3487	Cable, Floppy
922-3488	Clips, Mounting, CRT, Pkg. of 10
922-3489	Chassis, Main
922-3490	Bracket, Cable Support
922-3491	Insulator, Logic Board
922-3492	Cable, I / O Card, Front Panel, Analog, P / S
922-3495	Panel, Rear, I / O

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3497	CRT Assembly, ASAG / NH
922-3499	Washer, Flat, #6, Nylon, Pkg. of 25
922-3500	Gasket, EMI, Rear I / O Panel
922-3501	Label, Front Panel, Power Macintosh G3 All-In-One
922-3502	Plug, Modem Port, Pkg. of 5
922-3504	Alignment Tool, Display Service
922-3505	Cable, Power, 110V, Smoke, 10 ft.
922-3509	Cable, Main Motor
922-3510	Magnet, CPRC / International Only
922-3512	Cable, FireWire, Internal
922-3513	Cable, FireWire, External, 4-Pin to 6-Pin
922-3514	Cable, Video / Analog, P302 to P506
922-3515	Cable, Video / Analog, P305 to P502
922-3516	Bracket, Thermistor
922-3517	Cable, Microphone to Analog, P11 to P703
922-3518	Cable, Analog / PS, P507 to P908
922-3519	Cable, PS / P913, Analog / P505, Front Panel / P4
922-3520	Cable, Power HDA / Zip / CD-ROM
922-3521	Bracket, Zip, Blank
922-3522	Shield, Zip, Blank
922-3523	Plug, Zip, Blank
922-3524	Label, Product ID
922-3525	Shield, Zip / Floppy
922-3526	Shield, CD-ROM
922-3527	Feet, Rubber, Black, 9.5 mm, Pkg. of 10
922-3528	Carrier, Hard Drive
922-3529	Bezel, Tape Drive, DDS-3, Pkg. of 5
922-3531	Thumbscrews, Pkg. of 4
922-3532	Bumper, Side, Display, 14.1"
922-3534	Label, Product ID, Power Macintosh 5500/250
922-3535	Adapter, Power, 45 Watt, 3 Prong
922-3536	Screw, M3x8, Pkg. of 10
922-3537	Screw, M3x10, Pkg. of 10
922-3538	Screw, M4x16 Tap, Pkg. of 10

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3539	Screw, M3x6, Pkg. of 10
922-3540	Screw, M3x8, Pkg. of 10
922-3541	Screw, M3x10, Pkg. of 10
922-3542	Screw, M4x16, Machine, Pkg. of 10
922-3543	Screw, M3.5x8 Machine, Pkg. of 10
922-3544	Screw, FH, Tap, M5x10, Pkg. of 10
922-3545	Power Cord, Right Angle, 100V, AC
922-3546	Screw, Machine, M3.5x6x16, Pkg. of 10
922-3547	Board, Sound and Intermediate
922-3548	Microphone, Display, 14.1", CPRC / International Only
922-3550	Bezel, DVD-ROM Drive, MKE, Desktop
922-3552	Cable, Ultra Wide SCSI, Desktop
922-3554	Bumper, Poron, .5mmx3.5mm, Pkg. of 3
922-3555	Shield, Blank and CD / DVD, Pkg. of 5
922-3556	Shield, Zip and CD / DVD
922-3557	Bezel, CD-ROM, Sony
922-3558	Cable, IDE, Master / Slave, 40-Pin
922-3559	Keyboard, USB, Bondi Blue
922-3560	Mouse, USB, Bondi Blue
922-3561	Housing, Rear, Top, Bondi Blue
922-3563	Bezel, Outer, Front
922-3564	Panel, Front, Lower, Bondi Blue
922-3566	Fan with Bracket
922-3568	Board, Power / Headphone
922-3571	EMI Finger, PC Cardcage, Pkg. of 5
922-3572	Door, I / O, with Grommet, Bondi blue
922-3573	Cover, Access, Lower, with Handle, Bondi Blue
922-3574	Board, Filter, Power
922-3577	Foot, Rubber, Pkg. of 4
922-3578	Housing, Bottom, Rear, Bondi Blue
922-3579	Microphone
922-3581	Cable, Power, 3 Prong, UK
922-3582	Cable, Power, 3 Prong, Europe
922-3584	Panel, Rear I / O

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3585	Board, IrDA
922-3586	Chassis, Logic Board / Mass Storage
922-3589	Board, Audio / Video Interconnect, with Shield
922-3590	Cable, Audio, Interconnect to Logic Board
922-3591	Cable, Video, Interconnect to Logic Board
922-3592	Cable, IRDA, Interconnect to Logic Board
922-3593	Cable, Hard Drive, Power
922-3594	Cable, Data, Hard Drive / CD
922-3598	Power Cord, 110 V, US
922-3599	Power Cord, Japan
922-3600	Power Cord, Europe
922-3601	Power Cord, UK
922-3602	Power Cord, Denmark
922-3603	Power Cord, Australia
922-3604	Power Cord, Swiss
922-3605	Bezel, CD, Bondi Blue
922-3607	CRT Assembly, Northern Hemisphere
922-3608	CRT Assembly, Southern Hemisphere
922-3609	CRT Assembly, Equator
922-3610	Frame, CRT, Top
922-3611	Screw, Phillips, Self-Tapping, Pkg. of 10
922-3612	Screw, Phillips, Machine, Pkg. of 10
922-3613	Screw, Phillips, Self-Tapping with Washer, Pkg. of 10
922-3614	Screw, Phillips, Machine, Small, Pkg. of 10
922-3615	Bezel, Inner, Front
922-3616	Carrier, Hard Drive
922-3617	Screwlocks, Pkg. of 6
922-3618	Ball, Mouse, Pkg. of 5
922-3619	Retainer, Mouse
922-3620	Standoff, Modem, Locking, 10mm, Pkg. of 10
922-3621	Grounding Wire, CRT
922-3622	Cable, Video, RGB
922-3623	Cable, LED
922-3624	Cable, Audio, 5-Connector

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3625	Cable, Power Supply
922-3626	Gasket, CRT Bottom Frame, Rubber, Pkg. of 5
922-3627	Frame, CRT, Bottom
922-3628	Cable, IRDA, Enclosure to A / V Interconnect Board
922-3629	Cable, IDE, Master / Slave, 40-Pin
922-3630	Screw, Phillips, 3.5X.5X14, Pan, Pkg. of 10
922-3631	Heatsink, Microprocessor Board, 300 MHz
922-3634	Screw, Pan, 14mm, Crest Cup, Pkg. of 10
922-3637	Screw, CD Bezel to CD
922-3638	Screw, Pan, M3X6MM, Crest Cup, Pkg. of 10
922-3639	Screw, M3X.5X6MM, Phillips, Pkg. of 10
922-3640	Screw, Pan, 4-40X.25, Pkg. of 10
922-3645	Screw, Pan, M3.5X.6X8MM, Pkg. of 10
922-3646	Housing, Display, 14.1", CPRC / International Only
922-3647	Bezel, Intermediate
922-3648	Monitor Stand, Tripod
922-3649	Housing, Rear
922-3650	Board, User Controls
922-3651	Bezel, Front
922-3653	Board, Convergence / Tilt
922-3654	Cable, Video
922-3655	Ground Strap, CRT
922-3656	CRT Assembly, Northern Hemisphere, Studio Display 17
922-3657	CRT Assembly, Southern Hemisphere, Studio Display 17
922-3659	Screw, Rear Housing, Pkg. of 10
922-3660	Screw, Tripod Stand, Pkg. of 10
922-3662	Screw, Tap, User Controls, Pkg. of 10
922-3663	Screw, Main Deflection Board to CRT Frame, Pkg. of 10
922-3664	Screw, CRT Mounting, Pkg. of 10
922-3666	Cable, Flex, Data, Display, 12.1" TFT, CPRC / International Only
922-3669	Screw, Tap, Pan / Washer, Pkg. of 25
922-3672	Board, FireWire, w / shield
922-3673	Board, Front Panel
922-3677	Cable, USB Keyboard Extension

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3678	Foot, Rubber, with Adhesive, Pkg. of 2
922-3679	Gasket, Microphone, iMac, Pkg. of 4
922-3680	Microphone
922-3681	Housing, Rear
922-3682	Monitor Stand, Tripod
922-3683	Chassis, Version 1
922-3684	Panel, Front
922-3685	Panel, Side, Left
922-3686	Panel, Side, Right , Access
922-3687	Standoff, Hex, M3.5x6, 16mm, Pkg. of 10
922-3688	Bracket, Fan, Version 1
922-3689	Shield, Front Panel
922-3690	Panel, Lower, Front
922-3691	Panel, Top
922-3692	Housing, Speaker
922-3693	Cover, Security Bar
922-3695	Support, Front
922-3696	Support, Rear
922-3697	Handle, Top, Front or Rear
922-3698	Panel, Lower, Rear
922-3699	Panel, Rear, Vented
922-3700	Panel, I / O, Cover
922-3701	Panel, Latch
922-3704	Shield, PCI Slots, Pkg. of 5
922-3705	Shield, EMI, CD / DVD Drives, Rear
922-3706	Cable, Front Panel, Flat Gray
922-3707	Cable, IDE / ATA
922-3708	Cable, Audio
922-3709	Cable, FireWire, Power, Shielded
922-3710	Carrier, Drive, CD / DVD / Zip drives
922-3711	Carrier, Hard Drives, Version 1
922-3712	Speaker
922-3714	Cable, Ultra ATA, Version 1
922-3717	Cable, Ultra2 LVD SCSI, Version 1

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3721	Power Cord, 110 V, Shadow Gray, US / Canada
922-3722	Screw, Tap, Sems, M4x8mm, Pkg. of 5
922-3723	Housing, Bottom, Assembly
922-3724	USB Assembly
922-3725	Bezel, Front
922-3726	Bezel, Intermediate
922-3727	Mouse, USB, Blueberry
922-3728	Keyboard, USB, US, Blueberry
922-3729	Grommet, Latch, Pkg. of 10
922-3730	Power Cord, 110 V, US
922-3731	Power Cord, Japan
922-3732	Power Cord, Europe
922-3733	Power Cord, UK
922-3734	Power Cord, Denmark
922-3735	Power Cord, Australia
922-3736	Power Cord, Swiss
922-3737	Cable, Modem, Flex
922-3738	Standoffs, Nylon, Dual Locking, Pkg. of 5
922-3739	Door, I / O, with Grommet, Ice
922-3739	Door, I / O, Rev. 2
922-3740	Panel, Front, Lower, Blueberry
922-3741	Board, Audio / Video Interconnect, without IrDA
922-3741	Board, Audio / Video Interconnect, with Shield, Rev. 2, w / o IrDA
922-3742	Door, Audio / Video, Rev. B
922-3743	Monitor Stand, Desktop, Rev. B
922-3744	Monitor Stand, Flip-Out, Rev. B
922-3745	Power Cord, Jumper, Shadow Gray, International, Rev. B
922-3746	Spring, Keyboard, Pkg. of 6
922-3747	Cable, Video / USB, External
922-3749	Board, User Controls
922-3750	Ball, Mouse, Pkg. of 5
922-3751	Cable, FireWire, Unshielded
922-3753	Power Cord, Jumper, Shadow Gray, International
922-3754	Cover, Anode Cap

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3755	Screw, Tap, Pan, M3, Stl / Zinc, Pkg. of 10
922-3756	Label, Product ID, Studio Display 21, Pkg. of 4
922-3757	Label, USB, Pkg. of 4
922-3758	Cover, USB
922-3759	Screw, M5x12, Allen, Pkg. of 8, Handles / Supports
922-3760	Screw, M3.5x8, Allen, Pkg. of 5, Vented Rear Panel
922-3761	Screw, M5x18, Allen, Pkg. of 8, Access / Side Panels
922-3762	Screw, M3.5x4, Allen, Pkg. of 5, Access / Chassis
922-3763	Cable, Phone, Ice
922-3764	Adapter, Macintosh to VGA, Smoke
922-3766	Bracket, Power Supply
922-3767	Retainer, Hard Drive Carrier
922-3768	Label, Product ID, Pkg. of 5
922-3769	Adapter, VGA to Macintosh
922-3769	Adapter, VGA to Macintosh
922-3770	Adapter, SCSI, 50 pin to 25 pin
922-3772	Cover, Access, Lower, with Handle, Blueberry
922-3773	Housing, Rear, Top, Blueberry
922-3774	Bezel, Outer, Front, Blueberry
922-3775	Housing, Bottom, Rear, Blueberry
922-3776	Bezel, CD, Blueberry
922-3778	Gap Filler, Processor, EMI, Supression, Pkg. of 5
922-3779	Housing, Rear, Top, Strawberry
922-3780	Housing, Rear, Top, Grape
922-3781	Housing, Rear, Top, Tangerine
922-3782	Housing, Rear, Top, Lime
922-3783	Bezel, Outer, Front, Strawberry
922-3784	Bezel, Outer, Front, Grape
922-3785	Bezel, Outer, Front, Tangerine
922-3786	Bezel, Outer, Front, Lime
922-3787	Panel, Front, Lower, Strawberry
922-3788	Panel, Front, Lower, Grape
922-3789	Panel, Front, Lower, Tangerine
922-3790	Panel, Front, Lower, Lime

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3791	Cover, Access, Lower, with Handle, Strawberry
922-3792	Cover, Access, Lower, with Handle, Grape
922-3793	Cover , Access, Lower, with Handle, Tangerine
922-3794	Cover, Access, Lower, with Handle, Lime
922-3795	Bezel, CD, Strawberry
922-3796	Bezel, CD, Grape
922-3797	Bezel, CD, Tangerine
922-3798	Bezel, CD, Lime
922-3799	Keyboard, USB, US, Strawberry
922-3800	Keyboard, USB, US, Grape
922-3801	Keyboard, USB, US, Tangerine
922-3802	Keyboard, USB, US, Lime
922-3803	Mouse, USB, Strawberry
922-3804	Mouse, USB, Grape
922-3805	Mouse, USB, Tangerine
922-3806	Mouse, USB, Lime
922-3827	Screw, SEMS, M3x.7x8, Pkg. of 10
922-3828	Screw, TP, M4x.7x12, Pan / Washer, Pkg. of 10
922-3835	Grounding Wire, CRT, Rev. 2
922-3836	Cable, Audio, Rev. 2
922-3837	Frame, CRT, Bottom, Rev. 2
922-3838	CRT Assembly, Northern Hemisphere, Rev. 2
922-3839	CRT Assembly, Southern Hemisphere, Rev. 2
922-3840	CRT Assembly, Equatorial, Rev. 2
922-3841	Fan, 92mm, Rev. 2
922-3842	Cable, Video, RGB, Rev. 2
922-3853	Cable, Video Output, Xclaim VR
922-3854	Bracket, Fan, Version 2
922-3858	Enclosure with Chassis, Version 2
922-3860	Cable, Ultra ATA, Version 2
922-3861	Cable, Ultra2 LVD SCSI, Version 2
922-3863	Pad, Thermal, Pkg. of 5
922-3871	Support Plate, Carrier
922-3872	Shield, EMI, Zip Drive

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-3873	Screw, Pkg. of 5
922-3874	Screw, Pkg. of 15
922-9375	Ribbon Cable Unit
922-9376	Motor Cable Unit
922-9377	Switch, Power
922-9378	Motor, Carriage Drive
922-9379	Motor, Paper Feed
922-9380	Guide, Ink Tube
922-9381	Ground Cable
922-9382	Cable, Carriage, 19 pin
922-9383	Cable, Carriage, 20 pin
922-9384	Cable, Paper Sensor
922-9385	Cable, Connector Card Left
922-9386	Encoder Unit
922-9387	Separation Sheet
922-9388	Belt, Carriage
922-9389	Base, Control Panel
922-9390	Plate, Upper Cover
922-9391	Plate, Ground, Control Panel
922-9392	Plate, Ground, Paper Feed Motor
922-9393	Plate, Ground, Right Frame
922-9394	Plate, Ground, Holder, Logic Card
922-9395	Plate, Ground , Ink Compartment
922-9396	Plate, Press
922-9397	Holder, Logic Board
922-9398	Guide Ribbon Cable
922-9399	Arm, Power Switch
922-9400	Arm, Paper Sensor
922-9401	Print Timing Slit
922-9402	Cover, Carriage Board Holder
922-9403	Cover, Logic Board
922-9404	Cover, Sensor
922-9405	Holder, Carrige Board
922-9406	Holder, Joint

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

922-9407	Holder, Paper Sensor
922-9408	Holder, Encoder
922-9409	Holder, Card Cover
922-9410	Plate, Frame, Right
922-9411	Plate, Frame, Left
922-9412	Bracket, Idler Roller
922-9413	Roller, Idler
922-9414	Roller, Eject
922-9415	Roller, Paper Feed
922-9416	Photocoupler
922-9417	Stopper, Cap
922-9418	Spring, Plate, Right Frame
922-9419	Frame, Left
922-9420	Frame, Right
922-9421	Pinch Roller Unit
922-9422	Pick-up Roller Unit
922-9423	Plate, Paper Lifting
922-9424	Card, Connector, Right
922-9425	Card, Connector, Left
922-9426	Control Panel
922-9427	Ink Absorber Plate
922-9428	Ink Absorber Assembly
922-9429	Head Cover Unit Assembly
925-0008	Sensor, Optical Paper-Out
925-0009	Thermprotector, 210°C, Fuser Assy
925-0011	Sensor, Optical, Paper Empty
927-0002	EPROM, Model MB
930-0001	LED Assembly, ColorMonitor Ile-S
930-0002	LED Assembly, (ColorMonitor Ilc-S), Composite Ilc-SS
930-0003	LED Assembly, ColorMonitor Ile / Ilc-H, (Composite Ilc-H)
930-0004	LED, AppleColor RGB
930-0005	LED Assembly, Monochrome Monitor
930-0008	LED Assembly with Cable
931-0026	Set, Screws, Pkg. of 2

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

931-0030	Screw, Captive, 3 x 0.5mm, Pkg. of 10
933-0014	Board, I / O Connector
935-0001	Wire Ribbon and Spring
935-0002	AC Cord, AppleColor RGB
935-0003	AC Cord, Monochrome Monitor
935-0004	Lope, Guide (replaced by 971-0026)
935-0006	Auto Load Solenoid
936-0001	Power Cord, 110 V, White
936-0003	Cable, Interface
936-0006	Cable, Flexible
936-0007	Cable, PCB Interconnection
936-0008	Cable, Operation Panel
936-0009	Cable, Noise Filter
936-0015	Cable Assembly
936-0029	Power Cord, 110 V, Smoke
936-0034	Cable, Sheet Feeder
936-0041	Cable, Status Panel
936-0042	Cable, Optical Fiber
936-0043	Cable, Optical Assembly / Logic Board, 4-bit
936-0044	Cable, Scan Switch Assembly
936-0045	Cable, Limit Switch Assembly
936-0047	Cable, Power Supply Board / Logic Board
936-0048	Cable, Laser Harness
936-0059	Cable, Interconnect
936-0060	Cable, Bright / Contrast
936-0100	Cable, Power Supply Block to DC Power Supply
936-0101	Cable, DC Controller to High-Voltage Power Supply
936-0102	Cable, DC Controller to Power Supply Block
936-0103	Cable, DC Controller to Fuser
936-0106	Cable, Inverter
936-0107	Power Cord, 120 V, 1M, Captive
936-0108	Cable, Flex with Shim, FSTN Display, PB 140 / 145 (replaced by 922-0820)
937-0001	Switch, Power
937-0005	Switch, White Only,(ColorMonitor Ile / Ilc-S),Composite Ilc-S

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number Part Name

937-0006	On / Off Switch, (ColorMonitor 110V-S-Ile / Ilc-S), Composite Ilc-S
937-0014	On / Off Switch Assy, AppleColor RGB
937-0018	On / Off Switch, Monochrome Monitor
937-0019	AC Input Assembly with Fuse
937-0022	Signal Input Assembly
937-0026	Switch, Degaussing
937-0030	Switch, Home Position Kit
937-0031	Switch, Volume Control
937-0032	Switch, On / Off
937-0033	Switch, Paper Detect
937-0034	Switch, Cut Sheetfeeder
937-0035	Solenoid, Paper Bail
937-0038	AC Inlet, On / Off Switch Assy
937-0040	Switch, On / Off, Filter Assembly
937-0051	Keypad, Locking, AEK II, White
938-0003	Fuser Heater, 115V, 620W
938-0004	Heater, Fuser, 220 / 240AV
938-0005	Lamp, 4-bit and 8-bit
939-0015	Tractor Drive Gear
939-0016	Gear, Ribbon Drive
939-0018	Gear, Platen Drive, Pkg. of 3
939-0019	Gear, Platen Drive Idler, Pkg. of 3
939-0020	Gear, C.S.F. Drive, Pkg. of 3
939-0021	Gear, Ribbon Lift Shift, Pkg. of 3
939-0022	Gear, Ribbon Lift Cram, Pkg. of 3
939-0023	Gear 19T, Paper Pickup
939-0024	Gear 57T, Paper Pickup
939-0025	Gear 24T, Feeder Guide
939-0032	Gear 32T, Fuser Assy
939-0033	Gear / Arm Assy, Fuser Idler
939-0034	Gear 27T / 18T, Fuser Assembly
939-0035	Gear 20T, Fuser Assy
939-0038	Gear, C.S.F. Drive, Pkg. of 3
939-0042	Gear 14T, Fuser Assembly

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

941-0001	Fuse MT4-2A (2Amp 3AG)
941-0002	Fuse 1A
941-0005	Fuse, 125V / 6.3
941-0010	Fuse, 3 AMP
941-0012	Fuse, 1.5 AMP
941-0014	Fuse, 8 AMP
941-0016	Fuse, 2.5 A, 250 V, Pkg. of 5
941-0017	Fuse, 4 A, 250 V, Pkg. of 5
941-5219	Fuse, 1.5 Amp, 125V, Pkg. of 5
941-5220	Fuse, 2 Amp, 125V, Pkg. of 5
941-5221	Fuse, 4 Amp, 125V, Pkg. of 5
941-5222	Fuse, 3.15 A, 125 V
941-5223	Fuse, 3.15 A, 250 V, International
941-5224	Fuse, 2.5 A, 250 V, Pkg. of 10
941-5225	Fuse, 2.5 A, 250 V, Slow Blow, Pkg. of 5
944-1189	EMI Foam, Thin
946-0049	Tape, Clear Polyester 1 / 2
947-0007	Roller, Upper Fuser Assy
948-0002	Bracket, Mounting, 40 MB Hard Drive, for use with 661-1632 (replaced by 922-0008)
948-0016	Switch Bracket, ColorMonitor Ile-H, (Composite Ile-H)
948-0022	Shield, 800K External Drive
948-0031	Cover, Video Board C, Metal
948-0032	Paper Out Sensor
948-0033	Paper Guide Plate
948-0034	Cap, Roller, Fuser Assy
948-0035	Eliminator, Static
948-0037	Cover, Logic Board
948-0038	Frame
948-0042	Paper Pan Sub-Assembly
948-0043	Wire Form Assembly
948-0045	Complete Tractor Assembly
948-0046	Paper Pan (B)
948-0048	Serial Controller Mounting Plate
948-0050	Cover, Logic Board, 24-bit

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

948-0128	Shield, Logic Board, 4-bit
948-0132	Grounding Bracket
948-0134	Bracket, Transformer, 100-240 V
948-0136	Frame
948-0138	DC Controller Mounting Plate
948-0139	End Plate, Primary
948-0141	Plate, High-Voltage Ground
948-0145	Static Eliminator
948-0148	Battery Contact
948-0149	Bracket, Mounting, 20 MB Hard Drive, use with 661-1622
948-0150	Shield, Bottom Housing Assembly
948-0153	I / O Board Bracket
948-0155	Plate, Board Duct
948-0156	Ground Plate A
948-0157	Bracket, Mounting, 40 MB Hard Drive, for use with 661-1644
949-0002	Cover, Bottom, White
949-0003	Cover, Lower Right
949-0004	Cover, Upper Right
949-0006	Platen
949-0008	Cover, Paper
949-0009	Cover, Ribbon, White (replaced by 949-0084)
949-0010	Cover, Tractor, White (replaced by 949-0085)
949-0011	Cover, Top, White
949-0018	Bezel, Color Mon IIc-S, White
949-0019	Rear Cover, Color Mon IIe-S, Beige
949-0020	Rear Cover, Color Mon IIc-S, White
949-0023	Bezel, Color Mon IIe-H, Beige
949-0024	Bezel, Color Mon IIc-H White (replaced by 949-0081)
949-0025	Rear Cover, Color Mon IIe-H, Beige
949-0026	Rear Cover, Color Mon IIc-H, White
949-0027	Rear Panel / AC Power Cord Assy, Col Monitor IIe-H
949-0028	Rear Panel / AC Power Cord Assy, Col Monitor IIc-H
949-0029	Paper Guide
949-0052	Bracket, Cover Interlock

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

949-0054	Bezel Assembly, AppleColor RGB
949-0055	Rear Cover, AppleColor RGB
949-0056	Front Foot, Monitor
949-0057	Bottom Plate, Monitor
949-0067	Bezel, Monochrome Monitor
949-0068	Rear Cover, Monochrome Monitor
949-0077	Bezel, Composite Monitor - Ilc-S-Platinum
949-0078	Rear Cover, Composite Monitor-Ilc-S-Platinum
949-0079	Bezel, Plastic Case
949-0081	Bezel, Composite Monitor Ile-H-Platinum
949-0082	Rear Cover, Composite Monitor-Ile-H-Platinum
949-0084	Cover, Ribbon, Platinum
949-0085	Cover, Tractor, Platinum
949-0086	Cover, Top, Platinum
949-0087	Cover, Bottom, Platinum
949-0088	Tray (Upper), Paper, Imagewriter II SF, White
949-0089	Housing, Rear, Plastic
949-0103	Desc. Rear Panel, Composite Ile-H-Platinum
949-0113	Bezel, Plastic Case
949-0114	Housing, Rear, Plastic, without product ID label
949-0115	Stand Attachment, Plastic Bottom
949-0116	Bezel, Plastic Case
949-0117	Housing, Rear, Plastic
949-0118	Stand Attachment, Plastic Bottom
949-0119	Cover, Adjustment Panel
949-0127	Cover, Adjustment Panel
949-0129	Roller, Carrier, Pkg. of 10
949-0131	Paper Guide for Optical Sensor
949-0136	Tray (Upper), Paper, Imagewriter II
949-0137	Cover, Front
949-0138	Cover, Top
949-0139	Cover, Bottom
949-0140	Main Cover
949-0141	PCA, Control Panel

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

949-0142	Button, Release
949-0143	Heater Cover
949-0144	Upper Cover
949-0145	Tray, Main
949-0146	Tray, Auxiliary
949-0147	Tray, Copy
949-0148	Cover, Front Upper
949-0149	Plate Pin, Left, Fusing Assembly
949-0150	Plate Pin, Right Fusing Upper
949-0151	Rail, Right Guide
949-0152	Cover, Bottom
949-0153	Rail, Left Guide
949-0154	Cap, Bottom Cover
949-0158	Shutter Arm
949-0159	Hook, Left
949-0160	Hook, Right
949-0161	Hook Guide, Left
949-0162	Hook Guide, Right
949-0163	Lifter, Left
949-0164	Lifter, Right
949-0165	Guide, Auxiliary
949-0166	Arm, Paper Sensing
949-0167	Cover, Right (replaced by 971-0026)
949-0168	Cover, Left (replaced by 971-0026)
949-0169	Lever, Feed Roller Cam, Pkg. of 6
949-0170	Guide, Ribbon Support, Pkg. of 3
949-0171	Lever, Paper Bail, Pkg. of 6
949-0172	Lever, Paper Bail Adj. Rt, Pkg. of 3
949-0173	Lever, Paper Out Detect, Pkg. of 3
949-0174	Lever, Paper Bail Adj. Lt, Pkg. of 3
949-0175	Lever, Paper Bail Arm Lt, Pkg. of 3
949-0176	Lever, Ribbon Lift Shaft, Pkg. of 6
949-0177	Lever, C.S.F. Detect, Pkg. of 3
949-0178	Link, Paper Bail / Solenoid, Pkg. of 3

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

949-0179	Lever, Paper Bail Arm Rt, Pkg. of 3
949-0180	Bracket, Paper Bail / Platen, Pkg. of 3
949-0182	Lever, Top Cover InterLock
949-0183	Lamp Arm Cover
949-0184	Arm, Pre-Conditioning Lamp
949-0185	Claw, Separation, Fuser Assembly (replaced by 076-8414)
949-0186	Lever, Delivery Sensing
949-0187	Power Supply Cover
949-0188	Paper Holder
949-0189	Rear Cover
949-0190	Rear Panel Kit
949-0191	Separation Finger Kit
949-0192	Forward Collator Paper Deflector
949-0193	Forward Collator Support Output
949-0194	Forward Collator Assembly
949-0195	Envelope Hopper
949-0203	Holder, Left Heater Terminator
949-0204	Holder, Right Heater Terminator
949-0206	Cover, Assembly with Glass
949-0208	Cover, Bottom Assembly, 4-bit
949-0209	Cover, Switch
949-0210	Cover, Top
949-0211	Cover, CCD Board
949-0214	Cover, AC Inlet
949-0217	Guide, Card
949-0218	Cover, Rear
949-0219	Cover, Front
949-0221	Cassette Pickup Assembly, White
949-0222	Cassette Pickup Assembly, Platinum
949-0223	Bezel, Plastic Case
949-0224	Housing, Rear, Plastic
949-0226	Cover, Interior
949-0231	Cassette Stop, Right
949-0232	Cassette Stop, Left

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number Part Name

949-0233	Alignment Tool, Metal Tip, (Replaced by 922-3504)
949-0240	Fuser Paper Guide
949-0242	Sound Damping Material
949-0247	Block, Main Body
949-0248	Cover, Bottom Assembly, Platinum
949-0249	Cover, Top, Platinum
949-0250	Cover, Plastic, PCB, 160 SC
949-0251	Ground Plate, Power Supply, 110 / 120 V
949-0253	Adjustment Magnet Kit
949-0254	Guide, Flex Cable
949-0259	High-Voltage Tray
949-0260	Fuser Entrance Guide
949-0261	Stackability Guide
949-0262	Lever, Paper Selector
949-0263	Ground Plate Assembly, Power Supply, 220 / 240 V
949-0265	Face-Up Tray Lock, Left
949-0266	Face-Up Tray Lock, Right
949-0267	I / O Shield, Upper
949-0268	I / O Shield, Lower
949-0269	LED Holder
949-0270	Door Pivot
949-0271	DC Controller Interconnect Mount
949-0272	End Plate, Secondary
949-0273	Paper Support Plate
949-0274	Cover, Cassette Stop
949-0275	Arm, Paper Pickup
949-0276	Face-Up Cover Assembly
949-0277	Actuator, PS502
949-0278	Door Release Lever
949-0279	Multipurpose Tray Assembly, 50 sheet
949-0280	Cover, Rear
949-0281	Cover, Left
949-0282	Status Panel
949-0283	Cover, Top

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

949-0284	Cover, Bottom Left
949-0285	Cover, Bottom Right
949-0286	Upper Chassis
949-0287	Face-Up Tray C
949-0288	Face-Up Tray B
949-0289	Face-Up Tray A
949-0290	Face-Up Tray Support, Right
949-0291	Face-Up Tray Support, Left
949-0292	I / O Board Rail
949-0293	Cover, Front
949-0294	Cover, LED
949-0295	Front Access Door
949-0296	Paper Guide Plate
949-0297	Bezel, Plastic Case
949-0298	Housing, Rear, Plastic
949-0299	Access Door Cap
949-0300	Face-Up Tray Latch
949-0303	Housing, Rear, Plastic, International
949-0304	Holder, Main Board, Plastic
949-0307	Cover, Logic Board
949-0308	Cover, Front Access
949-0309	Cover, Platen
949-0311	Cover, Lower Access
949-0312	Lever, Paper Release
949-0313	Cover, Bottom, Platinum
949-0314	I / O Board Bracket
949-0315	Cover, Bottom Assembly, 8-bit, without product ID label
949-0319	Tray, Manual Feed
949-0320	Cover, Ribbon, Platinum
949-0321	Shield, Operation Panel
949-0325	Guide, CSF Output Tray Extension
949-0326	I / O Board Shield
949-0328	Plate, Stack-End
949-0329	Monitor Stand, Tilt Swivel

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

949-0330	Bezel, Plastic Case
949-0331	Housing, Rear, Plastic, without product ID label
949-0332	Paper Support Plate
949-0333	Housing, Display, Rear
949-0334	Retainer Ring, Trackball (replaced by 922-1699)
949-0335	Ball, Trackball (replaced by 922-1702)
949-0336	Door, Backup Battery
949-0337	Cover, Modem Connector
949-0338	Cover, Interconnect Cables
949-0341	Multipurpose Tray Assembly, 70 sheet
949-0352	Cover, Clutch
949-0353	Plate, Clutch
949-0354	Insulator, Bottom Housing Assembly
949-0357	Keyboard Assembly, with Keycaps, AK II, Version A
949-0358	Keyboard Assembly, with Keycaps, AK II, Version B
949-0362	Ball, Trackball (replaced by 922-1701)
949-0363	Retainer, Trackball (replaced by 922-1698)
949-0364	Shield, Modem
949-0365	Door, Battery
949-0366	Shield, Bezel
949-0370	Backlight Assembly, CPRC / International Only
949-0374	Monitor Stand, Tilt-Swivel
949-0375	Housing, Rear, Plastic
949-0376	Bezel, Plastic Case (replaced by 949-0394)
949-0377	Insulator, Inverter
949-0378	Insulator Contact
949-0379	Shield, Serial Controller
949-0380	DC Controller Interconnect Mount
949-0381	Cover, Rear
949-0382	Test Button Access Cap
949-0383	Density Adjustment Cover
949-0384	Insulator, Bright / Contrast
949-0385	Cover, Adjustment Panel
949-0388	Cover, Top, 24-bit

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

949-0390	Cover, Top Assembly, 24-bit
949-0391	Cover, Bottom Assembly, 24-bit
949-0393	DC Controller Mounting Bracket
949-0394	Bezel, Plastic Case, Rev. B
952-0012	Magnet, Case Top, Pkg. of 10
952-0014	Clip, Base Retainer, Security
955-0001	Standoff, Shoulder, M12.6x3.95x13 Stl
955-0005	Shims, ImageWriter II (3 sets of 5 Shims)
956-0001	Screw / Knob Set, ColorMonitor-S
956-0002	Screw / Knob Set, ColorMonitor-H
956-0003	Screw / Knob Set, AppleColor RGB
956-0004	Screw / Knob Set, Monochrome Monitor
956-0005	Screw / Knob Set, Composite Ile-H-Platinum
956-0006	Screw / Knob Set, Composite Ilc-S-Platinum
956-0007	Screw / Knob Set
956-0008	Casette Latch Set
956-0010	Foot, Rubber
956-0012	Screw / Knob Set (Screws, Contrast / Brightness Knobs, Feet, Doors)
956-0014	Rubber Feet, Pkg. of 4
956-0015	Screw / Knob Set (Screws, Contrast / Brightness Knobs, Feet, Doors)
956-0016	Platen Knob without RIBS
956-0021	Button, Eject, AppleCD SC
956-0022	Foot, Rubber
956-0023	Screw / Knob Set
956-0024	Screw / Knob Set
956-0028	Screw / Knob Set
956-0029	Knob, Brightness / Contrast
956-0030	Cover, Bottom and Screw
956-0039	Foot, Front, Rubber
957-0038	Spring, Fuser Roller, Grounding
957-0041	Spring, Bail Roller Arm, Pkg. of 3
957-0054	Spring, Platen Cradle, Pkg. of 2
957-0055	Spring, Paper Pan, Pkg. of 2
957-0060	Spring, Paper Bail Arm, Pkg. of 5

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number **Part Name**

958-0005	Ring, Snap, Fuser
958-0006	Bush, Carrier Shaft, Pkg. of 10
958-0007	Pad (replaced by 971-0026)
958-0008	Mylar, Sheet, Platen Cradle, Pkg. of 5
958-0013	Mylar, Bottom
958-0015	E-Ring, E-4, Pkg. of 2
958-0016	E-Ring, E-6, Pkg. of 2
958-0017	Mylar, Paper Guide Adjustment
959-0002	Belt, Carrier
959-0003	Motor Assembly, Ribbon
959-0004	Motor, Carrier
959-0005	Motor, Paper Feed
959-0015	Motor, ImageWriter II SF
959-0016	Motor, Carrier Drive
959-0017	Motor, Paper Feed
959-0018	Motor Assembly, Color Ribbon
959-0020	Carrier Felt Set, Pkg. of 6
959-0021	Fan, Lower
959-0022	Fan, Upper
959-0023	Roller, Pickup
959-0024	Pulley, Carrier Belt, Pkg. of 3
959-0025	Bearing, Platen Sleeve, Pkg. of 6
959-0026	Bearing, Carrier Frame, Pkg. of 3
959-0027	Pin Assembly, Ribbon Box Drive, Pkg. of 5
959-0028	Bearing, Carrier Shaft Lt, Pkg. of 3
959-0029	Bearing, Carrier Shaft Rt, Pkg. of 3
959-0030	Collar, Cam Gear, Pkg. of 6
959-0033	Bearing, Lower Fuser RLT
959-0034	Bearing, Upper Fuser RLT
959-0037	Motor Carrier Assembly
959-0045	Holder, Face-Up Passive Delivery
959-0046	Motor, Paper Feed
959-0047	Motor Assy, Ribbon
961-0001	Noise Filter PCB Assembly

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

961-0003	Filter, Ozone
961-0006	Noise Filter Assembly, 110 / 240V
961-0007	Filter, Ozone, For Case with Door
962-0001	PCB, Print Head
970-0046	Eliminator, Static Charge
970-0047	Cleaner Brush
970-0048	Pad, Separation
970-0049	Cleaner, Fuser Roller
970-0142	Rod, Support, CSF Paper
970-0143	Rod, Support, CSF Output Tray (replaced by 922-1695)
970-0269	Extension, CSF Output Tray Size
970-0445	Power Switch Assembly, 120 V
970-0447	Power Transformer, 115 V
970-0453	Deflection Yoke
970-0473	Screw Disk Drive Bezel
970-0629	Power Cord
970-1001	Filter, Ozone
970-1002	Microswitch Mounting Bracket
970-1003	Lever, Release, White
970-1004	Felt, Cleaning
970-1005	Belt, Paper Separation
970-1008	Cable, Fuser Assembly
970-1009	Motor, Main Drive
970-1010	Gear 24T, Main Motor
970-1011	Roller, Paper Pickup
970-1012	Roller, Paper Feed
970-1014	Sensor, Paper-Out Detect
970-1017	Roller, Feed, Transfer Assy
970-1019	Roller Assembly, Separation / Feeder
970-1020	Board, Preconditioning Exposure
970-1021	Corona Assembly, Transfer
970-1022	Roller, Upper Fuser
970-1023	Roller, Lower Fuser
970-1024	Claw, Fuser Separation

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

970-1025	Guide, Delivery, Lower, Fuser
970-1027	Heater, Fuser, 115V, 500W
970-1028	Tray, Copy
970-1029	Tray, Print Auxiliary
970-1030	Tray, Manual Paper Feed
970-1031	Triac, AC16DIFR (115V)
970-1032	Solenoid, Cassette, 24VDC
970-1035	Board, Varistor
970-1036	Spring, Tension, Corona Wire (replaced by 971-0026)
970-1037	Cover, Wire Termination, RH
970-1038	Cover, Wire Termination, LH
970-1040	Wire, Guide Nylon Roll
970-1041	Actuator, Cartridge Shield
970-1042	Arm, Cartridge Latch Roller
970-1043	Arm, Paper Out Detect
970-1047	Bracket, Fuser, RH
970-1049	Thermal Protector Mounting Bracket
970-1050	Bushing, Bronze, Fuser Roller
970-1051	Bushing, Delivery / Transfer
970-1052	Bushing, Fuser
970-1054	Bushing, Paper Feed Idler
970-1055	Bushing, Paper Feed Roller
970-1056	Bushing, Shutter
970-1058	Cam, Cartridge Shutter
970-1064	Cleaner, Felt, Corona Wire
970-1065	Clip, Cable, 3ns
970-1067	Connector, High-Voltage
970-1068	Cover, Upper Fuser
970-1069	Cover, Wire Harness
970-1071	Exposure Control Dial, White
970-1073	Drum, Clutch Driver
970-1089	Gear 60T, Cassette Drive
970-1091	Guide, Delivery, Upper, Fuser
970-1093	Guide, Lower, Paper Feed

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

970-1095	Holder, Drum
970-1096	Holder, Paper Delivery Photosensor
970-1104	Microswitch Assembly, Cassette
970-1105	Mount, Cartridge Latch Roller
970-1106	Mount, Paper Delivery Sensor
970-1107	Mount, Stud, Transfer Guide
970-1108	Nut, Hex, 6mm, Blk Stl Znc
970-1109	Panel Assy, Display
970-1110	Panel, Left, White
970-1111	Panel, Rear, White
970-1112	Panel, Right, White
970-1113	Panel, Front, White
970-1114	Paper Guide, Lower, Fuser
970-1115	Paper Guide, Upper, Fuser
970-1118	Photosensor, Paper Delivery
970-1125	Plate, Microswitch Mtg
970-1127	Plate, Paper Guide, Lower
970-1128	Plate, Stop, Cassette
970-1129	Rear Latch, Upper Unit
970-1135	Roller, Cartridge Latch
970-1136	Roller, Delivery, Rubber
970-1139	Roller, Transfer Guide
970-1141	Plate, Grounding
970-1142	Door, Cassette, White
970-1143	Cover, Power Interlock Assembly
970-1146	Shield, Reflector, Preconditioning
970-1147	Shutter, Laser Shielding
970-1148	Socket, Faston, 115V, 20-24 AWG
970-1149	Transfer Guide Assembly
970-1151	Spacer, Microswitch
970-1165	Board Standoff, Nylon
970-1166	Stop, Rubber, Cassette
970-1170	Terminal, Grounding
970-1173	Terminal, SG

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

970-1182	Frame, Shield, Top
970-1183	Frame, Shield, Bottom
970-1187	Connector, Power Supply
970-1190	Cable, Power, DC Controller
970-1192	Cable, Internal, Video Interface
970-1193	Cable, I / O
970-1194	Connector, I / O Assembly
970-1258	Sub-Bezel, Universal Uni / Apple 5.25
970-1262	Keypad, Alps, Apple IIc (For P / N 661-0294, 661-0361)
970-1263	Keypad, Locking, AK, AEK, AEK II, Tan / Ivory
970-1267	Latch, Front
970-1269	Strap, Cassette Door
970-1271	Disc, Insulator, Drum Drive
970-1272	Plate, Manual Paper Feed
970-1273	Transformer, DC Power Supply (110V)
970-1274	Plate, Cassette / Roller Pick-Up
970-1277	Board, Control, ColorMonitor IIe / IIc-S, (Composite IIc-S)
970-1278	PS / Panel / AC Cord Assy, IIe 110V-S
970-1279	PS / Panel / AC Cord Assy, IIc 110V-S
970-1294	Lever Release, Platinum
970-1295	Panel, Left, Platinum
970-1296	Panel, Rear, Platinum
970-1298	Panel, Front, Platinum
970-1299	Door, Cassette, Platinum
970-1305	PS / Panel / AC Cord Assy, Composite IIc-110V (replaced by 970-1279)
970-1307	Paper Pickup Guide, Platinum
970-1308	Exposure Control Dial, Platinum
970-1309	Bushing, Cover Mounting
970-1310	Bushing, Cassette Drive
970-1311	Strap, Cassette Door, Platinum
970-1312	Plate, Mounting Connector
970-1314	Fuser Lid
971-0005	Status Panel
971-0006	Paper Deflector

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

971-0007	Mirror Assembly
971-0008	Board, Connector
971-0010	Pressure Assembly
971-0011	Hinge Assembly, Right
971-0012	Hinge Assembly, Left
971-0013	Gear Drive Assembly
971-0014	Main Motor Assembly
971-0015	Paper Feed Drive Assembly
971-0016	Shutter Assembly
971-0017	Paper Feed Assembly
971-0018	Feeder Assembly
971-0019	Transfer Guide Assembly
971-0020	Delivery Assembly, Fuser
971-0021	Roller, Delivery
971-0022	Delivery Coupler Assembly
971-0023	Delivery Assembly
971-0025	Pre-Conditioning Exposure Assembly
971-0026	Transfer Corona Assembly
971-0028	Board, Distribution
971-0037	Feeder Guide Assembly
971-0038	Filter Case, Ozone, with Door
971-0039	Roller, Paper Feed
971-0040	Cover, Scanner Assembly
971-0041	Lens Assembly
971-0042	Transfer Roller Guide
971-0043	Face-Down Delivery Assembly
971-0044	Feeder Assembly
971-0045	Pickup Roller Assembly
971-0046	Rod Assembly
971-0047	Roller, Face-Up Passive Delivery
971-0048	Deflector
971-0049	Face-Up Delivery Drive Assembly
981-0006	Board, CRT C, Rev. A (replaced by 982-0077)
981-0007	Board, Video C, with Cable

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

981-0016	Board, Interconnect
981-0017	Board, Bright / Contrast
981-0020	Board, Keyboard Encoder, AK II, Version A
981-0021	Board, Keyboard Encoder, AK II, Version B
981-0029	Base PC Assembly
981-0030	Board, Fan & Sensor
982-0004	Board, Contrast Brightness
982-0011	Board, Fuser Assembly Heater Safety
982-0016	Board, Video, Vertical (replaced by 982-0024)
982-0020	Board, Headphone, AppleCD SC
982-0023	Fan, Power Supply
982-0024	Board, Video, Vertical
982-0035	Board, Cassette Feeder
982-0039	Board, Density Adjustment
982-0045	Cable, Fuser Assembly to Power Supply
982-0048	Board, Interconnect
982-0055	Fan
982-0059	PCB, Print Head
982-0062	Board, Operation Panel Assembly
982-0077	Board, CRT C, Rev. B
982-0096	Board, Position Sensor
982-0105	Inverter Unit
982-0106	Speaker
982-0107	Board, Headphone, AppleCD SC Plus
982-0125	LED Assembly with Cable
982-0126	AC Inlet Assembly (replaced by 076-0077)
982-0127	Contrast / Brightness Assembly
982-0128	On / Off Switch Assembly
982-0136	Sub PCB Connector
982-0139	Focus H Stat Control
982-0496	Ethernet NB Card and Cables
983-0008	Holder, Lamp
983-0012	Latch, Magnetic Holder
983-0014	Fan

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

983-0018	Actuator & Cable Assembly, Power-On Switch
984-0001	Feed Roller, 10 Pk
984-0003	Roller, Paper Bail, 6 / pk
984-0005	Roller, Lower, Fuser Assy
984-0013	Cover, Screw, Bezel, Rubber
B076-0871	Power Adapter / Cable Kit, AppleDesign Powered Speakers I, Britain
B661-0037	Keyboard, British
B661-0048	Speakers, AppleDesign Powered II, Platinum, British
B661-0160	Card, TV Tuner, Great Britain
B661-0310	Keyboard, AppleDesign, British (discontinued and replaced by B922-2832)
B661-0409	Card, Modem, 14.4, British
B661-0476	Keyboard, Portable, British
B661-0712	Keyboard, British
B661-0731	Keyboard, Apple Adjustable, British
B661-0935	Keyboard, British (discontinued and replaced by B922-3109)
B661-1147	Card, TV / FM Tuner, Britain
B661-1504	Modem, 56K, UK, CPRC / International only (replaced by 661-2099)
B661-1612	Keyboard, British, Lightweight
B661-1652	Keyboard, British
B699-0505	Power Adapter / Charger, UK
B699-0517	Power Adapter, British (replaced by B922-0043)
B699-2050	Power Adapter, 240 V, 48-62 Hz, UK
B922-0043	Power Adapter, 17 W, British
B922-0376	Power Adapter, British
B922-0561	Power Adapter, Right Angle, Great Britain
B922-0661	Battery Recharger, 240 V, UK
B922-1117	Power Adapter, British
B922-2575	Keyboard, PB 1400, British
B922-2832	Keyboard, AppleDesign, British
B922-3083	Keyboard, Apple Extended II, British
B922-3109	Keyboard, British
B922-3348	Keyboard, UK
B922-3559	Keyboard, USB, British, Bondi Blue
B922-3728	Keyboard, USB, UK, Blueberry

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

B922-3728	Keyboard, USB, British, Blueberry
B922-3799	Keyboard, USB, British, Strawberry
B922-3800	Keyboard, USB, British, Grape
B922-3801	Keyboard, USB, British, Tangerine
B922-3802	Keyboard, USB, British, Lime
BF661-0409	Card, Modem, 14.4, Belgian French
C661-0037	Keyboard, French Canadian
C661-0297	Keyboard, Foreign Language (replaced by C661-0416)
C661-0310	Keyboard, AppleDesign, French Canadian (discontinued and replaced by C922-2832)
C661-0383	Keyboard, Apple, French Canadian (discontinued and replaced by C922-2832)
C661-0384	Keyboard, Apple Extended, French Canadian (discontinued and replaced by C922-3083)
C661-0416	Keyboard, Platinum, French Canadian
C661-0544	Keyboard II, Apple Extended, ISO, French Canadian
C661-0712	Keyboard, French Canadian
C661-0713	Keyboard, Canada
C661-0731	Keyboard, Apple Adjustable, French Canadian
C661-1612	Keyboard, French Canadian, Lightweight
C661-1652	Keyboard, French Canadian
C922-2575	Keyboard, PB 1400, Canadian / French
C922-2832	Keyboard, AppleDesign, French Canadian
C922-3083	Keyboard II, Apple Extended, French Canadian
C922-3109	Keyboard, French Canadian
C922-3348	Keyboard, Canada
C922-3559	Keyboard, USB, French Canadian
C922-3728	Keyboard, USB, French Canadian, Blueberry
C922-3728	Keyboard, USB, French Canadian, Blueberry
C922-3799	Keyboard, USB, French Canadian, Strawberry
C922-3800	Keyboard, USB, French Canadian, Grape
C922-3801	Keyboard, USB, French Canadian, Tangerine
C922-3802	Keyboard, USB, French Canadian, Lime
CZ661-0712	Keyboard, Czechoslovakian
CZ922-3728	Keyboard, USB, Czech
D661-0037	Keyboard, German
D661-0310	Keyboard, AppleDesign, German (discontinued and replaced by D922-2832)

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

D661-0384	Keyboard, Apple Extended, German (discontinued and replaced by D661-0544)
D661-0409	Card, Modem, 14.4, German
D661-0416	Keyboard, Platinum, German
D661-0476	Keyboard, German, Original Portable
D661-0544	Keyboard II, Apple Extended, ISO, German
D661-0712	Keyboard, German
D661-0731	Keyboard, Apple Adjustable, German
D661-0935	Keyboard, German (discontinued and replaced by D922-3109)
D661-1504	Modem, 56K, German, CPRC / International only (replaced by 661-2099)
D661-1612	Keyboard, German, Lightweight
D661-1652	Keyboard, German
D661-1680	Keyboard, Hamburg Grey (German)
D922-2575	Keyboard, PB 1400, German
D922-2832	Keyboard, AppleDesign, German
D922-3083	Keyboard II, Apple Extended, German
D922-3109	Keyboard, German
D922-3348	Keyboard, GBR
D922-3559	Keyboard, USB, German, Bondi Blue
D922-3728	Keyboard, USB, German, Blueberry
D922-3728	Keyboard, USB, German, Blueberry
D922-3799	Keyboard, USB, German, Strawberry
D922-3800	Keyboard, USB, German, Grape
D922-3801	Keyboard, USB, German, Tangerine
D922-3802	Keyboard, USB, German, Lime
DK661-0712	Keyboard, Danish
DK922-3728	Keyboard, USB, Denmark
E661-0037	Keyboard, Spanish
E661-0310	Keyboard, AppleDesign, Spanish (discontinued and replaced by E922-2832)
E661-0383	Keyboard, Apple, Western Spanish (discontinued and replaced by E922-2832)
E661-0384	Keyboard, Apple Extended, Western Spanish
E661-0416	Keyboard, Platinum, Spanish
E661-0476	Keyboard, Spanish, Original Portable
E661-0544	Keyboard II, Apple Extended, ISO, Western Spanish
E661-0712	Keyboard, Spanish

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

E661-0713	Keyboard, Spanish
E661-0731	Keyboard, Apple Adjustable, Spanish
E661-0935	Keyboard, Spanish (discontinued and replaced by E922-3109)
E661-1612	Keyboard, Spanish, Lightweight
E661-1652	Keyboard, Spanish
E922-2575	Keyboard, PB 1400, Western Spanish
E922-2832	Keyboard, AppleDesign, Spanish, Replaced by Y922-2832
E922-3083	Keyboard II, Apple Extended, Spanish
E922-3109	Keyboard, Spanish
E922-3348	Keyboard, Spanish
E922-3559	Keyboard, USB, Spanish, Bondi Blue
E922-3728	Keyboard, USB, Latin America
F661-0037	Keyboard, French
F661-0160	Card, TV Tuner, France
F661-0310	Keyboard, AppleDesign, French (discontinued and replaced by F922-2832)
F661-0409	Card, Modem, 14.4, French
F661-0416	Keyboard, Platinum, French
F661-0476	Keyboard, French, Original Portable
F661-0544	Keyboard II, Apple Extended, ISO, French
F661-0712	Keyboard, French
F661-0731	Keyboard, Apple Adjustable, French
F661-0935	Keyboard, French (discontinued and replaced by F922-3109)
F661-1147	Card, TV / FM Tuner, French
F661-1504	Modem, 56K, French, CPRC / International Only (replaced by 661-2099)
F661-1612	Keyboard, French, Lightweight
F661-1652	Keyboard, French
F922-2575	Keyboard, PB 1400, French
F922-2832	Keyboard, AppleDesign, French
F922-3083	Keyboard II, Apple Extended, French
F922-3109	Keyboard, French
F922-3348	Keyboard, French
F922-3559	Keyboard, USB, French, Bondi Blue
F922-3728	Keyboard, USB, French, Blueberry
F922-3728	Keyboard, USB, French, Blueberry

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

F922-3799	Keyboard, USB, French, Strawberry
F922-3800	Keyboard, USB, French, Grape
F922-3801	Keyboard, USB, French, Tangerine
F922-3902	Keyboard, USB, French, Lime
FN661-0409	Card, Modem, 14.4, Belgian
FN922-3728	Keyboard, USB, Belgium
H661-0409	Card, Modem, 14.4, Norway
H661-0712	Keyboard, Norwegian
H922-3728	Keyboard, USB, Norwegian
J076-0871	Power Adapter / Cable Kit, AppleDesign Powered Speakers I, Japan
J661-0037	Keyboard, Japanese
J661-0160	Card, TV-Tuner, Japan Only
J661-0205	Card, RAM, 4 MB, Japan
J661-0712	Keyboard, Japanese
J661-0713	Keyboard, Japan
J661-0870	Monitor, Apple Color Plus 14, Whole Unit, Japan
J661-0935	Keyboard, Japanese (discontinued and replaced by J922-3109)
J661-1001	Keyboard, Japanese, CPRC / International Only
J661-1147	Card, TV / FM Tuner, Japan
J661-1149	Keyboard, AppleDesign, Graphite (Discontinued and Replaced by J922-2327)
J661-1283	Board, Ethernet/Modem, Japan Only
J661-1475	Card, Ethernet / Modem, V.34, Japanese
J661-1621	Modem, Internal, Fax / Data, 2400, Japan
J661-1652	Keyboard, Japanese
J661-1703	Geoport Telecom Adapter, Japan
J661-3334T	Whole Unit, Modem, PCMCIA, Japan Only
J699-2050	Power Adapter, 100-105 V, 48-62 Hz, Japan
J922-0023T	Cable, Modem, Japan Only
J922-0024T	Coupler, Modem, Japan Only
J922-0025T	Noise Filter, Modem, Japan Only
J922-0026T	Modem Case, Japan Only
J922-0661	Battery Recharger, 100 V, Japan
J922-2327	Keyboard, AppleDesign, Graphite, Japanese
J922-2575	Keyboard, PB 1400, Japan

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

J922-3083	Keyboard II, Apple Extended, Japanese
J922-3109	Keyboard, Japanese
J922-3348	Keyboard, Japan
J922-3559	Keyboard, USB, Japan, Bondi Blue
J922-3728	Keyboard, USB, Japanese, Blueberry
J922-3728	Keyboard, USB, Japan, Blueberry
J922-3799	Keyboard, USB, Japan, Strawberry
J922-3800	Keyboard, USB, Japan, Grape
J922-3801	Keyboard, USB, Japan, Tangerine
J922-3802	Keyboard, USB, Japan, Lime
JA699-0505	Power Adapter / Charger, Japan
JK661-0712	Keyboard, Japanese, Kanaji (replaced by J661-0712)
K661-0409	Card, Modem, 14.4, Finland
K922-3728	Keyboard, USB, Finish
KH922-3728	Keyboard, USB, Korea
M1710SC/A	Macintosh LC II Logic Board Upgrade
MG922-3728	Keyboard, USB, Hungarian
N661-0409	Card, Modem, 14.4, Dutch
N922-3728	Keyboard, USB, Dutch
PA661-0014	Monitor, Apple Performa, .39 Dot Pitch, Whole Unit, Pacific
PA661-0477	Keypad, Numeric, International PA version, Original
PA661-0870	Monitor, Apple Color Plus 14, Whole Unit, Pacific
PA661-1611	Keypad, Numeric, International PA Version, Lightweight
PL922-3728	Keyboard, USB, Poland
PO661-0712	Keyboard, Portuguese
PO922-3728	Keyboard, USB, Portugese
S661-0037	Keyboard, Swedish
S661-0409	Card, Modem, 14.4, Swedish
S661-0476	Keyboard, Swedish, Original Portable
S661-0712	Keyboard, Swedish
S661-0731	Keyboard, Apple Adjustable, Swedish
S661-0935	Keyboard, Swedish (discontinued and replaced by S922-3109)
S661-1612	Keyboard, Swedish, Lightweight
S661-1652	Keyboard, Swedish

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

S922-2575	Keyboard, PB 1400, Swedish
S922-3109	Keyboard, Swedish
S922-3348	Keyboard, Swedish
S922-3559	Keyboard, USB, Swedish, Bondi Blue
S922-3728	Keyboard, USB, Swedish, Blueberry
S922-3728	Keyboard, USB, Swedish, Blueberry
S922-3799	Keyboard, USB, Swedish, Strawberry
S922-3800	Keyboard, USB, Swedish, Grape
S922-3801	Keyboard, USB, Swedish, Tangerine
S922-3802	Keyboard, USB, Swedish, Lime
SD661-0409	Card, Modem, 14.4, Swiss German
SF661-0409	Card, Modem, 14.4, Swiss French
SF661-0712	Keyboard, Swiss French
SF922-3728	Keyboard, USB, Swiss French
SM922-3728	Keyboard, USB, Swiss Multilingual
T661-0037	Keyboard, Italian
T661-0310	Keyboard, AppleDesign, Italian (discontinued and replaced by T922-2832)
T661-0384	Keyboard, Apple Extended, Italian
T661-0409	Card, Modem, 14.4, Italian
T661-0416	Keyboard, Platinum, Italian
T661-0476	Keyboard, Italian, Original Portable
T661-0544	Keyboard II, Apple Extended, ISO, Italian
T661-0712	Keyboard, Italian
T661-0731	Keyboard, Apple Adjustable, Italian
T661-1612	Keyboard, Italian, Lightweight
T922-2832	Keyboard, AppleDesign, Italian
T922-3083	Keyboard II, Apple Extended, Italian
T922-3559	Keyboard, USB, Italian, Bondi Blue
T922-3728	Keyboard, USB, Italian, Blueberry
T922-3728	Keyboard, USB, Italian, Blueberry
T922-3799	Keyboard, USB, Italian, Strawberry
T922-3800	Keyboard, USB, Italian, Grape
T922-3801	Keyboard, USB, Italian, Tangerine
T922-3802	Keyboard, USB, Italian, Lime

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

[Part Number](#) [Part Name](#)

TA922-3728	Keyboard, USB, Tawain
TH922-3728	Keyboard, USB, Thai
TU661-0712	Keyboard, Turkish
U705-0005	Write Protect Switch, Disk II- / / /
U815-0064	Button, Load
U815-0066	Door and Hinge Assembly
U815-0073	Actuator, Write Protect, Shugart (replaced by 815-0377)
U880-0007	Belt, Disk Drive
X076-0871	Power Adapter / Cable Kit, AppleDesign Powered Speakers I, Australia
X661-0008	Monitor, Apple Basic Color, Whole Unit, Australia
X661-0009	Monitor, Apple Basic Color, Whole Unit, Australia
X661-0114	Monitor, Apple Performa, .39 Dot Pitch, Whole Unit, Australia
X661-0870	Monitor, Apple Color Plus 14, Whole Unit, Australia
X699-0505	Power Adapter / Charger, Australia
X699-0517	Power Adapter, Australia (replaced by X922-0043)
X699-2050	Power Adapter, 240 V, 48-62Hz, Australia
X922-0043	Power Adapter, 17 W, Australia
X922-0376	Power Adapter, Australia
X922-0561	Power Adapter, Right Angle, Australia
X922-0661	Battery Recharger, 240V, Australia
X922-1117	Power Adapter, Australia
Y661-0409	Card, Modem, 14.4, Spain
Y922-2832	Keyboard, AppleDesign, Spanish
Y922-3559	Keyboard, USB, Spanish, Bondi Blue
Y922-3728	Keyboard, USB, Spanish, Blueberry
Y922-3728	Keyboard, USB, Spanish, Blueberry
Y922-3799	Keyboard, USB, Spanish, Strawberry
Y922-3800	Keyboard, USB, Spanish, Grape
Y922-3801	Keyboard, USB, Spanish, Tangerine
Y922-3802	Keyboard, USB, Spanish, Lime
Z076-0871	Power Adapter / Cable Kit, AppleDesign Powered Speakers I, Europe
Z661-0010	Monitor, Apple Basic Color, Whole Unit, Europe
Z661-0048	Speakers, AppleDesign Powered II, Platinum, International
Z661-0113	Monitor, Apple Performa Plus, .29 Dot Pitch, Whole Unit, Europe

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit





Service Parts Database

Click a column heading to sort the list by that category. Click any part to see the Detail View.

Part Number Part Name

Z661-0114	Monitor, Apple Performa, .39 Dot Pitch, Whole Unit, Europe
Z661-0160	Card, TV Tuner with Bracket, International
Z661-0477	Keypad, Numeric, International Z Version, Original Portable
Z661-0712	Keyboard, International
Z661-0870	Monitor, Apple Color Plus 14, Whole Unit, Europe
Z661-1147	Card, TV / FM Tuner with Bracket, International
Z661-1611	Keypad, Numeric, International Z Version, Lightweight
Z699-0505	Power Adapter / Charger, 220 Euro
Z699-0517	Power Adapter, European (replaced by Z922-0043)
Z699-2050	Power Adapter, 220 V, 48-62 Hz, Europe
Z922-0043	Power Adapter, European, 17 W
Z922-0329	Label, Bottom Assembly, Product ID, 24-bit
Z922-0376	Power Adapter, European
Z922-0561	Power Adapter, Right Angle, Int
Z922-0661	Battery Recharger, 230 V, Europe
Z922-1117	Power Adapter, Europe
Z922-3728	Keyboard, USB, International, Blueberry
Z922-3728	Keyboard, USB, International, Blueberry
Z922-3799	Keyboard, USB, International, Strawberry
Z922-3800	Keyboard, USB, International, Grape
Z922-3801	Keyboard, USB, International, Tangerine
Z922-3802	Keyboard, USB, International, Lime

Found: 6618 Search Criteria: imac

Search

Quick
Search

List
View

Detail
View

Print

Quit

